


**1 9 9 4**

***IMPORT SERVICE  
MANUAL***

---

***STEALTH***



---

***ELECTRICAL***

***Volume — 2***

## SAFETY NOTICE

### CAUTION

ALL SERVICE AND REBUILDING INSTRUCTIONS CONTAINED HEREIN ARE APPLICABLE TO, AND FOR THE CONVENIENCE OF, THE AUTOMOTIVE TRADE ONLY. **All test and repair procedures on components or assemblies in non-automotive applications should be repaired in accordance with instructions supplied by the manufacturer of the total product.**

---

Proper service and repair is important to the safe, reliable, operation of all motor vehicles. The service procedures recommended and described in this publication were developed for professional service personnel and are effective methods for performing vehicle repair. Following these procedures will help assure efficient economical vehicle performance and service reliability. Some of these service procedures require the use of special tools designed for specific procedures. These special tools should be used when recommended throughout this publication.

---

**Special attention should be exercised when working with spring or tension loaded fasteners and devices such as E-Clips, Circlips, Snap rings, etc., as careless removal may cause personal injury. Always wear safety goggles whenever working on vehicles or vehicle components.**

---

It is important to note that this publication contains various **Cautions** and **Warnings**. These should be carefully read in order to minimize the risk of personal injury, or the possibility that improper service methods may damage the vehicle or render it unsafe. It is important to note that these **Cautions** and **Warnings** cover only the situations and procedures Chrysler Corporation has encountered and recommended. Chrysler Corporation could not possibly know, evaluate, and advise the service trade of all conceivable ways that service may be performed, or of the possible hazards of each. Consequently, Chrysler Corporation has not undertaken any such broad service review. Accordingly, anyone who uses a service procedure, or tool, that is not recommended in this publication must assure oneself thoroughly that neither personal safety, nor vehicle safety, be jeopardized by the service methods they select.

### **SERVICE AND OWNER MANUALS**

*A available for Chrysler, Plymouth, Dodge, Dodge Truck, Jeep, and Eagle vehicles.*

Telephone orders may be placed at the number below. Credit cards are accepted (no CODS). Please have your order information available at time of call.

**CALL: (218) 572-7240 OR Fax: (218) 572-0615  
FOR A FREE CATALOG OR TO PLACE AN ORDER.**



# BackupServiceManual

# Stealth

1994

Volume-2  
Electrical

## FOREWORD

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnosis, disassembly, repair, and installation procedures along with complete specifications and tightening references. Use of this manual will aid in properly performing any servicing necessary to maintain or restore the high levels of performance and reliability designed into these outstanding vehicles.



Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

## GROUP / SECTION INDEX

Electrical .....	8
Fusible Link, Fuse and IOD or Storage Connector Location .....	
Inspection Terminal Location .....	[ ]
Grounding Location .....	
Relay Location .....	
Sensor Location .....	[ ]
Control Unit Location .....	
Solenoid, Solenoid Valve Location .....	
Diode Location .....	
Junction Block .....	
Centralized Junction .....	
Harness Connector Inspection .....	
How to Diagnose .....	
Configuration Diagrams .....	[ ]
Circuit Diagrams .....	
Engine Electrical .....	
Chassis Electrical .....	

NOTE:  
For Engine, Chassis & Body, refer to . . .  
Volume-1  
"Engine, Chassis & Body".





# 8-2 FUSIBLE LINK, FUSE AND IOD OR STORAGE CONNECTOR LOCATION

## FUSIBLE LINK, FUSE AND IOD OR STORAGE CONNECTOR LOCATION




Name	Symbol	Name	Symbol
Dedicated fuse ① to ⑦	B	Fusible link	A
Dedicated fuse ⑧ ⑨	C	IOD or Storage connector	B
Dedicated fuse ⑩	E	Multi-purpose fuse	D

NOTE  
The "Name" column is arranged in alphabetical order.

### <Engine compartment>



### <Interior>




19F0134

INSPECTION TERMINAL LOCATION


Name	Symbol	Name	Symbol
Data link connector	B	Fuel pump check connector	A
Engine speed detection connector <DOHC>	A	Ignition timing adjustment connector	A

NOTE  
The "Name" column is arranged in alphabetical order.


<Engine compartment>




16F0502



<Interior>









19F0134




GROUNDING LOCATION




<Engine compartment>





<Interior>




19F0134






16F0267





16F0268






RELAY LOCATION




Name	Symbol	Name	Symbol
ABS power relay	A	Magnetic clutch relay	D
Auto-cruise relay	J	MFI relay	K
Blower motor relay	F	Motor relay (ABS hydraulic unit)	B
Blower motor relay (HI)	L	Power window relay	G
Condenser fan motor relay (HI)	D	Radiator fan motor relay (HI)	A
Condenser fan motor relay (LO)	D	Radiator fan motor relay (LO)	A
Defogger relay	G	Rear intermittent wiper relay	M
Door lock power relay 1	G	Starter relay	A
Door lock power relay 2 (keyless entry system equipped car)	M	Taillight relay	A
Fog light relay	A	Theft-alarm horn relay*	F
Fuel pump relay	C	Theft-alarm starter relay*	I
Generator relay	A	Turn-signal and hazard flasher unit	H
Headlight relay	A	Upper beam relay	E
Horn relay	A	Valve relay (ABS hydraulic unit)	B

NOTE







- (1) \*: Vehicles with theft-alarm system.
- (2) Names are listed in alphabetical order.



<Engine compartment>








<Instrument panel>





<Quarter panel>



SENSOR LOCATION



Name	Symbol	Name	Symbol
ABS front speed sensor	W	Heated oxygen sensor	F
ABS rear speed sensor	X	Interior temperature sensor	U
Air inlet sensor (for A/C)	Q	Kickdown servo switch	L
Air thermo sensor (for A/C)	P	Knock sensor <DOHC>	D
Automatic transaxle oil temperature sensor <A/T>	L	Photo sensor	R
Camshaft position sensor and crankshaft position sensor <SOHC>	M	Power steering pressure switch	E
Camshaft position sensor <DOHC>	G	Pulse generator A, B <A/T>	L
Crankshaft position sensor <DOHC>	H	Revolution pick-up sensor	I
EGR temperature sensor <Turbo, Non Turbo (California)>	C	Steering wheel angle speed sensor	N
Engine coolant temperature sensor (for A/C)	O	Thermostat	I
Engine coolant temperature sensor (for engine control)	K	Throttle position sensor	J
Front impact sensor	V	Vehicle speed sensor	B
G sensor (for ABS)	S	Volume air flow sensor	A
G sensor (for ECS)	T		-











NOTE  
Names are listed in alphabetical order.








<Engine compartment>

<DOHC>


<SOHC>
















<Instrument panel>






19F0134





<Roof>



<Front under floor>



<Rear under floor>





CONTROL UNIT LOCATION




Name	Symbol	Name	Symbol
ABS control unit	J	Electronic control suspension control unit	I
Active exhaust control module	H	Engine control module	C
Air conditioning compressor lock controller	D	ETACS control unit	B
Air conditioning control unit	C	Keyless entry control unit	F
Auto-cruise control unit	D	Light automatic shut-off unit	F
Daytime running light control unit	A	Motor antenna control unit	G
ELC-4 A/T control module	C	SRS diagnosis unit	E



NOTE  
Names are listed in alphabetical order.

<Engine compartment>











<Instrument panel>





<Quarter panel . luggage compartment>




SOLENOID, SOLENOID VALVE LOCATION

Name	Symbol	Name	Symbol
EGR solenoid <Turbo, Non Turbo (California)>	C	Fuel pressure solenoid <Turbo>	A
Evaporative emission purge solenoid	B	Turbocharger waste gate solenoid <Turbo>	D


NOTE  
Names are listed in alphabetical order.

<DOHC>









7FU1002

<SOHC>





7FU1025



DIODE LOCATION



Name	Symbol	Name	Symbol
Diode (ABS circuit)	A	Diode (Theft-alarm circuit)	C
Diode (MFI circuit)	B	Diode (4WS fluid level warning light circuit)	D
Diode (Seat belt warning circuit)	C	-	-

<Engine compartment>




<Dash panel>


16F0502




19F0134




<Instrument panel>



19F0134



JUNCTION BLOCK




KX35-AC-R1601-N

Remarks


- (1) Alphabets assigned to the connectors are keyed to those assigned to connectors on P.8-20.
- (2) Terminals of the harness side connector are indicated in parentheses ( ).

Front

Back



16F0304




16F0058

# CENTRALIZED JUNCTION

## FUSIBLE LINK (Relay box in engine compartment)

No.	Circuit	Housing color	Rated capacity (A)
1	Generator circuit	Wine red	120
2	—	—	—
3	Lighting circuit	Green	40
4	Ignition switch circuit	Pink	30
5	Radiator fan motor and condenser fan motor circuit	Green	40
6	Junction block (Multipurpose fuse ①, ⑥, ⑭, ⑯, ⑰, ⑲)	Green	40
7	ABS circuit	Yellow	60
8	—	—	—
9	Power window circuit	Pink	30
10	Defogger circuit	Green	40
11	—	—	—




16F0256

DEDICATED FUSE


Power supply circuit	No.	Rated capacity (A)	Housing color	Circuit
Battery	1	20	Yellow	MFI circuit
Taillight relay	2	15	Blue	Taillight circuit
Fusible link ⑥	3	10	Red	Horn circuit
Fusible link ③	4	15	Red	Fog light circuit
Headlight relay	5	10	Red	Upper beam circuit
Battery	6	10	Red	Hazard light circuit
	7	10	Red	ABS circuit
Fusible link ⑤	8	20	Yellow	Condenser fan motor circuit
	9	10	Red	Air conditioning circuit
Defogger relay	10	10	Red	Remote controlled mirror heater circuit

<Relay box in engine compartment>




16F0256

<Air conditioning relay box in engine compartment>



16F0002


<Interior relay box>



16F0431

**MULTI-PURPOSE FUSE (In junction block)**

Power supply circuit	No.	Rated capacity (A)	Load circuit	
Battery	1	10	Seat belt solenoid, MFI relay	
-	2	-	-	
Ignition switch	IG <sub>2</sub>	3	10	Radiator fan motor relay, Air conditioning compressor lock controller, Blower motor relay, Air conditioning control unit, ABS relay, ECS control unit, Condenser fan motor relay
	ACC	4	10	Audio, Motor antenna control unit, Auto-cruise control unit, ETACS unit
		5	15	Remote controlled mirror, Cigarette lighter
Battery	6	10	Door lock power relay, Motor antenna control unit	
Ignition switch IG <sub>2</sub>	7	10	ELC-4A/T control module	
	8	-	-	
Ignition switch	ACC	9	15	Wiper relay, Wiper motor, Washer motor, Rear intermittent wiper relay, Keyless control unit
		10	15	Accessory socket, ETACS unit
	IG <sub>1</sub>	11	15	Combination meter, Combination gauge, ETACS unit, Speed sensor, Motor antenna control unit, Turn signal and hazard flasher unit, Auto-cruise control main switch, SRS diagnosis unit, Auto-cruise relay
		12	15	Ignition coil, Power transistor, MFI relay, Engine control module
Battery	13	15	Amplifier	
	14	10	Theft-alarm horn, Theft-alarm horn relay	
-	15	-	-	
Battery	16	30	Blower motor	
	17	15	Stop light, High-mounted stop light	
Ignition switch IG <sub>1</sub>	18	10	Back-up light, Light automatic shut-OFF unit, SRS diagnosis unit	
Battery	19	10	Engine control module, ELC-4 A/T control module, ETACS unit, Dome light, Foot light, Door light, Luggage compartment light, Combination meter, Air conditioning control unit, Auto-cruise control unit, Ignition key cylinder illumination light, Audio, Light automatic shut-OFF unit, ECS control unit	




16F0304

CENTRALIZED RELAY

Classification		Name	Classification		Name
Relay box in engine compartment	A-01X	Headlight relay	Air conditioning relay box in engine compartment	A-31X	Condenser fan motor relay (HI)
	A-02X	ABS power relay		A-32X	-
	A-03X	Fog light relay		A-33X	Magnetic clutch relay
	A-04X	Radiator fan motor relay (LO)		A-34X	Condenser fan motor relay (LO)
	A-05X	Taillight relay	Interior relay box	C-04X	Door lock power relay 1
	A-06X	Horn relay		C-05X	-
	A-07X	Radiator fan motor relay (HI)		C-06X	Defogger relay
	A-08X	-		C-07X	Power window relay
	A-09X	Starter relay		-	-
	A-10X	Generator relay		-	-
	A-11X	IOD or Storage connector		-	-


NOTE  
IOD: Ignition Off Draw

<Relay box in engine compartment>




16F0256

<Air conditioning relay box in engine compartment>






16F0002

<Interior relay box>



16F0431



## HARNESS CONNECTOR INSPECTION

### CONNECTOR CONTINUITY AND VOLTAGE TEST

When checking continuity and/or voltage at the waterproof connectors, follow the steps below to avoid poor connector contact and/or reduced waterproof performance of connectors.

- (1) When checking is performed with the circuit in the state of continuity, be sure to use the special tool (harness connector).  
Never insert a test bar from the harness side, because to do so will reduce the waterproof performance and result in corrosion.
- (2) When the connector is disconnected for checking the female pin (the harness for checking the contact pressure of connector pins should be used).  
Never force the insertion of a test bar, because to do so will cause poor contact.
- (3) When the male pin is to be checked, apply the test bar against the pin directly.

Care must be taken not to short-circuit the connector pins.

### TERMINAL ENGAGEMENT CHECK


When the terminal stopper of connector is out of order, engagement of male and female terminals becomes improper even when the connector itself is engaged perfectly and the terminal sometimes slips out to the rear side of connector. Ascertain, therefore, that each terminal does not come off the connector by pulling each harness wire.


### CONNECTOR TERMINAL ENGAGEMENT AND DISENGAGEMENT

Connectors which are loose shall be rectified by removing the female terminal from connector housing and raising its lance to establish a more secure engagement. Removal of connector terminal used for MFI and 4 A/T control circuit shall be done in the following manner.


### COMPUTER CONNECTOR

- (1) Insert screwdriver [1.4 mm (.06 in.) width] as shown in the figure, disengage front holder and remove it.






- (2) Insert harness of terminal to be rectified deep into connector from harness side and hold it there.




- (3) Insert tip of screwdriver [1.4 mm (.06 in.) width] into connector in a manner as shown in the figure, raise housing lance slightly with it and pull out harness.

**Caution**

Tool No. 753787-I supplied by AMP can be used instead of screwdriver.




- (4) Insert needle through a hole provided on terminal and raise contact point of male terminal.




**ROUND WATERPROOF CONNECTOR**

- (1) Remove waterproof cap by using a screwdriver.  
 (2) Insert tip of screwdriver [1.4 mm (.06 in.) or 2.0 mm (.08 in.) width] into connector in a manner as shown in the figure, raise housing lance slightly with it and pull out harness.




- (3) Insert screwdriver through a hole provided on terminal and raise contact point of male terminal.




**RECTANGULAR WATERPROOF CONNECTOR**

(1) Disengage front holder by using a screwdriver and remove it.




(2) Insert tip of screwdriver [\*0.8 mm (.03 in.) width] into connector in a manner as shown in the figure, push it lightly to raise housing lance and pull out harness.

\*If right size screwdriver is not available, convert a conventional driver to suit the size.




(3) Press contact point of male terminal down by holding a screwdriver [1.4 mm (.06 in.) width] in a manner as shown in the figure.



**INJECTOR CONNECTOR**

(1) Remove waterproof cap.



(2) Insert tip of screwdriver [1.4 mm (.06 in.) width] into connector in a manner as shown in the figure, press in terminal lance and pull out harness.

(3) Press contact point of male terminal down by holding a screwdriver [1.4 mm (.06 in.) width] in a manner as shown in the figure.

**Caution**


**Make sure that lance is in proper condition before terminal is inserted into connector.**

## HOW TO DIAGNOSE

The most important point in troubleshooting is to determine "Probable Causes". Once the probable causes are determined, parts to be checked can be limited to those associated with such probable causes. Therefore, unnecessary checks can be eliminated. The determination of the probable causes must be based on a theory and be supported by facts and must not be based on intuition only.

### TROUBLESHOOTING STEPS

If an attempt is made to solve a problem without going through correct steps for troubleshooting, the problem symptoms could become more complicated, resulting in failure to determine the causes correctly and making incorrect repairs. The four steps below should be followed in troubleshooting.



### INFORMATION FOR DIAGNOSIS


This manual contains the cable diagrams as well as the individual circuit drawings, operational explanations, and troubleshooting hints for each component required to facilitate the task of troubleshooting. The information is compiled in the following manner:

- (1) Cable diagrams show the connector positions, etc., on the actual vehicle as well as the harness path.
- (2) Circuit drawings show the configuration of the circuit with all switches in their normal positions.
- (3) Operational explanations include circuit drawings of voltage flow when the switch is operated and how the component operates in reaction.
- (4) Troubleshooting hints include numerous examples of problems which might occur, traced backward in a common-sense manner to the origin of the trouble.

Problems whose origins may not be found in this manner are pursued through the various system circuits.

#### NOTE


Components of MFI, ETACS, ECS, etc. with ECU do not include 3 and 4 above. For this information, refer to a manual which includes details of these components.



**INSPECTION**


**1. Visual and aural checks**

Check relay operation, blower motor rotation, light illumination, etc. visually or aurally. The flow of current is invisible but can be checked by the operation of the parts.



**2. Simple checks**

For example, if a headlight does not come on and a faulty fuse or poor grounding is suspected, replace the fuse with a new one or ground the light to the body by a jumper wire to determine which part is responsible for the problem.



**3. Checking with instruments**


Use an appropriate instrument in an adequate range and read the indication correctly. You must have sufficient knowledge and experience to handle instruments correctly.

**INSPECTION INSTRUMENTS**

In inspection, make use of the following instruments.


**1. Test lights**


A test light consists of a 12V bulb and lead wires. It is used to check voltages or shortcircuits.



**2. Self-power test light**


A self-power test light consists of a bulb, battery and lead wires connected in series. It is used to check continuity or grounding.






**3. Jumper wire**

A jumper wire is used to close an open circuit. Never use one to connect a power supply directly to a load.



**4. Voltmeter**

A voltmeter is used to measure the circuit voltage. Normally, the positive (red lead) probe is applied to the point of voltage measurement and the negative (black lead) probe to the body ground.



**5. Ohmmeter**

An ohmmeter is used to check continuity or measure resistance of a switch or coil. If the measuring range has been changed, the zero point must be adjusted before measurement.

**CHECKING SWITCHES**


In a circuit diagram, a switch is represented by a symbol and in the idle state.

**1. Normal open or normal close switch**

Switches are classified into those which make the circuit open and those which make the circuit closed when off.

Normal open (NO) type	
OFF	ON
<p>Current does not flow</p>	<p>Current flows</p>
Normal close (NC) type	
OFF	ON
<p>Current flows</p>	<p>Current does not flow</p>

16A0255




2. SWITCH CONNECTION

This figure illustrates a complex switch. The continuity between terminals at each position is as indicated in the table below.


Terminal No. / Position	1	2	3	4	5	6
OFF						
1st stage	○	—	—	—	○	○
2nd stage	○			○		○
3rd stage	○		○			○
4th stage	○	○				○

NOTE  
O-O denotes continuity between terminals.




CHECKING RELAYS

1. When current flows through the coil of a relay, its core is magnetized to attract the iron piece, closing (ON) the contact at the tip of the iron piece. When the coil current is turned off, the iron piece is made to return to its original position by a spring, opening the contact (OFF).




2. By using a relay, a heavy current can be turned on and off by a switch of small capacity. For example, in the circuit shown here, when the switch is turned on (closed), current flows to the coil of the relay. Then, its contact is turned on (closed) and the light comes on. The current flowing at this time to the switch is the relay coil current only and is very small.




3. The relays may be classified into the normal open type and the normal close type by their contact construction.

NOTE  
The deenergized state means that no current is flowing through the coil and the energized state means that current is flowing through the coil.




When a normal close type relay as illustrated here is checked, there should be continuity between terminals (1) and (2) and between terminals 3 and 4 when the relay is deenergized, and the continuity should be lost between terminals 1 and 2. A relay can be checked in this manner and it cannot be determined if a relay is okay or faulty by checking its state only when it is deenergized (or energized).



## CHECKING FUSES

A blade type fuse has test taps provided to allow checking of the fuse itself without removing it from the fuse block. The fuse is okay if the test light comes on when its one lead is connected to the test taps (one at a time) and the other lead is grounded. (Change the ignition switch position adequately so that the fuse circuit becomes live.)




## CAUTIONS IN EVENT OF BLOWN FUSE

When a fuse is blown, there are two probable causes as follows: One is that it is blown due to flow of current exceeding its rating.

The other is that it is blown due to repeated on/off current flowing through it. Which of the two causes is responsible can be easily determined by visual check as described below.




### (1) Fuse blown due to current exceeding rating

The illustration shows the state of a fuse blown due to this cause. In this case, do not replace the fuse with a new one hastily since a current heavy enough to blow the fuse has flowed through it. First, check the circuit for shorting and check for abnormal electric parts. Only after the correction of such shorting or parts, fuse of the same capacity should be used as a replacement. Never use a fuse of larger capacity than the one that has blown. If such a fuse is used, electric parts or wirings could be damaged before the fuse blows in the event an overcurrent occurs again.



### (2) Fuse blown due to repeated current on/off

The illustration shows the state of a fuse blown due to repeated current on/off. Normally, this type of problem occurs after fairly long period of use and hence is less frequent than the above type. In this case, you may simply replace with a new fuse of the same capacity.



## CHECKING CABLES AND WIRES

1. Check connections for looseness, rust and stains.
2. Check terminals and wires for corrosion by battery electrolyte, etc.
3. Check terminals and wires for open circuit or impending open circuit.
4. Check wire insulation and coating for damage, cracks and degrading.
5. Check conductive parts of terminals for contact with other metallic parts (vehicle body and other parts).
6. Check grounding parts to verify that there is complete continuity between attaching bolt(s) and vehicle body.
7. Check for incorrect wiring.
8. Check that wirings are so clamped as to prevent contact with sharp corners of the vehicle body, etc. or hot parts (exhaust manifold, pipe, etc.).
9. Check that wirings are clamped firmly to secure enough clearance from the fan pulley, fan belt and other rotating or moving parts.
10. Check that the wirings between the fixed parts such as the vehicle body and the vibrating parts such as the engine are made with adequate allowance for vibrations.

## HANDLING ON-VEHICLE BATTERY

When checking or servicing does not require power from the on-vehicle battery, be sure to disconnect the cable from the battery (-) terminal. This is to prevent problems that could be caused by a short circuit. Disconnect the (-) terminal first and reconnect it last.

### Caution

1. **Before connecting or disconnecting the negative cable, be sure to turn off the ignition switch and the lighting switch.**  
(If this is not done, there is the possibility of semiconductor parts being damaged.)
2. **After completion of the work steps [when the battery's negative (-) terminal is connected], warm up the engine and allow it to idle for approximately five minutes under the conditions described below, in order to stabilize the engine control conditions, and then check to be sure that the idling is satisfactory.**


**Engine coolant temperature: 85 – 95°C (185 – 203°F)**

**Lights, electric fans, accessories: OFF**

**Transaxle: neutral position**

**(A/T models: "N" or "P")**

**Steering wheel: neutral (center) position**






## GENERAL ELECTRICAL SYSTEM CHECKS

A circuit consists of the power supply, switch, relay, load, ground, etc. There are various methods to check a circuit including an overall check, voltage check, shortcircuit check and continuity check. Each of these methods is briefly described in the following.


### 1. VOLTAGE CHECK


- (1) Ground one lead wire of the test light. If a voltmeter is used instead of the test light, ground the grounding side lead wire.
- (2) Connect the other lead wire of the test light to the power side terminal of the switch connector. The test light should come on or the voltmeter should indicate a voltage.
- (3) Then, connect the test light or voltmeter to the motor connector. The test light should not come on, or the voltmeter should indicate no voltage. When the switch is turned on in this state, the test light should come on, or the voltmeter should indicate a voltage, with motor starting to run.
- (4) The circuit illustrated here is normal but if there is any problem such as the motor failing to run, check voltages beginning at the connector nearest to the motor until the faulty part is identified.



2. SHORT CIRCUIT CHECK

A blown fuse indicates that a circuit is shorted. The circuit responsible can be determined by the following procedures.





### 3. CONTINUITY CHECK

- (1) When the switch is in the OFF position, the self power test light should come on or the ohmmeter should read 0 ohm only when the terminals 1 and 2 are interconnected.
- (2) When the switch is in the ON position, the self power test light should come on or the ohmmeter should read 0 ohm only when the terminals 3 and 4 are interconnected.

---


# CONFIGURATION DIAGRAMS

## CONTENTS

Dash Panel .....	48	How to Read Configuration Diagram .....	39
Engine and Transaxle <DOHC-A/T> .....	46	Instrument Panel and Floor Console .....	50
Engine and Transaxle <DOHC-M/T> .....	44	Interior .....	52
Engine and Transaxle <SOHC> .....	42	Luggage Compartment .....	54
Engine Compartment .....	40	Overall Configuration Diagram .....	38



OVERALL CONFIGURATION DIAGRAM



36F0019


- NOTE  
(1) This illustration shows only the major wiring harnesses.  
(2) \* indicates also equipped at the right side

# HOW TO READ CONFIGURATION DIAGRAM

The wiring harness diagrams clearly show the connector locations and harness routings at each site on actual vehicles.

Denotes connector No.  
 The same connector No. is used throughout the circuit diagrams to facilitate connector location searches.  
 The first alphabetical symbol indicates the location site of the connector and a number that follows in the unique number.  
 Numbers are assigned to parts in clockwise order on the diagram.  
 In case connectors of the same shape (same number of poles) are located close to each other, connector colors are shown to aid in identification.  
 Example: A-12

Number specific to connector (serial number)  
 Connector location site symbol  
 A: Engine compartment  
 B: Engine and transaxle  
 C: Dash panel  
 D: Instrument panel and floor console  
 E: Interior  
 F: Luggage compartment



Denotes a section covered by a corrugated tube.



Denotes ground point.  
 Same ground number is used throughout circuit diagrams to facilitate search of ground point. Refer to **GROUNDING LOCATION** for details of ground points.

# ENGINE COMPARTMENT

Connector symbol

**A**

<Turbo>





- A-01X Headlight relay
- A-02X ABS power relay
- A-03X Foglight relay
- A-04X Radiator fan motor relay (LO)
- A-05X Taillight relay
- A-06X Horn relay
- A-07X Radiator fan motor relay (HI)
- A-08X –
- A-09X Starter relay
- A-10X Generator relay
- A-11X IOD or Storage connector
- A-12 ABS front speed sensor (RH)
- A-13 ECS front shock absorber (RH)
- A-14 Washer fluid level sensor
- A-15 Front wiper motor
- A-16 Engine speed detection connector <DOHC>
- A-17 Fuel pump check connector
- A-18 Ignition timing adjustment connector
- A-19 Front washer motor

Refer to  
CENTRALIZED  
JUNCTION

- A-20 Evaporative emission purge solenoid
- A-21 EGR solenoid
- <Turbo, Non Turbo (California)>
- A-22 EGR temperature sensor
- <Turbo, Non Turbo (California)>
- A-23 –
- A-24 Brake fluid level sensor
- A-25 ECS front shock absorber (LH)
- A-26 } Theft-alarm horn
- A-27 }
- A-28 Auto-cruise vacuum pump
- A-29 ABS front speed sensor (LH)
- A-30 4WS fluid level sensor <Turbo>

ENGINE HOOD



- A-41 Headlight (LO, LH)
- A-42 –
- A-43 Fog light (LH)
- A-44 –
- A-45 } Condenser fan motor
- A-46 } Condenser fan motor
- A-47 } Horn
- A-50 } Horn
- A-51 Fuel pump resistor <Turbo>
- A-52 –
- A-53 –
- A-54 Pulse generator <A/T>
- A-55 Radiator fan motor
- A-56 Engine coolant level sensor
- A-57 –
- A-58 Fog light (RH)
- A-59 –
- A-60 –
- A-61 Headlight (LO, RH)
- A-62 Front combination light (RH)
- A-63 SRS front impact sensor (RH)
- A-64 } ABS hydraulic unit
- A-65 } ABS hydraulic unit
- A-66 Hood switch
- A-67 Front wiring harness and control wiring harness combination
- A-68 Diode (for ABS circuit)
- A-69 Resistor <Turbo>
- A-70 Turbocharger waste gate solenoid <Turbo>
- A-71 Fuel pressure solenoid <Turbo>
- A-72 Control wiring harness and solenoid valve harness combination
- A-73 Inspection light
- A-74 Daytime running light control unit
- A-75 Upper beam relay
- A-76 Headlight (HI, LH)
- A-77 Headlight (HI, RH)
- A-78 No connection <Turbo>

- A-31X Condenser fan motor relay (HI)
  - A-32X –
  - A-33X Magnetic clutch relay
  - A-34X Condenser fan motor relay (LO)
  - A-35 Dual pressure switch
  - A-36 } Air conditioning relay box
  - A-37 } Air conditioning relay box
  - A-38 SRS front impact sensor (LH)
  - A-39 Front combination light (LH)
  - A-40 Inspection light switch
- } Refer to  
CENTRALIZED  
JUNCTION

Remarks


- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **4**), refer to P.8-4.
- (3) "–" means that the connector with code-number is not used.

## ENGINE AND TRANSAXLE &lt;SOHC&gt;

Connector symbol

**B**


Front View



B-01 Engine coolant temperature gauge unit  
 B-02 Engine coolant temperature sensor  
 B-03 –  
 B-04 Crankshaft position sensor and camshaft position sensor  
 B-05 Throttle position sensor  
 B-06 –  
 B-07 Control wiring harness and injector wiring harness combination  
 B-08 –  
 B-09 –  
 B-10 –  
 B-11 Injector No. 5  
 B-12 Injector No. 3

B-13 Injector No. 1  
 B-14 Ignition coil  
 B-15 –  
 B-16 Left bank heated oxygen sensor (front) <California>  
 B-17 } Generator  
 B-18 }  
 B-19 Right bank heated oxygen sensor (front) <California>  
 B-20 Magnetic clutch  
 B-21 Power transistor  
 B-22 –  
 B-23 } Starter motor  
 B-24 }

Rear View



- B-25 Back-up light switch <M/T>
- B-26 Park/Neutral position switch <A/T>
- B-27 ELC-4 A/T control solenoid valve <A/T>
- B-28 —
- B-29 Volume air flow sensor (with intake air temperature sensor and atmospheric sensor)
- B-30 Control wiring harness and battery cable combination
- B-31 Injector No. 2
- B-32 Injector No. 4
- B-33 Injector No. 6
- B-34 Speed sensor

- B-35 Idle air control motor (stepper motor)
- B-36 Oil pressure gauge unit
- B-37 Oil pressure switch
- B-38 Power steering pressure switch
- B-39 Condenser assembly
- B-40 } —
- B-41 } —
- B-42 Kickdown servo switch
- B-43 A/T temperature sensor
- B-44 Right bank heated oxygen sensor (rear) <California>
- B-45 Left bank heated oxygen sensor (rear) <California>

Remarks


- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **3**), refer to P.8-4.
- (3) "—" means that the connector with code-number is not used.

ENGINE AND TRANSAXLE <DOHC-M/T>

Connector symbol

**B**


Front View



- B-01 Engine coolant temperature gauge unit
- B-02 Engine coolant temperature sensor
- B-03 –
- B-04 –
- B-05 Throttle position sensor
- B-06 Control wiring harness and oil pressure wiring harness combination
- B-07 Control wiring harness and injector wiring harness combination
- B-08 Knock sensor
- B-09 Variable induction servo motor
- B-10 } (with intake control valve position sensor) <Non-Turbo>

- B-11 Injector No. 5
- B-12 Injector No. 3
- B-13 Injector No. 1
- B-14 Ignition coil
- B-15 Capacitor
- B-16 Left bank heated oxygen sensor (front) <Turbo, Non Turbo – California>
- B-17 } Generator
- B-18 } Generator
- B-19 Right bank heated oxygen sensor (front)
- B-20 Magnetic clutch
- B-21 } Power transistor
- B-22 } Power transistor

Rear View




- B-23 } Starter motor
- B-24 } Starter motor
- B-25 } Back-up light switch
- B-26 } Back-up light switch
- B-27 } –
- B-28 } Fuel pump relay <Turbo>
- B-29 } Volume air flow sensor (with intake air temperature sensor and atmospheric sensor)
- B-30 } Control wiring harness and battery cable combination
- B-31 } Injector No. 2
- B-32 } Injector No. 4
- B-33 } Injector No. 6
- B-34 } Speed sensor
- B-35 } Idle air control motor (stepper motor)
- B-36 } Oil pressure gauge unit
- B-37 } Oil pressure switch
- B-38 } Power steering pressure switch

- B-39 –
- B-40 Camshaft position sensor
- B-41 Crankshaft position sensor
- B-42 –
- B-43 –
- B-44 Right bank heated oxygen sensor (rear) <California>
- B-45 Left bank heated oxygen sensor (rear) <California>


Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **3**), refer to P.8-4.
- (3) “–” means that the connector with code-number is not used.

ENGINE AND TRANSAXLE <DOHC-A/T>



Front View




36F0075

- B-01 Engine coolant temperature gauge unit
- B-02 Engine coolant temperature sensor
- B-03 –
- B-04 –
- B-05 Throttle position sensor
- B-06 Control wiring harness and oil pressure wiring harness combination
- B-07 Control wiring harness and injector wiring harness combination
- B-08 Knock sensor
- B-09 } Variable induction servo motor
- B-10 } (with intake control valve position sensor)

- B-11 Injector No. 5
- B-12 Injector No. 3
- B-13 Injector No. 1
- B-14 Ignition coil
- B-15 Capacitor
- B-16 Left bank heated oxygen sensor (front) <California>
- B-17 } Generator
- B-18 } Generator
- B-19 Right bank heated oxygen sensor (front)
- B-20 Magnetic clutch
- B-21 } Power transistor
- B-22 } Power transistor

Rear View



36F0072

- B-23 } Starter motor
- B-24 }
- B-25
- B-26 Park/Neutral position switch
- B-27 ELC-4 A/T control solenoid valve
- B-28 –
- B-29 Volume air flow sensor (with intake air temperature sensor and atmospheric sensor)
- B-30 Control wiring harness and battery cable combination
- B-31 Injector No. 2
- B-32 Injector No. 4
- B-33 Injector No. 6
- B-34 Speed sensor
- B-35 Idle air control motor (stepper motor)
- B-36 Oil pressure gauge unit
- B-37 Oil pressure switch
- B-38 Power steering pressure switch

- B-39 –
- B-40 Camshaft position sensor
- B-41 Crankshaft position sensor
- B-42 Kickdown servo switch
- B-43 A/T fluid temperature sensor
- B-44 Right bank heated oxygen sensor (rear)  
<California>
- B-45 Left bank heated oxygen sensor (rear)  
<California>

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **3**), refer to P.8-4.
- (3) “–” means that the connector with code-number is not used.


# DASH PANEL

Connector symbol

**C**


## JUNCTION BLOCK

<Front side>



36F0079


<Rear side>




36F0003

- C-01 } Body wiring harness (LH)
- C-02 } and front wiring
- C-03 } harness combination
- C-04X Door lock power relay 1
- C-05X –
- C-06X Defogger relay
- C-07X Power window relay
- C-08 } Diode (for seat belt warning circuit)
- C-09 }
- C-10 } Column switch
- C-11 }
- C-12 Diode (for theft-alarm circuit)
- C-13 –
- C-14 Control wiring harness and instrument panel wiring harness combination
- C-15 Body wiring harness (LH) and instrument panel wiring harness combination
- C-16 } Air conditioning control panel
- C-17 }
- C-18 Air conditioning switch
- C-19 Blower switch
- C-20 Heater control panel illumination light
- C-21 Blend air damper control motor

Refer to  
CENTRALIZED  
JUNCTION



- C-22 Mode selection damper control motor
- C-23 Power transistor (for full-auto air conditioning circuit)
- C-24 Blower resistor
- C-25 Air conditioning control unit
- C-26 } <Manual air conditioning>
- C-27 Air-inlet sensor <Full-auto air conditioning>
- C-28 Air selection damper control motor
- C-29 } Body wiring harness (LH) and control
- C-30 } wiring harness combination
- C-31 Body wiring harness (LH) and front wiring harness combination
- C-32 } Body wiring harness (RH) and front wiring
- C-33 } harness combination
- C-34 Body wiring harness (LH) and body wiring harness (RH) combination
- C-35 Foot light (RH)
- C-36 Body wiring harness (RH) and control wiring harness combination
- C-37 Auto-cruise control unit
- C-38 Blower motor
- C-39 Blower motor relay (HI)
- C-40 Air conditioning compressor lock controller
- C-41 Air-inlet sensor <Manual air conditioning>
- C-42 Air-thermo sensor
- C-43 Engine coolant temperature sensor
- C-44 Engine control relay
- C-45 Over drive and power/economy switch
- C-46 } ELC-4 A/T control module
- C-47 }





- C-48 -
- C-49 } Air conditioning control unit
- C-50 } <Full-auto air conditioning>
- C-51 }
- C-52 } Engine control module
- C-53 }
- C-54 }
- C-55 } Left bank heated oxygen sensor (front)
- C-56 } <Non Turbo except California>
- C-57 } Theft-alarm starter relay
- C-58 } Clock spring
- C-59 } Key reminder switch
- C-60 } Ignition switch
- C-61 } Steering wheel angle speed sensor
- C-62 } Stop light switch
- C-63 } Clutch pedal position switch (for auto-cruise control circuit)
- C-64 } Clutch pedal position switch (for theft-alarm circuit)
- C-65 }
- C-66 } ETACS unit
- C-67 } Foot light (LH)
- C-68 } Front wiring harness and junction block combination
- C-69 }
- C-70 }
- C-71 } Adapter wiring harness and junction block combination

- C-72 } Theft-alarm horn relay
- C-73 } Blower motor relay
- C-74 } Roof wiring harness and junction block combination
- C-75 } -
- C-76 } Body wiring harness (LH) and
- C-77 } junction block combination
- C-78 }
- C-79 } Data link connector
- C-80 }
- C-81 } Body wiring harness (LH) and
- C-82 } junction block combination
- C-83 }
- C-84 } Auto-cruise relay
- C-85 } -
- C-86 } Passenger's air bag module
- C-87 } No connection <Turbo>
- C-88 } Control wiring harness and front wiring harness combination
- C-89 } Body wiring harness (LH) and body wiring harness (RH) combination
- C-90 } Engine control module <Turbo, Non Turbo – California>

Remarks


- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) The details concerning the ground point (example: **5**), refer to P.8-4.

# INSTRUMENT PANEL AND FLOOR CONSOLE




- D-01 Fog light switch
- D-02 Front speaker (LH)
- D-03 } Combination meter
- D-04 }
- D-05 }
- D-06 Defogger switch and ECS switch
- D-07 –
- D-08 Hazard switch
- D-09 Combination gauge
- D-10 Diode (for 4WS fluid level warning light circuit)
- D-11 Glove box illumination light
- D-12 Photo sensor

- D-13 Front speaker (RH)
- D-14 Glove box illumination light switch
- D-15 Instrument panel wiring harness and control wiring harness combination
- D-16 Instrument panel wiring harness and body wiring harness (RH) combination
- D-17 Ashtray illumination light
- D-18 } Cigarette lighter
- D-19 }
- D-20 Cigarette lighter illumination light
- D-21 Power seat switch
- D-22 Body wiring harness (LH) and console wiring harness combination



- D-23 } SRS diagnosis unit
- D-24 } SRS diagnosis unit
- D-25 –
- D-26 SRS diagnosis unit
- D-27 ABS G sensor
- D-28 Parking brake switch
- D-29 –
- D-30 } Accessory socket
- D-31 } Accessory socket
- D-32 Auto-cruise main switch
- D-33 Seatbelt warning buzzer
- D-34 } Radio
- D-35 } Radio
- D-36 } Radio
- D-37 Rear wiper and washer switch
- D-38 Active exhaust switch
- D-39 Remote-control mirror switch
- D-40 Rheostat
- D-41 } Instrument panel wiring harness and
- D-42 } body wiring harness (LH) combination
- D-43 } Instrument panel wiring harness and adapter
- D-44 } wiring harness combination
- D-45 Instrument panel wiring harness and front
- D-46 wiring harness combination
- D-47 Radio



36F0082


Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) “–” means that the connector with code-number is not used.

INTERIOR


Connector symbol

**E**



- E-01 Body wiring harness (RH) and door wiring harness (RH) combination
- E-02 Vanity mirror illumination light (LH)
- E-03 Door mirror (RH)
- E-04 Door speaker (RH)
- E-05 Dome light
- E-06 Power window sub switch
- E-07 Vanity mirror illumination light (RH)
- E-08 Power window motor (RH)
- E-09 Door light (RH)
- E-10 Door key cylinder unlock switch (RH)

- E-11 Door lock actuator (RH)
- E-12 ABS control unit
- E-13 ABS resistor <AWD>
- E-14 Front seat belt solenoid (RH)
- E-15 Door switch (RH)
- E-16 ABS rear speed sensor (RH)
- E-17 Light automatic shut-OFF unit
- E-18 Rear intermittent wiper relay
- E-19 ABS rear speed sensor (LH)
- E-20 Front seat belt solenoid (LH)
- E-21 Door switch (LH)



36F0077



- E-22 Door lock actuator (LH)
- E-23 Door key cylinder unlock switch (LH)
- E-24 Front seat belt switch (RH)
- E-25 Door light (LH)
- E-26 Front seat belt switch (LH)
- E-27 Power seat assembly
- E-28 ECS G sensor
- E-29 Door speaker
- E-30 Turn signal and hazard flasher unit
- E-31 Diode (for MFI circuit)
- E-32 Body wiring harness (LH) and door wiring harness (LH) combination
- E-33 Door mirror (LH)
- E-34 Power window main switch

- E-35 Power window motor (LH)
- E-36 –
- E-37 Keyless control unit
- E-38 Door lock power relay 2 (for keyless control system)
- E-39 Amplifier

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **7**), refer to P.8-4.
- (3) "–" means that the connector with code-number is not used.

## LUGGAGE COMPARTMENT



36F0063

F-01	Interior temperature sensor	F-23	Liftgate cylinder lock switch
F-02	Defogger (+)	F-24	Liftgate switch
F-03	Rear wiper motor	F-25	Back-up light (LH)
F-04	High-mounted stop light	F-26	Active exhaust control unit
F-05	Defogger (-)	F-27	-
F-06	Rear speaker (RH)	F-28	-
F-07	ECS rear shock absorber (RH)	F-29	Active exhaust actuator assembly
F-08	Luggage compartment light	F-30	Rear combination light (LH)
F-09	ABS resistor <FWD>	F-31	Motor antenna control unit
F-10	Rear combination light (RH)	F-32	ECS rear shock absorber (LH)
F-11	Back-up light (RH)	F-33	Rear speaker (LH)
F-12	} ECS control unit	F-34	} Body wiring harness (LH) and liftgate wiring harness combination
F-13			
F-14	Body wiring harness (RH) and fuel tank wiring harness combination	F-36	-
F-15	Rear washer motor	F-39	-
F-16	Fuel tank	F-40	CD changer
F-17	License plate light (RH)		
F-18	Body wiring harness (RH) and rear bumper wiring harness combination		
F-19	} Body wiring harness (LH) and body wiring harness (RH) combination		
F-20			
F-21	License plate light (LH)		
F-22	Luggage compartment light switch		

## Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: [10]), refer to P.8-4.
- (3) "-" means that the connector with code-number is not used.

# CIRCUIT DIAGRAMS

## CONTENTS

Active Exhaust System Circuit .....	193	How to Read Wiring Diagrams .....	62
Anti-lock Braking System (ABS) Circuit .....	180	Ignition Circuit .....	249
Auto-cruise Control Circuit .....	199	MFI Circuit .....	68
Back-up Light Circuit .....	321	Manual Air Conditioning Circuit .....	144
Buzzer Circuit .....	130	Meter and Gauges Circuit .....	275
Central Door Locking Circuit .....	135	Power Distribution Circuit .....	63
Charging Circuit .....	221	Power Seat Circuit .....	214
Cigarette Lighter Circuit .....	364	Power Window Circuit .....	132
Cooling Circuit .....	116	Radio and Tape Player Circuit .....	366
Defogger Circuit .....	407	Rear Window Defogger Circuit .....	407
Dome Light, Foot Light and Ignition Key Cylinder Illumination Light Circuit .....	318	Rear Wiper and Washer Circuit .....	353
Door Light and Luggage Compartment Light Circuit .....	319	Remote Controlled Mirror Circuit .....	179
ELC-4 A/T Circuit .....	121	Starting Circuit .....	237
Electronic Control Suspension (ECS) Circuit .....	188	Stop Light Circuit .....	331
Fog Light Circuit .....	307	Supplemental Restraint System (SRS) Circuit .....	196
Full Auto Air Conditioning Circuit .....	161	Taillight, Parking/Side Marker Light and License Plate Light Circuit .....	311
Glove Box Light, Vanity Mirror Light and Inspection Light Circuit .....	320	Tension-reducer Type Seat Belt Circuit .....	216
Headlight Circuit .....	289	Theft-alarm System Circuit .....	412
Heater Circuit .....	142	Turn-signal Light and Hazard Light Circuit .....	322
Horn Circuit .....	360	Turn-signal Light, Hazard Light and Stop Light Circuit .....	328
How to Read Circuit Diagrams .....	56	Warning Light Circuit .....	277
		Windshield Wiper and Washer Circuit .....	348

# HOW TO READ CIRCUIT DIAGRAMS

The circuit of each system from the fuse (or fusible link) to ground is shown. The power supply is shown at the top and the ground at the bottom to facilitate understanding of how the current flows.

Indicates power takeout.


Indicates connector No. The same No. as in the wiring harness diagram is used.

If the same connector is shown at two or more locations, the connector is indicated by  with connector symbol shown inside.

An "X" at the end of a connector No. indicates that the connector is connected to a centralized junction that is shown in the section "Centralized Junction".

Indicates the operating conditions of the engine coolant switch, etc.

Indicates that the diagram is continued at  on the next page.




Indicates shield wire.

Indicates terminal No.

A broken line indicates that these connectors are the same intermediate connectors.


Indicates that the diagram is continued from  on the previous page.



In case two or more connectors are connected to the same device, markings indicating the same connector are connected by a broken line.

Indicates input/output to/from control unit (current flow direction).

Input    Output    Input/output



Indicates current flow downward or upward as controlled by the control unit.

Indicates harness junction where wire diameter or color changes.


Indicates J/B (Junction Block).













Indicates vehicle body ground point. (Same No. as that of ground point in GROUNDING LOCATION)

Indicates continuity of harnesses on the opposite page of a double page circuit diagram.

Indicates that the terminal is a spare one for the device (sensor in this case) is not provided.

CONNECTOR / GROUNDING INDICATIONS



	No.	Item	Symbol	Contents
Connector marking	①	Male 		Double connector contour lines indicate male connector terminals and single contour lines indicates female terminals as illustrated here.
	-	Female 		
Connector symbol marking	②	Device 		The symbol indicates the connector as viewed from the illustrated direction. At the connection with a device, the connector symbol on the device side is shown, and for an intermediate connector, the male connector symbol is shown. However, the data link connector is indicated in a different way. For details, refer to MUT-II Operating Instruction.
Connector connection marking	③	Direct connection type 		A connection between a device and connector on the harness side is either by direct insertion in the device (direct connection type) or by connection with a harness connector furnished on the device side (harness connection type). The two types are indicated as illustrated.
	④	Harness connection type 		
	⑤	Intermediate connector 		
Grounding markings	⑥	Body ground 		Grounding is either by body ground, device ground or control unit interior ground. These are indicated as illustrated.
	⑦	Device ground 		
	⑧	Ground in control unit 		

**SYMBOLS**

Devices appearing in circuit diagrams are indicated by the following symbols.

Battery 	Body ground 	Single bulb 	Resistor 	Diode 	Capacitor 
Fuse 	Equipment ground 	Dual bulb 	Variable resistor 	Zener diode 	Crossing of wires without connection 
Fusible link 	ECU interior ground 	Speaker 	Coil 	Transistor with 	Crossing of wires with connection 
Connector Female side  Male side 	Motor 	Horn 	Pulse generator 	Buzzer 	Chime 
Thyristor 	Piezoelectric device 	Thermistor 	Light emitting diode 	Photo diode 	Photo transistor 

**WIRE COLOR CODES**


Wire colors are identified by the following color codes.

Code	Wire color	Code	Wire color
B	Black	P	Pink
BR	Brown	R	Red
G	Green	SB	Sky blue
GR	Gray	V	Violet
L	Blue	W	White
LG	Light green	Y	Yellow
O	Orange	–	

**NOTE**

If a cable has two colors, the first of the two color code characters indicates the basic color (color of the cable coating) and the second indicates the marking color.

Example: <F> 1.25G – B



# HOW TO READ WIRING DIAGRAMS


Indicates the connector No.  
The same No. as the wiring diagram  
and circuit diagram is used.

Indicates the  
harness entry  
location number.

Junction points indicated by a square (⊞) indicate circuits with differences in specifications.

Indicates the harness name and harness entry location.  
(In this case, this indicates that the harness is the roof harness, and that it is entered in the harness entry location number of 5.)  
Example: <5-2>

Classification number  
Harness entry location number



Indicates the name of the harness to connect to and the number of the relevant connector.


Wires with the same destination are indicated with a single thick line.

Indicates size of wire (mm<sup>2</sup>)


Indicates wire colour code.

Indicates the connector terminal No.  
Identical symbols are entered to indicate which harness corresponds to which connector terminal.

The connector symbol shows the harness-side connector as seen from front-on (from the direction shown in the illustration).




**POWER DISTRIBUTION CIRCUIT**




NOTE  
 \*1: VEHICLES WITH GENERATOR RATED OUTPUT 90A  
 \*2: VEHICLES WITH GENERATOR RATED OUTPUT 110A






POWER DISTRIBUTION CIRCUIT (CONTINUED)




Remark  
 The above circuit diagram shows the current flow at the ignition key position "ACC", "ON" and "ST" combined. Be sure trace the appropriate circuit depending on the ignition key position.

COMPONENT LOCATION


Fusible link




Dedicated fuse ① to ⑦




Dedicated fuse ⑧ ⑨




Dedicated fuse ⑩




Headlight relay, Taillight relay





Defogger relay










MFI CIRCUIT <SOHC> (FEDERAL AND CANADA) (CONTINUED)






MFI CIRCUIT <SOHC> (FEDERAL AND CANADA) (CONTINUED)













MFI CIRCUIT <SOHC> (CALIFORNIA) (CONTINUED)





MFI CIRCUIT <SOHC> (CALIFORNIA) (CONTINUED)

















COMPONENT LOCATION











<SOHC>




Name	Symbol	Name	Symbol
Air conditioning relay	O	Idle air control motor (stepper motor)	L
Air conditioning switch	G	Ignition coil (ignition power transistor)	M
Camshaft position sensor and crankshaft position sensor	D	Ignition timing adjusting terminal	Q
Check engine/malfunction indicator lamp	P	Injector	K
Diagnostic output terminal and diagnostic test mode control terminal	R	Multiport fuel injection (MFI) relay	N
EGR solenoid <California>	V	Park/Neutral position switch <A/T>	I
EGR temperature sensor <California>	T	Power steering pressure switch	H
Engine control module	S	Throttle position sensor (with built-in closed throttle position switch)	C
Engine coolant temperature sensor	B	Variable air intake control servo (DC motor) (with built-in air intake control valve position sensor)	J
Evaporative emission purge solenoid	U	Vehicle speed sensor (reed switch)	F
Heated oxygen sensor	E	Volume air flow sensor (with built-in intake air temperature sensor and barometric pressure sensor)	A

NOTE  
The "Name" column is arranged in alphabetical order.


















MFI CIRCUIT <DOHC NON TURBO> (FEDERAL AND CANADA) (CONTINUED)





MFI CIRCUIT <DOHC NON TURBO> (FEDERAL AND CANADA) (CONTINUED)

















**COMPONENT LOCATION**











**<DOHC NON TURBO> (FEDERAL AND CANADA)**



Name	Symbol	Name	Symbol
Air conditioning relay	O	Ignition coil (ignition power transistor)	M
Air conditioning switch	G	Ignition timing adjusting terminal	Q
Camshaft position sensor	V	Injector	K
Check engine/malfunction indicator lamp	P	Knock sensor	T
Crankshaft position sensor	D	Multiport fuel injection (MFI) relay	N
Diagnostic output terminal and diagnostic test mode control terminal	R	Park/Neutral position switch <A/T>	I
Engine control module	S	Power steering pressure switch	H
Engine coolant temperature sensor	B	Throttle position sensor (with built-in closed throttle position switch)	C
Evaporative emission purge solenoid	U	Variable induction control motor (DC motor) (with built-in induction control valve position sensor)	J
Heated oxygen sensor	E	Vehicle speed sensor	F
Idle air control motor (stepper motor)	L	Volume air flow sensor (with built-in intake air temperature sensor and barometric pressure sensor)	A

NOTE  
The "Name" column is in alphabetical order












# MFI CIRCUIT


## <DOHC NON TURBO> (CALIFORNIA&







MFI CIRCUIT <DOHC NON TURBO> (CALIFORNIA) (CONTINUED)






MFI CIRCUIT <DOHC NON TURBO> (CALIFORNIA) (CONTINUED)







# MFI CIRCUIT


## <TURBO> (FEDERAL AND CANADA)







MFI CIRCUIT <TURBO> (FEDERAL AND CANADA) (CONTINUED)






MFI CIRCUIT <TURBO> (FEDERAL AND CANADA) (CONTINUED)














MFI CIRCUIT <TURBO> (CALIFORNIA) (CONTINUED)





MFI CIRCUIT <TURBO> (CALIFORNIA) (CONTINUED)

















COMPONENT LOCATION











<TURBO, DOHC NON TURBO (CALIFORNIA)>











Name	Symbol	Name	Symbol
Air conditioning relay	O	Ignition coil (ignition power transistor)	M
Air conditioning switch	G	Ignition timing adjusting terminal	Q
Camshaft position sensor	AA	Injector	K
Check engine/malfunction indicator lamp	P	Knock sensor	T
Crankshaft position sensor	D	Multiport fuel injection (MFI) relay	N
Diagnostic output terminal and diagnostic test mode control terminal	R	Park/Neutral position switch <A/T>	I
EGR solenoid	Z	Power steering pressure switch	H
EGR temperature sensor	Y	Resistor <Turbo>	W
Engine control module	S	Throttle position sensor (with built-in closed throttle position switch)	C
Engine coolant temperature sensor	B	Turbocharger waste gate solenoid <Turbo>	U
Evaporative emission purge solenoid	X	Variable induction control motor (DC motor) (with built-in induction control valve position sensor) <Non Turbo>	J
Fuel pressure solenoid <Turbo>	V	Vehicle speed sensor (reed switch)	F
Heated oxygen sensor	E	Volume air flow sensor (with built-in intake air temperature sensor and barometric pressure sensor)	A
Idle air control motor (stepper motor)	L	-	-

NOTE  
The "Name" column is in alphabetical order.
















# COOLING CIRCUIT







## <TURBO, NON TURBO (CALIFORNIA)>






COMPONENT LOCATION


Name	Symbol	Name	Symbol
Air conditioning compressor lock controller	D	Condenser fan motor relay (LO)	B
Air conditioning control unit	C	Radiator fan motor relay (HI)	A
Condenser fan motor relay (HI)	B	Radiator fan motor relay (LO)	A




ELC-4 A/T CIRCUIT (FEDERAL AND CANADA)




ELC-4 A/T CIRCUIT (FEDERAL AND CANADA) (CONTINUED)







ELC-4 A/T CIRCUIT (FEDERAL AND CANADA) (CONTINUED)




ELC-4 AT CIRCUIT (CALIFORNIA)





ELC-4 A/T CIRCUIT (CALIFORNIA) (CONTINUED)






ELC-4 A/T CIRCUIT (CALIFORNIA) (CONTINUED)




COMPONENT LOCATION


Name	Symbol	Name	Symbol
AA fluid temperature sensor	A	Engine control module	E
A/T solenoid valve assembly (within the valve body)	B	Kickdown servo switch	A
Auto-cruise control unit	F	Pulse generator	A
Data link connector	D	Throttle position sensor	C
ELC-4 AA control module	E	-	-




16F0502




19F0134




16F0063




TFA0280




16F004



16F0498




16F0292




16F0284

# BUZZER CIRCUIT




COMPONENT LOCATION


Name	Symbol	Name	Symbol
Buzzer	C	ETACS unit	A
Diode (seat belt warning)	B	—	




19F0134



16F0354




36F0021



19F0075


# POWER WINDOW CIRCUIT








COMPONENT LOCATION

Name	Symbol	Name	Symbol
Data link connector	C	Power window relay	B
ETACS unit	A	–	–




19F0134




# CENTRAL DOOR LOCKING CIRCUIT

(Vehicles without keyless entry system)



\*1: VEHICLES WITHOUT POWER WINDOW  
 \*2: VEHICLES WITH POWER WINDOW


**CENTRAL DOOR LOCKING CIRCUIT (Vehicles without keyless entry system)  
(CONTINUED)**







\*3: VEHICLES WITHOUT THEFT-ALARM SYSTEM  
\*4: VEHICLES WITH THEFT-ALARM SYSTEM

COMPONENT LOCATION

Name	Symbol	Name	Symbol
Data link connector	C	Door lock power relay 1	B
Door lock actuator	D	ETACS unit	A




19F0134




# CENTRAL DOOR LOCKING CIRCUIT


(Vehicles with keyless entry system)



\*1: VEHICLES WITHOUT POWER WINDOW  
 \*2: VEHICLES WITH POWER WINDOW





**CENTRAL DOOR LOCKING CIRCUIT (Vehicles with keyless entry system)  
(CONTINUED)**






\*3: VEHICLES WITHOUT THEFT-ALARM SYSTEM  
\*4: VEHICLES WITH THEFT-ALARM SYSTEM

COMPONENT LOCATION



Name	Symbol	Name	Symbol
Data link connector	C	Door lock power relay 2 (keyless entry system)	E
Door lock actuator	D	ETACS unit	A
Door lock power relay 1	B	Keyless entry control unit	E




19F0134



16F0268




HEATER CIRCUIT




COMPONENT LOCATION


Name	Symbol	Name	Symbol
Blower motor relay	A	Blower resistor	B
Blower motor relay (HI)	C	–	–




19F0134



16F0189




20F0039




16F0284


# MANUAL AIR CONDITIONING CIRCUIT


<SOHC>





MANUAL AIR CONDITIONING CIRCUIT <SOHC> (CONTINUED)










# MANUAL AIR CONDITIONING CIRCUIT

## <DOHC NON TURBO> (FEDERAL AND CANADA)





MANUAL AIR CONDITIONING CIRCUIT <DOHC NON TURBO>  
(FEDERAL AND CANADA) (CONTINUED)






MANUAL AIR CONDITIONING CIRCUIT <DOHC NON TURBO>  
(FEDERAL AND CANADA) (CONTINUED)






MANUAL AIR CONDITIONING CIRCUIT <DOHC NON TURBO> (FEDERAL AND CANADA)  
(CONTINUED)




# MANUAL AIR CONDITIONING CIRCUIT

<TURBO, DOHC NON TURBO (CALIFORNIA)>




MANUAL AIR CONDITIONING CIRCUIT <TURBO, DOHC NON TURBO (CALIFORNIA)> (CONTINUED)





MANUAL AIR CONDITIONING CIRCUIT <TURBO, DOHC NON TURBO (CALIFORNIA)>  
(CONTINUED)






MANUAL AIR CONDITIONING CIRCUIT <TURBO, DOHC NON TURBO (CALIFORNIA)>

(CONTINUED)

AIR CONDITIONING COMPRESSOR LOCK CONTROLLER


BLOWER SWITCH

TAIL LIGHT RELAY





# FULL AUTO 'AIR CONDITIONING CIRCUIT

<DOHC NON TURBO> (FEDERAL AND CANADA)



FULL AUTO AIR CONDITIONING CIRCUIT <DOHC NON TURBO>  
(FEDERAL AND CANADA) (CONTINUED)







FULL AUTO AIR CONDITIONING CIRCUIT  
<DOHC NON TURBO> (FEDERAL AND CANADA)  
(CONTINUED)


AIR CONDITIONING  
COMPRESSOR LOCK  
CONTROLLER


J/B  
(MULTI-PURPOSE)  
FUSE ③






FULL AUTO AIR CONDITIONING. CIRCUIT <DOHC NON TURBO> (FEDERAL AND CANADA) (CONTINUED)






FULL AUTO AIR CONDITIONING CIRCUIT <DOHC NON TURBO> (FEDERAL AND CANADA) (CONTINUED)





# FULL AUTO AIR CONDITIONING CIRCUIT

<TURBO, DOHC NON TURBO (CALIFORNIA)>




FULL AUTO AIR CONDITIONING CIRCUIT  
<TURBO, DOHC NON TURBO (CALIFORNIA)> (CONTINUED)







FULL AUTO AIR CONDITIONING CIRCUIT  
<TURBO, DOHC NON TURBO (CALIFORNIA)>  
(CONTINUED)






FULL AUTO AIR CONDITIONING CIRCUIT  
<TURBO, DOHC NON TURBO (CALIFORNIA)> (CONTINUED)




















FULL AUTO AIR CONDITIONING CIRCUIT  
 <TURBO, DOHC NON TURBO (CALIFORNIA)> (CONTINUED)




COMPONENT LOCATION

Name	Symbol	Name	Symbol
Air conditioning compressor lock controller	H	Dual pressure switch	B
Air conditioning control unit	D	ELC-4 AA control module	D
Air-inlet sensor	G	Engine control module	D
Air-thermo sensor	E	Engine coolant temperature sensor	I
Blower motor relay	K	Interior temperature sensor	L
Blower motor relay (HI)	H	Magnetic clutch relay	A
Condenser fan motor relay (HI)	A	Photo sensor	F
Condenser fan motor relay (LO)	A	Revolution sensor	C
Data link connector	J	Thermostat	C






# REMOTE CONTROLLED MIRROR CIRCUIT



# ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT


<FWD>



ABS CONTROL UNIT

E-12


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	





# ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT

<AWD>





ABS CONTROL UNIT

E-12

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	


ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT <AWD> (CONTINUED)






COMPONENT LOCATION


Name	Symbol	Name	Symbol
ABS control unit	F	G sensor	D
ABS power relay	C	Hydraulic unit	A
Data link connector	E	Motor relay	A
Diode	B	Rear speed sensor	H
Front speed sensor	G	Valve relay	A




16F0502




19F0134




16F000 8




16F0024











16F0503




16F005



16F0498




# ELECTRONIC CONTROL SUSPENSION (ECS) CIRCUIT



NOTE  
 \*1:NON-TURBO (VEHICLES FOR FEDERAL AND CANADA)  
 \*2:TURBO, NON-TURBO (VEHICLES FOR CALIFORNIA)




ELECTRONIC CONTROL SUSPENSION (ECS) CIRCUIT (CONTINUED)




COMPONENT LOCATION


Name	Symbol	Name	Symbol
Data link connector	E	G sensor	D
ECS control unit	F	Steering wheel angle speed sensor	B
Engine control module	I c	Throttle position sensor	A




16F0502




19F0134




16F0043




12F0072





16F0292




16F0498




12F0096



ACTIVE EXHAUST SYSTEM CIRCUIT




ACTIVE EXHAUST SYSTEM CIRCUIT (CONTINUED)





COMPONENT LOCATION


Name	Symbol	Name	Symbol
Active exhaust control unit	C	Engine control module	B
Actuator assembly	D	Power window relay	A




19F0134




16F0494



16F0292




16F0281




05F0005









## COMPONENT LOCATION




Name	Symbol
Data link connector	C
Front impact sensor	A
SRS diagnosis unit	B




19F0134


# AUTO-CRUISE CONTROL CIRCUIT

<M/T> SOHC, DOHC NON TURBO (FEDERAL AND CANADA)



AUTO-CRUISE CONTROL CIRCUIT <M/T> SOHC, DOHC NON TURBO (FEDERAL AND CANADA) (CONTINUED)






AUTO-CRUISE CONTROL UNIT C-37

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

1	2	3	4	5	M	6	7	8	9	10	
11	12	13	14	15	16	17	18	19	20	21	22


# AUTO-CRUISE CONTROL CIRCUIT

<M/T> TURBO, DOHC NON TURBO (CALIFORNIA)





AUTO-CRUISE CONTROL CIRCUIT  
<M/T> TURBO, DOHC  
NON TURBO (CALIFORNIA)  
(CONTINUED)




AUTO-CRUISE CONTROL UNIT C-37

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20


# AUTO-CRUISE CONTROL CIRCUIT

<A/T> SOHC, DOHC NON TURBO (FEDERAL AND CANADA)



AUTO-CRUISE CONTROL CIRCUIT <A/T> SOHC, DOHC NON TURBO (FEDERAL AND CANADA) (CONTINUED)






AUTO-CRUISE CONTROL UNIT

c-37

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20


AUTO-CRUISE CONTROL CIRCUIT <A/T> SOHC, DOHC NON TURBO (FEDERAL AND CANADA) (CONTINUED)





AUTO-CRUISE CONTROL CIRCUIT <A/T> DOHC (CALIFORNIA) (CONTINUED)






AUTO-CRUISE CONTROL UNIT

c-37

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

AUTO-CRUISE CONTROL CIRCUIT <A/T> DOHC (CALIFORNIA) (CONTINUED)




COMPONENT LOCATION


Name	Symbol	Name	Symbol
Auto-cruise control unit	B	Engine control module	C
Auto-cruise relay	C	Throttle position sensor	A
Data link connector	D	–	–




16F0502




19F0134




16F0043



16F0284




16F0396




16F0498


POWER SEAT CIRCUIT



NOTE  
 \*1: VEHICLES WITHOUT THEFT ALARM SYSTEM  
 \*2: VEHICLES WITH THEFT ALARM SYSTEM




# TENSION-REDUCER TYPE SEAT BELT CIRCUIT




\*1: VEHICLES WITHOUT THEFT-ALARM SYSTEM  
 \*2: VEHICLES WITH THEFT-ALARM SYSTEM

COMPONENT LOCATION


Name	Symbol	Name	Symbol
Data link connectr	B	Front seat belt solenoid	C
ETACS unit	A	-	-




19F0134




16F035



16F0498



16F0268



16F0465

Note: \* indicates that this component is used on the right side as well.



# ENGINE ELECTRICAL

## CONTENTS


<b>CHARGING SYSTEM</b> .....	<b>220</b>	Camshaft Position Sensor Inspection .....	Refer to GROUP14 (ON-VEHICLE INSPECTION OF MFI COMPONENTS)
<b>GENERATOR</b> .....	<b>230</b>	Crankshaft Position Sensor Inspection .....	Refer to GROUP14 (ON-VEHICLE INSPECTION OF MFI COMPONENTS)
<b>SERVICE ADJUSTMENT PROCEDURES</b> .....	<b>224</b>	Ignition Timing Adjustment . . . .	Refer to GROUP 9
Charging System Inspection .....	224	<b>SPECIFICATIONS</b> .....	<b>247</b>
<b>SPECIFICATIONS</b> .....	<b>220</b>	General Specifications .....	247
General Specifications .....	220	Service Specifications .....	248
Service Specifications .....	220	<b>TROUBLESHOOTING</b> .....	<b>249</b>
<b>TROUBLESHOOTING</b> .....	<b>221</b>	<b>STARTING SYSTEM</b> .....	<b>236</b>
<b>IGNITION SYSTEM</b> .....	<b>247</b>	<b>SPECIFICATIONS</b> .....	<b>236</b>
<b>DISTRIBUTOR</b> .....	<b>262</b>	General Specifications .....	236
<b>IGNITION SYSTEM &lt;DOHC&gt;</b> .....	<b>256</b>	Service Specifications .....	236
<b>IGNITION SYSTEM &lt;SOHC&gt;</b> .....	<b>253</b>	<b>STARTER MOTOR</b> .....	<b>240</b>
<b>SERVICE ADJUSTMENT PROCEDURES</b> .....	<b>252</b>	<b>TROUBLESHOOTING</b> .....	<b>237</b>
High Tension Cable Spark Test <SOHC> .....	252		
Spark Plug Cable Test .....	252		
Spark Plug Test .....	252		



TROUBLESHOOTING

CIRCUIT DIAGRAM

<SOHC>



NOTE  
 \*1: VEHICLES WITH GENERATOR RATED OUTPUT 90A  
 \*2: VEHICLES WITH GENERATOR RATED OUTPUT 110A



**OPERATION**

**When engine is stopped**

When the ignition switch is switched to the “ON” position, electricity flows from the “L” terminal of the generator to the field coil, and at the same time the charging warning light illuminates.

**When engine is being started/has started**

When the engine is started, charging voltage is applied to the “L” terminal of the generator, with the result that the charging warning light is extinguished.

In addition, because battery voltage is applied to the “S” terminal of the generator, this battery voltage is monitored at the IC voltage regulator, thus switching ON and OFF the current to the field coil and thereby controlling the output voltage of the generator.

Power is supplied to each load from the “B” terminal of the generator.

**NOTE**


The generator relay functions as a back-up for the flow of electricity to the field coil if there is a disconnection or damaged wiring of the charging warning light.

**TROUBLESHOOTING HINTS**


1. Charging warning light does not go on when the ignition switch is turned to “ON”, before the engine starts.
  - Check the bulb.
2. Charging warning light fails to go off once the engine starts.
  - Check the IC voltage regulator (located within the generator).
3. Discharged or overcharged battery.
  - Check the IC voltage regulator (located within the generator).
4. The charging warning light illuminates dimly.
  - Check the diode (within the combination meter) for a short-circuit.

**COMPONENT LOCATION**

Name	Symbol
Generator relay	A



16F0257



16F0261

## SERVICE ADJUSTMENT PROCEDURES

### CHARGING SYSTEM INSPECTION

#### GENERATOR OUTPUT LINE VOLTAGE DROP TEST

The test is performed to check whether the wiring between terminal B of the generator and the positive terminal of the battery (including the fusible link) is good or not.


- (1) Before the test is performed, be sure to check the following items.
  - Mounted condition of generator
  - Generator drive belt tension (Refer to GROUP 0 – Maintenance Service.)
  - Fusible link condition
  - Whether strange sound is heard from generator during engine rotation
- (2) Set the ignition switch to "OFF".
- (3) Disconnect the negative cable of the battery.

- (4) Disconnect the output line of the generator from terminal B of the generator.
- (5) Connect a 0-100A test DC ammeter between terminal B and the disconnected output line in series. (Connect the positive lead wire of the ammeter to terminal B and connect the negative lead wire of the ammeter to the disconnected output line.)

#### NOTE:

- Use of a clamp type ammeter is recommended, as it allows measurements to be made without disconnecting the output line of the generator. Why is a clamp type ammeter recommended? When you check a vehicle in which a low output current exists due to incompletely connected terminal B of the generator, you may be unable to detect the cause of the trouble, because direct loosening of terminal B and connection of an ammeter to terminal B completes the connection.

- (6) Connect a digital voltmeter between terminal B of the generator and the positive terminal of the battery. (Connect the positive lead wire of the voltmeter to terminal B and connect the negative lead wire of the voltmeter to the positive terminal of the battery)



(7) Set an engine tachometer.

NOTE:

- For engine tachometer setting procedure, refer to GROUP 9 – Service Adjustment Procedures.

(8) Connect the negative cable of the battery.

(9) Leave the engine hood opened.

(10) Start the engine.

(11) Adjust the generator load by turning the headlamps or smaller lamps ON or OFF so that the ammeter will indicate a somewhat higher value than 30A with the engine running at 2500 rpm.

(12) Slowly lower the engine speed to adjust the engine speed so that the ammeter will indicate 30A. Take the reading of the voltmeter at the time.

**Limit value: 0.3V max.  
(0.4V max. in case of ammeter reading of 40A)**

(13) If the voltmeter reading is in excess of the limit value, a defective generator output line is suspected. Check the wiring (including fusible link) between terminal B of the generator and the positive terminal of the battery.

If there are problems like loosely tightened terminals, discolored harness due to overheating, etc., make repairs and perform the test thereafter.

(14) After the test has been completed, let the engine run at idle. Turn off the lamps and other devices and place the ignition switch at "OFF".

(15) Disconnect the negative cable of the battery.

(16) Remove the test ammeter, voltmeter and engine tachometer.

(17) Connect the output line of the generator to terminal B of the generator.

(18) Reconnect the negative cable of the battery.

### OUTPUT CURRENT TEST

The test is performed to check whether the generator has the capability to output expected current.

(1) Before the output current test is performed, be sure to check the following items.

- Mounted condition of generator
- Battery condition (Refer to GROUP 8 – Battery.)

NOTE:

The battery used for output current test is preferably in a slightly discharged condition. With a fully charged battery, shortage of load could result in incorrect test.

- Generator drive belt tension (Refer to GROUP 0 – Maintenance Service.)
- Fusible link condition
- Whether strange sound is heard from generator during engine rotation

(2) Place the ignition switch at "OFF".

(3) Disconnect the negative cable of the battery.

(4) Disconnect the output line of the generator from terminal B of the generator.

(5) Connect a 0-100A test DC ammeter between terminal B and the disconnected output line in series. (Connect the positive lead wire of the ammeter to terminal B and connect the negative lead wire of the ammeter to the disconnected output line.)


CAUTION:

- Since a large current flows, firmly secure all the connections with bolts and nuts. Be sure to avoid the method of fastening connections with clips.

NOTE:

- Use of a clamp type ammeter is recommended, as it allows measurements to be made without disconnecting the output line of the generator.

(6) Connect a 0-20V test voltmeter between terminal B and ground. (Connect the positive lead wire of the voltmeter to terminal B and connect the negative lead wire of the voltmeter to a good ground.)



6EN0893

(7) Set an engine tachometer.

NOTE:

- For engine tachometer setting procedure, refer to GROUP 9 – Service Adjustment Procedures.

(8) Connect the negative cable of the battery.

(9) Leave the engine hood opened.

(10) Check that the voltmeter reading is equal to the battery voltage.

NOTE:

- When the voltmeter reading is OV, an open-circuited wiring or fusible link between terminal B of the generator and the positive terminal of the battery is suspected.

(11) Set the lighting switch to “ON” to light the headlamps, and then start the engine.

(12) Set the headlamps to high beam and set the heater blower switch to HI. Immediately increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

**Limit value: 70% of nominal output current**

NOTES:

- For the nominal output current value, refer to General Specifications.
- Since the charge current abruptly decreases after starting the engine, perform the above-mentioned operations quickly when reading the maximum current value.
- The output current value varies with the size of electric load and the temperature of the generator itself.

When the electric load of the vehicle under test is small, the specified output current may be unavailable even if there is nothing wrong with the generator. In such a case, leave the headlamps lighted to discharge the battery, or get another car and use the lamps and other devices of the car to increase the electric load, and then re-perform the test. If the temperature of the generator itself or the ambient temperature is too high, the specified output current may be unavailable, either. In such a case, let the generator cool down before retesting.

(13) Check to ensure that the ammeter reading is in excess of the limit value. If the reading is lower than the limit value, and there is nothing wrong with the output line of the generator, remove the generator from the engine and check it.

(14) After the output current test has been completed, reduce the engine speed to the idling speed.

(15) Place the ignition switch at “OFF”.

(16) Disconnect the negative cable of the battery.

(17) Remove the test ammeter, voltmeter and engine tachometer.

(18) Connect the output line of the generator to terminal B of the generator.

(19) Reconnect the negative cable of the battery.

### REGULATOR VOLTAGE TEST

The test is performed to check whether the voltage regulator is properly controlling the output voltage of the generator.

(1) Before the regulator voltage test is performed, be sure to check the following items.

- Mounted condition of generator
- Check to ensure that the battery mounted in the vehicle is in fully charged condition. (Refer to GROUP 8 – Battery.)
- Generator drive belt tension (Refer to GROUP 0 – Maintenance Service.)
- Fusible link condition
- Whether strange sound is heard from generator during engine rotation


(2) Place the ignition switch at “OFF”.

(3) Disconnect the negative cable of the battery.

(4) Connect a digital voltmeter between terminal S of the generator and ground. (Connect the positive lead wire of the voltmeter to terminal S. Connect the negative lead wire of the voltmeter to a good ground or the battery negative terminal.)

(5) Disconnect the output line of the generator from terminal B of the generator.

(6) Connect a 0-100A test DC ammeter between terminal B and the disconnected output line in series. (Connect the positive lead wire of the ammeter to terminal B and connect the negative lead wire of the ammeter to the disconnected output line.)



6EN0883

- (7) Set an engine tachometer.

NOTE:

- For engine tachometer setting procedure, refer to GROUP 9 – Service Adjustment Procedures.

- (8) Connect the negative cable of the battery.

- (9) Place the ignition switch at “ON” and check that the voltmeter reading is equal to the battery voltage.

NOTE:

When the voltmeter reading is OV, an open-circuited wiring or fusible link between terminal S of the generator and the positive terminal of the battery is suspected.

- (10) Check to ensure that all of the lamps and accessories are “OFF”.

- (11) Start the engine.

- (12) Increase the engine speed to 2,500 rpm.

- (13) When the output current of the generator has decreased to less than 10A, read the value indicated by the voltmeter.

- (14) If the reading is equal to a value in the regulator voltage table, it follows that the voltage regulator is performing well. If the reading is out of the standard limits, the voltage regulator or generator is out of order.

**Regulator Voltage Table**

Detecting Terminal	Voltage Regulator Ambient Temperature	Standard Limits (V)
	°C (°F)	
Terminal “S”	-20 (-4)	14.2 – 15.4
	20 (68)	13.9 – 14.9
	60 (140)	13.4 – 14.6
	80 (176)	13.1 – 14.5

- (15) After the test has been completed, let the engine run at idle.

- (16) Place the ignition switch at “OFF”.

- (17) Disconnect the negative cable of the battery.


- (18) Remove the test ammeter, voltmeter and engine tachometer.

- (19) Connect the output line of the generator to terminal B of the generator.

- (20) Reconnect the negative cable of the battery.

**GENERATOR <DOHC>****REMOVAL AND INSTALLATION****Pre-removal and Post-installation Operation**


- Removal and Installation of Right Bank Warm Up Three-Way Catalytic Converter  
(Refer to GROUP 11 – Exhaust Pipe, Main Muffler and Catalytic Converter)



16F0346

**Removal steps**


1. Air hose E <Turbo>
2. Air pipe C <Turbo>
3. Clamp nuts of suction hose  
<Vehicles with air conditioning>
4. Drive belt  
(Refer to GROUP 9 – Service Adjustment Procedures.)
5. Generator connector
6. Heated oxygen sensor connector
7. Generator and generator bracket assembly
8. Generator bracket
9. Generator

**SERVICE POINT OF REMOVAL****3. REMOVAL OF CLAMP NUT**

On vehicles with air conditioning, remove the clamp nut, raise the suction hose and suspend it from the engine hood using a cord.

**GENERATOR <SOHC>****REMOVAL AND INSTALLATION****Post-installation Operation**


- Adjustment of Accelerator Cable  
(Refer to GROUP 14 – Engine Control.)



16F0286


**Removal steps**

1. Drive belt  
(Refer to GROUP 9 – Service Adjustment Procedures.)
2. Accelerator cable
3. Connection of brake booster vacuum hose
4. EGR valve <Vehicles for California>
5. Connection of generator connector
6. Generator

**'SERVICE POINT OF REMOVAL****6. REMOVAL OF GENERATOR**

Take out the generator from behind the surge tank at the center of the vehicle.


## DISASSEMBLY AND REASSEMBLY



## Disassembly steps

- ☒ 1. Generator pulley
- + 2. Rotor assembly
- 3. Rear bearing
- 4. Bearing retainer
- 5. Front bearing
- 6. Front bracket
- ↔ 7. Stator
- 8. Insulator
- 9. Plate
- ↔ 10. Regulator and brush holder
- 11. Slinger
- 12. Rectifier
- 13. Brush
- 14. Brush spring
- 15. Rear bracket

7EL0104



7EL0008


### SERVICE POINTS OF DISASSEMBLY

#### SEPARATING THE STATOR AND FRONT BRACKET


Insert plain screwdriver between front bracket and stator core and pry downward.

**Caution**


Do not insert screwdriver too deep, as there is danger of damage to stator coil.




1EL109




7F1119



6EL115



6EL116



3EL010

## 1. REMOVAL OF GENERATOR PULLEY

- (1) Clamp the rotor in a vise with soft jaws.
- (2) After removing the nut, remove the pulley and front bracket from the rotor.

## 7. REMOVAL OF STATOR / 10. REGULATOR AND BRUSH HOLDER

- (1) When removing the stator, unsolder stator lead wire from the main diode of the rectifier.
- (2) When removing the brush holder, unsolder it from the rectifier.

### Caution

- (1) When soldering or unsoldering, use care to make sure that heat of soldering iron is not transmitted to diodes for a long period. Finish soldering or unsoldering in as short a time as possible.
- (2) Use care that no undue force is exerted to leads of diodes.

## INSPECTION

### ROTOR


- (1) Check field coil for continuity. Check to ensure that there is continuity between slip rings.  
If resistance is extremely small, it means that there is a short. If there is no continuity or if there is short circuit, replace rotor assembly.

**Resistance value : Approx 3 – 5  $\Omega$**


- (2) Check field coil for grounding. Check to ensure that there is no continuity between slip ring and core. If there is continuity, replace rotor assembly.

### STATOR

- (1) Make continuity test on stator coil. Check to ensure that there is continuity between coil leads.  
If there is no continuity, replace stator assembly.




- (2) Check coil for grounding. Check to ensure that there is no continuity between coil and core. If there is continuity, replace stator assembly.



## RECTIFIERS


### (1) Positive Rectifier Test

Check for continuity between positive rectifier and stator coil lead connection terminal with a circuit tester. If there is continuity in both directions, diode is shorted. Replace rectifier assembly.




### (2) Negative Rectifier Test

Check for continuity between negative rectifier and stator coil lead connection terminal. If there is continuity in both directions, diode is shorted, and rectifier assembly must be replaced.




### (3) Diode Trio Test

Check three diodes for continuity by connecting an ammeter to both ends of each diode. If there is no continuity in both directions, diode is faulty and heatsink assembly must be replaced.




## BRUSH REPLACEMENT


- (1) Replace brush by the following procedures if it has been worn to limit line.




(2) Unsolder pigtail and remove old brush and spring.



(3) Install brush spring and new brush in brush holder.  
(4) Insert the brush to where there is a space 2 to 3 mm (.079 to .118 in.) between the limit line and the end of the brush holder.




(5) Solder pigtail to brush holder as shown in the illustration.



**SERVICE POINT OF REASSEMBLY**  
**2. INSTALLATION OF ROTOR ASSEMBLY**

Before rotor is attached to rear bracket, insert wire through small hole made in rear bracket to lift brush. After rotor has



# STARTING SYSTEM SPECIFICATIONS

## GENERAL SPECIFICATIONS

Items	Specification
Starter motor	
Type	Reduction drive (with planetary gear)
Rated output kW/V	1.2/12
No. of pinion teeth	8

## SERVICE SPECIFICATIONS

Items	Specifications
Standard value	
Starter motor	
Free running characteristics	
Terminal voltage V	11
Current A	90 or less
Speed rpm	3,000 or more
Pinion gap mm (in.)	0.5 – 2.0 (.020 – .079)
Commutator runout mm (in.)	0.05 (.002)
Commutator diameter mm (in.)	29.4 (1.158)
Undercut depth mm (in.)	0.5 (.020)
Limit	
Commutator runout mm (in.)	0.1 (.004)
Commutator diameter mm (in.)	28.4 (1.118)


# TROUBLESHOOTING

## CIRCUIT DIAGRAM


<VEHICLES WITHOUT THEFT-ALARM SYSTEM>

(M/T)

(A/T)



<VEHICLES WITH THEFT-ALARM SYSTEM>



**OPERATION**

- For models equipped with the M/T, the clutch

when the clutch pedal is depressed; when the ignition switch is then switched to the “ST” position, electricity flows to the starter relay and the starter motor, the contact (magnetic switch) of the starter is switched ON and the starter motor is activated.






**NOTE**

If the ignition switch is switched to the “ST” position without the clutch pedal being depressed, electricity flows to the starter relay (coil), the clutch pedal position switch (contacts) and to ground, with the result that the contacts of the starter relay are switched OFF, and, because the power to the starter motor is thereby interrupted, the starter motor is not activated.

- For models equipped with the A/T, when the ignition switch is switched to the “ST” position while the selector lever is at the “P” or “N” position, the contact (magnetic switch) of the starter is switched ON and the starter motor is activated.

**TROUBLESHOOTING HINTS**

- Check the starter (coil).
- Check for poor contact at the battery terminals and starter.
- Check Park/Neutral position switch.
- Check clutch pedal position switch.
- Check starter relay.
- Check theft-alarm starter relay.
- Check key reminder switch.



## STARTER MOTOR

### REMOVAL AND INSTALLATION

Refer to GROUP 21 – Transaxle.

### INSPECTION

#### PINION GAP ADJUSTMENT

- (1) Disconnect field coil wire from M-terminal of magnetic switch.
- (2) Connect a 12V battery between S-terminal and M-terminal.
- (3) Set switch to "ON", and pinion will move out.

#### Caution

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

- (4) Check pinion to stopper clearance (pinion gap) with a feeler gauge.

**Pinion gap: 0.5 – 2.0 mm (.020 – .079 in.)**

- (5) If pinion gap is out of specification, adjust by adding or removing gaskets between magnetic switch and front bracket.

#### PULL-IN TEST OF MAGNETIC SWITCH

- (1) Disconnect field coil wire from M-terminal of magnetic switch.
- (2) Connect a 12V battery between S-terminal and M-terminal.

#### Caution

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

- (3) If pinion moves out, then pull-in coil is good. If it doesn't, replace magnetic switch.


#### HOLD-IN TEST OF MAGNETIC SWITCH

- (1) Disconnect field coil wire from M-terminal of magnetic switch.
- (2) Connect a 12V battery between S-terminal and body.

#### Caution

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**


- (3) If pinion remains out, everything is in order. If pinion moves in, hold-in circuit is open. Replace magnetic switch.



**FREE RUNNING TEST**

- (1) Place starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows:
- (2) Connect a test ammeter (100-ampere scale) and carbon pile rheostat in series with battery positive post and starter motor terminal.
- (3) Connect a voltmeter (15-volt scale) across starter motor.
- (4) Rotate carbon pile to full-resistance position.
- (5) Connect battery cable from battery negative post to starter motor body.
- (6) Adjust rheostat until the battery voltage shown by the voltmeter is 1 IV.
- (7) Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

**Current: max. 90 Amps**




**RETURN TEST OF MAGNETIC SWITCH**

- (1) Disconnect field coil wire from M-terminal of magnetic switch.
- (2) Connect a 12V battery between M-terminal and body.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**


- (3) Pull pinion out and release. If pinion quickly returns to its original position, everything is in order. If it doesn't, replace magnetic switch.



**STARTER RELAY**


- (1) Remove the starter relay from the relay box.
- (2) Connect battery to terminal 2 and check continuity between terminals with terminal 4 grounded.

Power is supplied	3-4 terminals	No continuity
	3-5 terminals	Continuity
Power is not supplied	3-4 terminals	Continuity
	3-5 terminals	No continuity
	1-2 terminals	Continuity




**STARTER MOTOR****DISASSEMBLY AND REASSEMBLY**

&lt;EXCEPT CALIFORNIA VERSION&gt;


**Disassembly steps**

1. Screw
2. Magnetic switch
3. Screw
4. Screw
5. Rear bracket
6. Brush holder
7. Brush
8. Rear bearing
9. Armature
10. Yoke assembly
11. Ball
12. Packing A
13. Packing B
14. Plate
15. Planetary gear
16. Lever
17. Snap ring
18. Stop ring
19. Overrunning clutch
20. Internal gear
21. Planetary gear holder
22. Front bracket



**DISASSEMBLY AND REASSEMBLY**

<CALIFORNIA VERSION>



**Disassembly steps**

7EN0628



- |                      |                           |
|----------------------|---------------------------|
| 1. Screw             | 12. Packing A             |
| 2. Magnetic switch   | 13. Packing B             |
| 3. Screw             | 14. Plate                 |
| 4. Starter cover     | 15. Planetary gear        |
| 5. Rear bracket      | 16. Lever                 |
| 6. Brush holder      | ◄◄ ◄◄ 17. Snap ring       |
| 7. Brush             | ◄◄ ◄◄ 18. Stop ring       |
| ◄◄ 9. Armature       | 19. Overrunning clutch    |
| ◄◄ 10. Yoke assembly | 20. Internal gear         |
| ◄◄ 11. Ball          | 21. Planetary gear holder |
|                      | 22. Front bracket         |

**SERVICE POINTS OF DISASSEMBLY**

**9. REMOVAL OF ARMATURE / 11. BALL**

**Caution**

When removing the armature, take care not to lose the ball (which is used as a bearing ) in the armature end.

**17. REMOVAL OF SNAP RING / 18. STOP RING**

(1) Press the stop ring, by using an appropriate socket wrench, to the snap ring side.

(2) After removing the snap ring (by using snap-ring pliers), remove the stop ring and the overrunning clutch.

**CLEANING STARTER MOTOR PARTS**

1. Do not immerse parts in cleaning solvent. Immersing the yoke and field coil assembly and/or armature will damage insulation. Wipe these parts with a cloth only.
2. Do not immerse drive unit in cleaning solvent. Overrunning clutch is pre-lubricated at the factory and solvent will wash lubrication from clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

**INSPECTION****CHECKING THE COMMUTATOR**

(1) Place the armature on a pair of V-blocks, and check the deflection by using a dial gauge.



**Standard value: 0.05 mm (.0020 in.)**


**Limit: 0.1 mm (.0040 in.)**

(2) Check the outer diameter of the commutator.


**Standard value: 29.4 mm (1.158 in.)**

**Limit: 28.4 mm (1.118 in.)**






- (3) Check the depth of the undercut between segments.  
**Standard value: 0.5 mm (.020 in.)**



### BRUSH HOLDER

Check for continuity between brush holder plate and brush holder.  
 The normal condition is non-continuity.




### OVERRUNNING CLUTCH

1. While holding clutch housing, rotate the pinion. Drive pinion should rotate smoothly in one direction, but should not rotate in opposite direction. If clutch does not function properly, replace overrunning clutch assembly.
2. Inspect pinion for wear or burrs. If pinion is worn or burred, replace overrunning clutch assembly. If pinion is damaged, also inspect ring gear for wear or burrs.


### FRONT AND REAR BRACKET BUSHING

Inspect bushing for wear or burrs. If bushing is worn or burred, replace front bracket assembly or rear bracket assembly.



### REPLACEMENT OF BRUSHES AND SPRINGS

1. Brushes that are worn beyond wear limit line, or oil-soaked, should be replaced.
2. When replacing field coil brushes, crush worn brush with pliers, taking care not to damage pigtail.




3. Sand pigtail end with sandpaper to ensure good soldering.
4. Insert pigtail into hole provided in new brush and solder it. Make sure that pigtail and excess solder do not come out onto brush surface.
5. When replacing ground brush, slide the brush from brush holder by prying retaining spring back.

## TESTING ARMATURE


### TESTING ARMATURE FOR SHORT-CIRCUIT

1. Place armature in a growler.
2. Hold a thin steel blade parallel and just above while rotating armature slowly in growler. A shorted armature will cause blade to vibrate and be attracted to the core. Replace shorted armature.




### TESTING ARMATURE FOR GROUNDING

Check the insulation between the armature coil cores and the commutator segments. They are normal if there is no continuity.



### CHECKING FOR ARMATURE COIL WIRING DAMAGE / DISCONNECTION


Check for continuity between segments. The condition is normal if there is continuity.



## SERVICE POINTS OF REASSEMBLY

### 18. INSTALLATION OF STOP RING / 17. SNAP RING

Using a suitable pulling tool, pull overrunning clutch stop ring over snap ring.



**IGNITION SYSTEM****SPECIFICATIONS****GENERAL SPECIFICATIONS****DISTRIBUTOR**

Items	SOHC
Type	Contact pointless type
Identification No.	T5T42671
Part No.	MD1 47874
Advance mechanism	Controlled by engine control unit
Firing order	1 - 2 - 3 4 5 - 6

**IGNITION COIL**

Items	SOHC	DOHC
Type	Mold single-coil	Mold 3-coil
Identification No.	F-504	F-536
Part No.	MD160532	MD1 52648

**SPARK PLUG**

Items	SOHC	DOHC
NGK	BPR5ES-11	PFR6J-11
NIPPON DENSO	WI 6EPR11	PK20PR-P11


## SERVICE SPECIFICATIONS

Items	Specifications
Standard value Ignition coil Primary coil resistance at 20°C (68°F) $\Omega$ <SOHC> <DOHC> Secondary coil resistance at 20°C (68°F) $k\Omega$ <SOHC> <DOHC> Spark plug gap   mm (in.)	0.72 – 0.88 0.67 – 0.81 10.29 – 13.92 11.31 – 15.30 1.0 – 1.1 (.39 – .43)


# TROUBLESHOOTING

## CIRCUIT DIAGRAM

<SOHC>



<DOHC>



**OPERATION****<SOHC>**




- Turn ignition switch to “ON” position, and battery voltage will be applied to primary winding of ignition coil.
- When crankshaft position sensor and camshaft position sensor signal is input to engine control module, ON-OFF control of power transistor is performed by engine control module.
- When power transistor is turned on, current flows from ignition coil (primary winding) to ground through power transistor.
- When power transistor is turned off, high voltage is generated in primary winding of ignition coil which induces even higher voltage in the secondary winding, causing a spark at the spark plug(s).

**<DOHC>**

- When crankshaft position sensor and camshaft position sensor signal is input to engine control module, engine control module makes ON-OFF control of power transistors one by one.
- When power transistor A is turned from ON to OFF, the spark plugs of No. 1 and No. 4 cylinders spark. Turning of power transistor B from ON to OFF will produce sparking in spark plugs of No. 2 and No. 5 cylinders. Furthermore, when power transistor C is turned from ON to OFF, sparking is produced in spark plugs of No. 5 and No. 6 cylinders.
- The rest of operation is the same as described for SOHC engine.

**TROUBLESHOOTING HINTS**

1. Engine cranks, but does not start.
  - (1) Spark is insufficient or does not occur at all (on spark plug).
    - Check ignition coil.
    - Check distributor. <SOHC Engine>
    - Check crankshaft position sensor and camshaft position sensor <DOHC Engine>
    - Check power transistor.
    - Check spark plugs.
    - Check spark plug cable.
  - (2) Spark is good.
    - Check ignition timing.
2. Engine idles roughly or stalls.
  - Check spark plugs.
  - Check ignition timing.
  - Check ignition coil.
  - Check spark plug cable.
3. Poor acceleration
  - Check ignition timing.
  - Check spark plug cable.
  - Check ignition coil.



## SERVICE ADJUSTMENT PROCEDURES

### SPARK PLUG CABLE TEST

- (1) Disconnect, one at a time, each of the spark plug cables while the engine is idling to check whether the engine's running performance changes or not.

#### Caution

**Wear rubber gloves while doing so.**

- (2) If the engine performance does not change, check the resistance of the spark plug cable, and check the spark plug itself.


### SPARK PLUG TEST

- (1) Remove the spark plug and connect to the spark plug cable.
- (2) Ground the spark plug outer electrode (body), and crank the engine.


Check to be sure that there is an electrical discharge between the electrodes at this time.

### HIGH TENSION CABLE SPARK TEST <SOHC>

- (1) Disconnect the high-tension cable from the distributor cap.
- (2) Hold the high tension cable about 6 – 8 mm (.24 – .31 in.) away from engine proper (grounding portion such as cylinder block) and crank engine to verify that sparks are produced.

**IGNITION SYSTEM****REMOVAL AND INSTALLATION <SOHC>****Removal steps**

1. High tension cable
- ◆◆ 2. Spark plug cable
3. Spark plug
- ◆◆ 4. Distributor
5. O-ring
6. Ignition coil
7. Ignition power transistor




**INSPECTION**

**SPARK PLUG**

Check plug gap using a plug gap gauge and adjust if it is not as specified.


**Standard value: 1.0 – 1.1 mm (.040 – .043 in.)**



**SPARK PLUG CABLE**

- (1) Check cap and coating for cracks.
- (2) Measure resistance.

**Limit: Max. 22 kΩ**



**IGNITION POWER TRANSISTOR**

**NOTE**

An analog-type circuit tester should be used.


- (1) Connect the negative (–) terminal of the 1.5V power supply to terminal ② of the ignition power transistor; then check whether there is continuity between terminal ③ and terminal ② when terminal ① and the positive (+) terminal are connected and disconnected.

**NOTE**

Connect the (–) probe of the circuit tester to terminal ③.

Terminal 1 and (+) terminal	Terminal 3 and terminal 2
Connected	Continuity
Unconnected	No continuity

- (2) Replace the ignition power transistor if there is a malfunction.



**IGNITION COIL**

**Primary Coil Resistance**



Measure the resistance of the positive (+) terminal and negative (–) terminal of the ignition coil.

**Standard value: 0.72 – 0.88 Ω**

**Secondary Coil Resistance**

Measure the resistance of the positive (+) terminal and the high-voltage terminal.

**Standard value: 10.29 – 13.92 kΩ**



## SERVICE POINTS OF INSTALLATION

### 4. INSTALLATION OF DISTRIBUTOR

- (1) Turn the crankshaft so that the No. 1 cylinder is at compression top dead center.

#### Caution

**Be careful not to turn it to the No. 4 cylinder compression top dead center by mistake.**


- (2) Align the distributor housing and gear mating marks.

- (3) Install the distributor to the engine while aligning the distributor's installation flange with the center of the distributor installation stud.

### 2. INSTALLATION OF SPARK PLUG CABLE



Improper arrangement of spark plug cables will induce voltage between the cables, causing miss firing and developing a surge at acceleration in high-speed operation. Therefore, be careful to arrange the spark plug cables properly by the following procedure.

1. Install the spark plug cable clamps as shown in the illustration.
2. The numerals on the support and clamp indicate the spark plug cable No.
3. Pay attention to the following items when the spark plug cables are installed.
  - (1) Install the cables securely to avoid possible contact with metal parts.
  - (2) Install the cables neatly, ensuring they are not too tight, loose, twisted or kinked.




## REMOVAL AND INSTALLATION &lt;DOHC&gt;


3.0 Nm  
2.2 ft.lbs.



3 25 Nm  
18 ft.lbs.




13 Nm  
10 ft.lbs.



10 Nm  
8 ft.lbs.


22 Nm  
16 ft.lbs.

**Removal steps**

- 1. Center cover
- 2. Spark plug cable
- 3. Spark plug
- 4. Ignition coil
- 5. Ignition power transistor
- 6. Clamp

**Pre-removal and Post-installation Operation**


- Removal and Installation of Intake Manifold Plenum  
(Refer to GROUP 11 -Intake Manifold.)



- 7. Camshaft position sensor
- 8. Crankshaft position sensor

**Pre-removal and Post-installation Operation**

- Removal and Installation of Timing Belt Cover (Refer to GROUP 9 -Timing Belt.)



**INSPECTION**

**SPARK PLUG**


Check the plug gap and replace if the limit is exceeded.

**Standard value: 1.0 – 1.1 mm (.039 – .043 in.)**

**Limit: 1.3 mm (.051 in.)**

**Caution**


1. Do not attempt to adjust the gap of the platinum plug.
2. Cleaning of the platinum plug may damage the platinum tip. Therefore, if carbon deposits must be removed, use a plug cleaner and complete cleaning within 20 seconds for protection of the electrode. Do not use wire brushes.



**SPARK PLUG CABLE**

- (1) Check cap and coating for cracks.
- (2) Measure resistance.

**Limit: Max. 22 kΩ**



**IGNITION POWER TRANSISTOR**

**NOTE**

An analog-type circuit tester should be used.

**No. 1 – No. 4 coil side**


- (1) Connect the negative (–) terminal of the 1.5V power supply to terminal ④ of the ignition power transistor; then check whether there is continuity between terminal ⑬ and terminal ④ when terminal ③ and the positive (+) terminal are connected and disconnected.

**NOTE**

Connect the (–) probe of the circuit tester to terminal ⑬.

Terminal 3 and (+) terminal	Terminal 13 and terminal 4
Connected	Continuity
Unconnected	No continuity

- (2) Replace the ignition power transistor if there is a malfunction.



**No. 2 – No. 5 coil side**


- (1) Connect the negative (–) terminal of the 1.5V power supply to terminal ④ of the ignition power transistor; then check whether there is continuity between terminal ⑫ and terminal ④ when terminal ② and the positive (+) terminal are connected and disconnected.

**NOTE**

Connect the (–) probe of the circuit tester to terminal ⑫.

Terminal 2 and (+) terminal	Terminal 12 and terminal 4
Connected	Continuity
Unconnected	No continuity

(2) Replace the ignition power transistor if there is a malfunction.



**No. 3 – No. 6 coil side**


(1) Connect the negative (–) terminal of the 1.5V power supply to terminal ④ of the ignition power transistor; then check whether there is continuity between terminal ⑪ and terminal ④ when terminal ① and the positive (+) terminal are connected and disconnected.

**NOTE**

Connect the (–) probe of the circuit tester to terminal ⑪.

Terminal 1 and (+) terminal	Terminal 11 and terminal 4
Connected	Continuity
Unconnected	No continuity

(2) Replace the ignition power transistor if there is a malfunction.



**IGNITION COIL**

**Primary Coil Resistance**

Measure the resistance between connector terminal ③ (power) and each coil terminal.

**Measuring point:**

- Coil A (No. 1 – No. 4 cylinder side coil) ..... ② – ③
- Coil B (No. 2 – No. 5 cylinder side coil) ..... ② – ③
- Coil C (No. 3 – No. 6 cylinder side coil) ..... ② – ③

**Standard value: 0.67 – 0.81 Ω**


**Secondary Coil Resistance**

Measure the resistance between each coil high voltage terminals.

**Measuring point:**

- Coil A (No. 1 – No. 4 cylinder side coil)
- Coil B (No. 2 – No. 5 cylinder side coil)
- Coil C (No. 3 – No. 6 cylinder side coil)


**Standard value: 11.3 – 15.3 kΩ**




**SERVICE POINTS OF INSTALLATION****2. INSTALLATION OF SPARK PLUG CABLE**

Improper arrangement of spark plug cables will induce voltage between the cables, causing miss firing and developing a surge at acceleration in high-speed operation. Therefore, be careful to arrange the spark plug cables properly by the following procedure.

1. Install the spark plug cable clamps as shown in the illustration.
2. The numerals on the support and clamp indicate the spark plug cable No.
3. Pay attention to the following items when the spark plug cables are installed.
  - (1) Install the cables securely to avoid possible contact with metal parts.
  - (2) Install the cables neatly, ensuring they are not too tight, loose, twisted or kinked.



**DISTRIBUTOR****DISASSEMBLY AND REASSEMBLY****Disassembly steps**

1. Distributor cap
2. O-ring
3. Contact carbon
4. Rotor
5. O-ring
6. Housing & crankshaft position sensor assembly

7EL0103

**INSPECTION**

Check the following points; repair or replace if a problem is found.

**CAP AND ROTOR**

- (1) There must be no cracking in the cap.
- (2) There must be no damage to the cap's electrode or the rotor's electrode.
- (3) Clean away any dirt from the cap and rotor.

**CAMSHAFT POSITION SENSOR, CRANKSHAFT POSITION SENSOR**

Refer to GROUP 14 – On-vehicle Inspection of MFI Components.

# CHASSIS ELECTRICAL

## CONTENTS

AERO PARTS (ACTIVE AERO) .....	Refer to GROUP 23A	ELECTRONIC CONTROL	
ANTI-LOCK BRAKING SYSTEM .....	Refer to GROUP 5	SUSPENSION (ECS) .....	Refer to GROUP 2B
BATTERY .....	265	FRONT SEAT (POWER SEAT) .....	Refer to GROUP 23A
SERVICE ADJUSTMENT PROCEDURES .....	265	HEATER AND AIR CONDITIONING .....	Refer to GROUP 24
SPECIFICATIONS .....	265	HORN .....	360
General Specifications .....	265	HORN SWITCH* .....	362
CIGARETTE LIGHTER .....	364	RELAY .....	363
CIGARETTE LIGHTER .....	365	SPECIFICATIONS .....	360
SPECIFICATIONS .....	364	General Specifications .....	360
General Specifications .....	364	TROUBLESHOOTING .....	360
TROUBLESHOOTING .....	364	IGNITION SWITCH* .....	268
COLUMN SWITCH .....	342	IGNITION SWITCH .....	268
COLUMN SWITCH* .....	343	SPECIAL TOOL .....	268
SPECIAL TOOL .....	342	KEYLESS ENTRY SYSTEM	
SPECIFICATIONS .....	342	(CENTRAL DOOR LOCKING) .....	Refer to GROUP 23A
General Specifications .....	342	LIGHTING SYSTEM .....	288
CRUISE CONTROL SYSTEM Refer to GROUP 14G		FOG LIGHT .....	335
DOOR HANDLE AND LATCH		FOG LIGHT SWITCH .....	340
(CENTRAL DOOR LOCKING) .....	Refer to GROUP 23A	FRONT COMBINATION LIGHT .....	336
DOOR GLASS AND REGULATOR		HAZARD SWITCH .....	341
(POWER WINDOWS) .....	Refer to GROUP 23A	HEADLIGHT .....	335
DOOR MIRROR (ELECTRONIC		HIGH MOUNTED STOP LIGHT .....	338
CONTROLLED MIRROR) .....	Refer to GROUP 23A	REAR COMBINATION LIGHT - BACK-UP	
		LIGHT AND LICENSE PLATE LIGHT .....	337

CONTINUED ON NEXT PAGE

### WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

#### WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized CHRYSLER dealer.
- (3) CHRYSLER dealer personnel must thoroughly review this manual, and especially its GROUP 23B – Supplemental Restraint System (SRS), GROUP 0 – Maintenance Service, before beginning any service or maintenance of any component of the SRS or any SRS-related component.

#### NOTE

The SRS includes the following components: impact sensors, SRS diagnosis unit, SRS warning light, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (\*).

RELAY .....	338	REAR WINDOW DEFOGGER .....	406
RHEOSTAT .....	341	DEFOGGER RELAY .....	411
SERVICE ADJUSTMENT PROCEDURES .....	332	REAR WINDOW DEFOGGER SWITCH .....	410
SPECIAL TOOL .....	288	SERVICE ADJUSTMENT PROCEDURES .....	410
SPECIFICATIONS .....	288	SPECIAL TOOL .....	406
General Specifications .....	288	TROUBLESHOOTING .....	407
Service Specifications .....	288	SEAT BELT (BUZZER) .....	Refer to GROUP 23A
TROUBLESHOOTING .....	289	SEAT BELT (TENSION-REDUCER TYPE SEAT BELT) .....	Refer to GROUP 23A
METERS AND GAUGES .....	271	SUPPLEMENTAL RESTRAINT SYSTEM (SRS) .....	Refer to GROUP 23B
COMBINATION GAUGES .....	286	THEFT-ALARM SYSTEM .....	411
COMBINATION METERS .....	284	SPECIAL TOOL .....	411
SERVICE ADJUSTMENT PROCEDURES .....	279	TROUBLESHOOTING .....	412
SPECIFICATIONS .....	271	WIPER AND WASHER SYSTEM .....	346
General Specifications .....	271	REAR WIPER AND WASHER .....	357
Sealants and Adhesives .....	273	SPECIAL TOOL .....	347
Service Specifications .....	273	SPECIFICATIONS .....	346
TROUBLESHOOTING .....	274	General Specifications .....	346
RADIO AND TAPE PLAYER .....	366	Service Specifications .....	347
CD AUTO CHANGER .....	405	TROUBLESHOOTING .....	348
MOTOR ANTENNA - ANTENNA FEEDER CABLE - AMPLIFIER .....	402	WINDSHIELD WIPER AND WASHER .....	354
RADIO AND TAPE PLAYER .....	400		
RADIO REMOTE-CONTROL* .....	400		
SPEAKER .....	401		
TROUBLESHOOTING .....	366		
WHIP ANTENNA - ANTENNA FEEDER CABLE - AMPLIFIER .....	403		

# BATTERY


## SPECIFICATIONS

### GENERAL SPECIFICATIONS

Items	Specifications
Type	75D23R-MF
Ampere hours (5HR) Ah	52
Cranking rating [at – 18°C (0°F)] A	520
Reserve capacity min.	118

#### NOTES

1. CRANKING RATING is the current a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2 volts or greater at a specified temperature.
2. RESERVE CAPACITY RATING is the amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5 at 27°C (80°F).



## SERVICE ADJUSTMENT PROCEDURES

### BATTERY INSPECTION

#### BATTERY VISUAL INSPECTION (1)

The battery contains a visual test indicator which gives blue signal when an adequate charge level exists, and white signal when charging is required.

#### BATTERY VISUAL INSPECTION (2)

Make sure ignition switch is in Off position and all battery feed accessories are Off.

1. Disconnect ground cable from battery before disconnecting (+) cable.
2. Remove battery from vehicle.

#### Caution

**Care should be taken in the event battery case is cracked or leaking to protect hands from the electrolyte. A suitable pair of rubber gloves (not the household type) should be worn when removing battery by hand.**

3. Inspect battery carrier for damage caused by loss of acid from battery. If acid damage is present, it will be necessary to clean area with a solution of clean warm water and baking soda. Scrub area with a stiff bristle brush and wipe off with a cloth moistened with ammonia or baking soda in water.

4. Clean top of battery with same solutions as described in step (3).
5. Inspect battery case and cover for cracks. If cracks are present, battery must be replaced.
6. Clean the battery post with a suitable battery post cleaning tool.
7. Clean the inside surfaces of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminals clamps.
8. Install the battery in vehicle.
9. Connect (+) and (-) cables to battery in the order of mention.
10. Tighten the clamp nut securely.

## BATTERY CHARGING

### Caution

**When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries on charge or which have recently been charged.**

**Do not break live circuits at the terminals of the batteries on charge. A spark will occur where the live circuit is broken.**

**Keep all open flames away from the battery.**

Battery electrolyte temperature may temporarily be allowed to rise to 55°C (131°F). Increase of electrolyte temperature above 55°C (131°F) is harmful to the battery, causing deformation of battery cell, decrease in life of battery, etc.

### CHARGE RATE

If the test indicator is white, the battery should be charged as outlined below.

When the dot appears or when maximum charge shown below is reached, charging should be stopped.

### NOTE

When the charging is performed at 5 amps, charging is virtually 100% three hours after the indicator's indication changes from white to green.

Use fast charging only in an emergency.

If the indicator does not turn to green even after the battery is charged, the battery should be replaced; do not overcharge.

### Charge Rate Chart


Battery	Slow Charging		Fast Charging	
	5 amps 15 hrs.	10 amps 7.5 hrs.	20 amps 3.75 hrs.	30 amps 2.5 hrs.
75D23R-MF (520 amps)				

**BATTERY TEST**

TEST STEP		RESULT	ACTION TO TAKE																																												
A0	<b>VISUAL INSPECTION</b> <ul style="list-style-type: none"> <li>Remove negative cable, then positive cable.</li> <li>Check for dirty or corroded connections.</li> </ul>	 	CLEAN terminals and clamps. GO to A1. GO to A1.																																												
A1	<b>LOOSE BATTERY POST</b> <ul style="list-style-type: none"> <li>Check for loose battery post.</li> </ul>	 	REPLACE battery. GO to A2.																																												
A2	<b>CRACKED BATTERY COVER</b> <ul style="list-style-type: none"> <li>Remove holddowns and shields.</li> <li>Check for broken/cracked case or cover.</li> </ul>	 	REPLACE battery. GO to A3.																																												
A3	<b>TEST INDICATOR/OPEN CIRCUIT VOLTAGE TEST</b> <ul style="list-style-type: none"> <li>Turn headlights on for 15 seconds.</li> <li>Turn headlights off for 2 minutes to allow battery voltage to stabilize.</li> <li>Disconnect cables.</li> <li>Read open circuit voltage.</li> </ul>	Open circuit voltage is less than 12.4 V 	CHARGE battery at 5 amps, then GO to A3.																																												
		Open circuit voltage is more than 12.4 V 	GO to A4.																																												
A4	<b>LOAD TEST</b> <ul style="list-style-type: none"> <li>Connect a load tester to the battery.</li> <li>Load the battery at the recommended discharge rate (See LOAD TEST RATE CHART) for 15 seconds.</li> <li>Read voltage after 15 seconds, then remove load.</li> </ul> <table border="1" data-bbox="151 1229 817 1649"> <thead> <tr> <th colspan="3">LOAD TEST CHART</th> </tr> <tr> <th rowspan="2">Minimum voltage</th> <th colspan="2">Temperature</th> </tr> <tr> <th>°F</th> <th>°C</th> </tr> </thead> <tbody> <tr> <td>9.6</td> <td>70 and above</td> <td>21 and above</td> </tr> <tr> <td>9.5</td> <td>60</td> <td>16</td> </tr> <tr> <td>9.4</td> <td>50</td> <td>10</td> </tr> <tr> <td>9.3</td> <td>40</td> <td>4</td> </tr> <tr> <td>9.1</td> <td>30</td> <td>-1</td> </tr> <tr> <td>8.9</td> <td>20</td> <td>-7</td> </tr> <tr> <td>8.7</td> <td>10</td> <td>-12</td> </tr> <tr> <td>8.5</td> <td>0</td> <td>-18</td> </tr> </tbody> </table> <table border="1" data-bbox="151 1670 817 1808"> <thead> <tr> <th colspan="4">LOAD TEST RATE CHART</th> </tr> <tr> <th>Load test (Amps)</th> <th>Cranking Rating 0°F</th> <th>Reserve Capacity</th> <th>Application</th> </tr> </thead> <tbody> <tr> <td>240 amps</td> <td>520 amps</td> <td>118 minutes</td> <td>75D23R-MF</td> </tr> </tbody> </table>	LOAD TEST CHART			Minimum voltage	Temperature		°F	°C	9.6	70 and above	21 and above	9.5	60	16	9.4	50	10	9.3	40	4	9.1	30	-1	8.9	20	-7	8.7	10	-12	8.5	0	-18	LOAD TEST RATE CHART				Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application	240 amps	520 amps	118 minutes	75D23R-MF	 Voltage is less than minimum listed (white indicator).  Voltage is more than minimum listed. (Blue indicator).	REPLACE battery. Battery OK.
LOAD TEST CHART																																															
Minimum voltage	Temperature																																														
	°F	°C																																													
9.6	70 and above	21 and above																																													
9.5	60	16																																													
9.4	50	10																																													
9.3	40	4																																													
9.1	30	-1																																													
8.9	20	-7																																													
8.7	10	-12																																													
8.5	0	-18																																													
LOAD TEST RATE CHART																																															
Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application																																												
240 amps	520 amps	118 minutes	75D23R-MF																																												

# IGNITION SWITCH


## SPECIAL TOOL

Tool number and tool name	Replaced by Miller tool number	Application
 MB990803 Steering wheel puller	General service tool	Removal of steering wheel

# IGNITION SWITCH

## REMOVAL AND INSTALLATION

**CAUTION: SRS**  
Before removal of air bag module, refer to GROUP 23B – SRS Service Precautions and Air Bag Module and Clock Spring.



### Removal steps of ignition switch segment

3. Knee protector  
(Refer to GROUP 23A – Instrument Panel.)
- ↔ 4. Column cover lower
- ↔ 5. Column cover upper
6. Lap cooler duct and foot shower duct
10. Key reminder switch segment
11. Ignition switch segment

### Removal steps of steering lock cylinder

1. Air bag module (Refer to GROUP 23B – Air Bag Module and Clock Spring.)
- ↔ 2. Steering wheel
3. Knee protector  
(Refer to GROUP 23A – Instrument Panel.)
- ↔ 4. Column cover lower
- ↔ 5. Column cover upper
6. Lap cooler duct and foot shower duct
- ↔ 7. Column switch and clock spring assembly
8. Ignition key illumination ring
9. Steering lock cylinder

16F0507




## SERVICE POINTS OF REMOVAL

### 2. REMOVAL OF STEERING WHEEL




Remove the steering wheel by using the special tool.

#### Caution

Do not hammer on the steering wheel to remove it; doing so may damage the collapsible mechanism.



13R0655



**4. REMOVAL OF COLUMN COVER LOWER / 5. COLUMN COVER UPPER**

After the screws have been removed, remove the covers, while making sure not to break the grippers.

**9. REMOVAL OF STEERING LOCK CYLINDER**

- (1) Insert the ignition key into the steering lock cylinder and place the key in the ACC position.
- (2) Press the lock pin down with a Phillips head screwdriver (small-size one) to remove the steering lock cylinder.


**INSPECTION**

**IGNITION SWITCH INSPECTION**

- (1) Remove the knee protector, the column cover lower and the column cover upper. (Refer to GROUP 23A – Instrument Panel.)
- (2) Disconnect the wiring connector from the ignition switch and key reminder switch, and connect an ohmmeter to the switch side connector.
- (3) Operate the switch, and check the continuity between the terminals.

Position	Terminal Key	Ignition switch						Key reminder switch				Ignition key illumination light				
		1	2	3	4	5	6	7	8	9	12	10	11			
LOCK	Removed															
	Inserted															
ACC																
ON																
START																

NOTE  
O-O indicates that there is continuity between the terminals.



## SERVICE POINTS OF INSTALLATION

### 7. INSTALLATION OF COLUMN SWITCH AND CLOCK SPRING ASSEMBLY

Line up the “NEUTRAL” mark of the clock spring with the mating mark to center the clock spring.

#### Caution

If the clock spring is not centered, problems such as intermediate failure of the steering wheel to turn, broken ribbon cable in the clock spring, or the like could occur. As a result, they might hinder proper operation of the SRS, resulting in serious injury.

# METERS AND GAUGES

## SPECIFICATIONS

### GENERAL SPECIFICATIONS

#### METERS AND GAUGES

Items	Specifications
Speedometer	
Type	Electrical type
Tachometer	
Type	Pulse type
Fuel gauge	
Type	Coil type
Fuel gauge unit	
Type	Variable resistance type
Engine coolant temperature gauge	
Type	Coil type
Engine coolant temperature gauge unit	
Type	Thermistor type
Oil pressure gauge	
Type	Bi-metal type
Oil pressure gauge unit	
Type	Bi-metal type
Pressure gauge <Turbo>	
Type	Moving coil type
Voltage gauge <Non-turbo>	
Type	Moving iron type

## INDICATORS AND WARNING LIGHTS

terns	Specifications
Indicator lights	
Turn signal indicator light W	3.0
High beam indicator light W	1.4 (74)
Charging system warning light W	1.4 (74)
Oil pressure warning light W	1.4 (74)
Door-ajar warning light W	1.4 (74)
Brake warning light W	1.4 (74)
Low fuel warning light W	3.4 (158)
Seat belt warning light W	1.4 (74)
Cruise control indicator light W	1.4 (74)
Engine coolant level warning light W	1.4 (74)
Check engine warning light W	1.4 (74)
Security indicator light* <sup>1</sup> W	1.4 (74)
Power/economy changeover indicator light <A/T> W	1.12
Overdrive indicator light <A/T> W	1.12
Supplemental restraint system warning light W	1.4 (74) x 2
Anti-lock braking system warning light W	1.4 (74)
Washer fluid level indicator light W	1.4 (74)
4-wheel steering oil level warning light <4WD> W	1.4 (74)
Cruise control ON indicator light W	1.4 (74)
Tour/sport mode indicator light* <sup>2</sup> W	1.12
Tour mode indicator light* <sup>3</sup> W	1.12

## NOTE

- (1) The values in parentheses denote SAE trade numbers
- (2) The \*<sup>1</sup> symbol indicates vehicles with theft-alarm system.
- (3) The \*<sup>2</sup> symbol indicates vehicles with Electronic Control Suspension.
- (4) The \*<sup>3</sup> symbol indicates vehicles with Active Exhaust System.

## SERVICE SPECIFICATIONS

Items	Specifications
Standard Values	
Speedometer indication error	
20 mph	19-22
40 mph	38-44
60 mph	57-66
80 mph	76-88
100 m p h	94-110
40 km/h	37-44
80 km/h	75-88
120 k m / h	113-132
160 k m / h	150-176
Tachometer indication error rpm	
1,000	± 100
3,000	± 150
5,000	± 250
6,000	± 300
Fuel gauge unit resistance $\Omega$	
Point F	3 ± 2
Point E	110 ± 7
Fuel gauge unit float height mm (in.)	
Point F	18.6 – 21.6 (.73 – .85)
Point E	193.4 – 196.4 (7.61 – 7.73)
Engine coolant temperature gauge unit resistance $\Omega$ [at 70°C(158°F)]	104 ± 13.5
Fuel gauge resistance $\Omega$	
Between A- B	Approx. 254
Between A- C	Approx. 101
Between B – C	Approx. 153
Engine coolant temperature gauge resistance $\Omega$	
Between A- B	Approx. 51
Between A- C	Approx. 139
Between B – C	Approx. 190
Oil pressure gauge resistance $\Omega$	Approx. 42
Pressure meter resistance <Turbo> $\Omega$	Approx. 72

## SEALANTS AND ADHESIVES

Items	Specified sealants and adhesives
Engine coolant temperature gauge unit	MOPAR Part No. 4318034 or equivalent

## TROUBLESHOOTING

### OPERATION

#### <Fuel gauge>

- When the ignition key is at the “ON” position, the fuel gauge is activated.
- When there is much fuel, the unit’s resistance is small and the current flowing in the circuit is great, so the gauge’s indicator indicates in the “F” area.
- When there is little fuel, the unit’s resistance is high and the current flowing in the circuit is small, so the gauge’s indicator indicates in the “E” area.

#### <Engine coolant temperature gauge>

- When the ignition key is at the “ON” position, the engine coolant temperature gauge is activated.
- When the engine coolant temperature is high, the unit’s resistance is low and there is a great flow of current in the circuit, so the gauge’s indicator indicates in the “H” area.
- When the engine coolant temperature is low, the unit’s resistance is high and there is a small flow of current in the circuit, so the gauge’s indicator indicates in the “C” area.

#### <Speed sensor>

- Pulses are produced in accordance with the vehicle speed, and vehicle-speed signals are input to systems (the MFI system, etc.) that regulate according to the vehicle speed.

### TROUBLESHOOTING HINTS

1. The fuel gauge doesn’t function, or shows the incorrect indication.
  - (1) Disconnect the connector of the fuel pump and gauge unit assembly; the “F” side is indicated when terminal ⑤ is then grounded.
    - Check the fuel gauge.
2. The engine coolant temperature gauge doesn’t function, or shows the incorrect indication.
  - (1) The “H” side is indicated when the connector of the engine coolant temperature gauge unit is disconnected and then grounded.
    - Check the engine coolant temperature gauge unit.
3. Systems dependent upon control according to the vehicle speed do not function correctly.
  - Check the speed sensor

#### <Oil pressure gauge>

- When the ignition key is at the “ON” position, the oil pressure gauge is activated.
- When oil pressure is high, the internal contacts of the gauge unit are kept closed for a longer period of time. This causes more current to flow in the circuit, and the gauge pointer swings to the high pressure side.
- When oil pressure is low, the internal contacts of the gauge unit open in a shorter period of time. Therefore, there is less current flowing in the circuit and the gauge pointer swings to the low pressure side.

#### <Pressure (TURBO) gauge>

- When the ignition key is set to the “ON” position, the gauge indicator will be at “0”.
- When the engine is started, the indicator will move from “0” to the minus (–) side, and then, as the boost level increases, it will move to the plus (+) side.

#### <Voltage gauge (NON-TURBO)>

- When the ignition key is placed in the “ON” position, the voltage gauge operates and indicates a battery voltage of approximately 12V.
- When the engine is started, the voltage gauge indicates a battery voltage of 12 to 16V, indicating that the battery is on charge.



4. The oil pressure gauge doesn’t function, or shows the incorrect indication.
  - (1) The “H” side is indicated when the connector of the oil pressure gauge unit is disconnected and then grounded.
    - Check the oil pressure gauge unit.
5. The meter illumination light does not illuminate.
  - (1) The tail lights illuminate.
    - Check the rheostat.
6. The voltage gauge doesn’t function, or shows the incorrect indication.
  - Check the voltage gauge.

METER AND GAUGES CIRCUIT





CIRCUIT DIAGRAM

COMPONENT LOCATION


Engine control module




IGNIT ON SWITC (IG1)




COMBINATION METER



METER AND GAUGES CIRCUIT (CONTINUED)



WARNING LIGHT CIRCUIT  
CIRCUIT DIAGRAM






# SERVICE ADJUSTMENT PROCEDURES

## INSPECTION





### SPEEDOMETER INSPECTION

- (1) Assure tire pressure at standard value.  
(Refer to GROUP 22 – Specifications.)
- (2) Set the vehicle on a speedometer tester.
- (3) Set free rollers securely on the floor according to the wheelbase and rear tread of the vehicle (when rear wheels are to be set on free rollers).
- (4) Raise the rear wheels on a jack and' place rigid racks to support the specified positions of the side sills (when rear wheels are to be raised on a jack).
- (5) Make sure the parking brake has been set. <FWD>

<Rear wheels on free rollers>



<Rear wheels raised on jack>





- (6) Attach anchoring bars on the tie-down brackets and secure their ends to the anchor plates.
- (7) Make sure the tension on the right and left bars is the same. Also be sure there is enough tension on each bar.
- (8) Attach a chain or wire to the rear tie-down hole. Make sure the end of the wire or chain is secured firmly.
- (9) Take all other necessary precautions.
- (10) Use a speedometer tester to measure the speedometer's indication error.

### Standard value:

Standard indication	Allowable range
mph	mph
20	19 – 22
40	38 – 44
60	57 – 66
80	76 – 88
100	94 – 110
km/h	km/h
40	37 – 44
80	75 – 88
120	113 – 132
160	150 – 176

### Caution

Do not operate the clutch or accelerator abruptly or decelerate during the operations.



**TACHOMETER INSPECTION**

- (1) Insert paper clip into the engine revolution speed detection terminal provided in the engine compartment, and connect the engine tachometer to the inserted paper clip.

**Caution**

As the tachometer is negative grounded, do not connect battery conversely to prevent damaging transistor and diode.

**NOTE**

For tachometer inspection, use of a fluxmeter-type engine tachometer is recommended. (Because a fluxmeter only needs to be clipped to the high tension cable.)

- (2) Connect the engine tachometer and compare the engine tachometer and tachometer readings. Replace tachometer if difference is excessive.





**Standard value:**


- 1,000 ±100 rpm
- 3,000 ±150 rpm
- 5,000 ±250 rpm
- 6,000 ±300 rpm

**Caution**

The engine speed signal output from the DOHC engine is one-third of the actual speed. When the engine speed is measured, make sure that the engine tachometer is placed in the 2-cylinder range. (The real speed is indicated.)

**FUEL GAUGE SIMPLE INSPECTION**





**FUEL GAUGE UNIT INSPECTION**

To check, remove fuel gauge unit from fuel tank. (Refer to GROUP 14 – Fuel Tank.)

**Fuel Gauge Unit Resistance**

- (1) Check that resistance value between the fuel gauge terminal and ground terminal is at standard value when fuel gauge unit float is at point F (highest) and point E (lowest).

**Standard value: Point F:  $3 \pm 2 \Omega$   
Point E:  $110 \pm 7 \Omega$**


- (2) Check that resistance value changes smoothly when float moves slowly between point F (highest) and point E (lowest).

**Fuel Gauge Unit Float Height**

Move float and measure the height at point F (highest) and point E (lowest) with float arm touching stopper.

**Standard value:**

**Point F: 18.6 – 21.6 mm (.73 – .85 in.)  
Point E: 193.4 – 196.4 mm (7.61 – 7.73 in.)**



**FUEL SENSOR INSPECTION**


Connect fuel gauge unit to battery via test light (12V – 3.4W). Immerse in water. Condition good if light goes off when unit thermistor is in water and lights when unit is removed from water.

**Caution**

**After completing this test, wipe the unit dry and install it in the fuel tank.**


ENGINE COOLANT TEMPERATURE GAUGE SIMPLE INSPECTION

- Remove the water temperature gauge unit coupling connector.
- Connect the harness connector via a test light to the ground.
- Place the ignition switch in the ON position.




- Check the test light and gauge conditions.
- ① Test light lights. (Pointer of gauge does not swing.)
  - ② Test light lights. (Pointer of gauge swings.)
  - @ Test light does not light. (Pointer of gauge does not swing.)

- Replace water temperature gauge.
- Replace water temperature gauge unit.
- Correct harness.



1 C0009



11 Nm  
7.9 ft.lbs.

1C0010

ENGINE COOLANT TEMPERATURE GAUGE UNIT INSPECTION

To check, remove engine coolant temperature gauge unit from the intake manifold of the SOHC engine or from the thermostat housing of the DOHC engine.

Engine Coolant Temperature Gauge Unit Resistance

- (1) Immerse unit in 70°C (158°F) water to measure resistance.

Standard value: 104±13.5 Ω

- (2) After checking, apply the specified sealant around the thread of engine coolant temperature gauge unit and install on the intake manifold of the SOHC engine or on the thermostat housing of the DOHC engine.


Specified sealant: MOPAR Part No. 4318034 or equivalent

**OIL PRESSURE GAUGE SIMPLE INSPECTION**

Remove the oil pressure gauge unit coupling connector.

harness connector it to the ground. A

Place the ignition switch in the ON position.




Check the test light and gauge conditions.

① Test light lights. (Pointer of gauge does not swing.)	Replace oil pressure gauge.
② Test light lights. (Pointer of gauge swings.)	Replace oil pressure gauge unit.
③ Test light does not light. (Pointer of gauge does not swing.)	Correct harness.

**VOLTAGE GAUGE SIMPLE TEST**

Correct voltmeter to battery.

Correct voltmeter to battery.




Check voltage gauge for conditions,

① Voltage indicated by voltmeter differs from voltage indicated by voltage gauge (position indicated by pointer).	Replace gauge.
② Gauge does not operate.	Correct harness or replace gauge.

## COMBINATION METERS

### REMOVAL AND INSTALLATION



#### Removal steps

1. Knee protector (Refer to GROUP 23A – Instrument Panel.)
2. Column cover lower
3. Column cover upper
4. Meter bezel
5. Combination meter
6. Vehicles speed sensor




#### SERVICE POINTS OF REMOVAL


##### 2. REMOVAL OF COLUMN COVER LOWER / 3. COLUMN COVER UPPER

After the screws have been removed, remove the covers, while making sure not to break the grippers.

Front of vehicle




19F0123



**INSPECTION**

**VEHICLES SPEED SENSOR INSPECTION**

- (1) Remove the vehicles speed sensor and connect as shown in the illustration, using a 3 – 10 kΩ resistance.
- (2) Use a voltmeter to check for voltage at terminals ② and ③ when the pulse generator shaft is turning. (One revolution is four pulses.)




**FUEL GAUGE INSPECTION**

Measure resistance between terminals with circuit tester.

**Standard value:**

- A - B     Approx. 254 Ω
- A - C     Approx. 101 Ω
- B - C     Approx. 153 Ω

**DISASSEMBLY AND REASSEMBLY**




**Disassembly steps**

1. Trip counter reset knob
2. Meter glass
3. Window plate
4. Speedometer
5. Fuel gauge
6. Tachometer
7. Printed-circuit board
8. Meter case

## COMBINATION GAUGES


## REMOVAL AND INSTALLATION



## Removal steps

1. Instrument panel  
(Refer to GROUP 23A – Instrument Panel.)  
Distribution duct  
[Refer to GROUP 24 -Ventilators  
(Instrument Panel).]
2. Combination gauge

16F0211



16F0143

## INSPECTION


## PRESSURE GAUGE INSPECTION &lt;Turbo&gt;

Measure resistance between terminals with circuit tester.

**Standard value: Approx. 72  $\Omega$**

## VOLTAGE GAUGE INSPECTION &lt;Non-Turbo&gt;

Refer to P.8-283




16F0142

## OIL PRESSURE GAUGE INSPECTION

Measure resistance between terminals with circuit tester.

**Standard value: Approx. 42  $\Omega$**



16F0141

## ENGINE COOLANT TEMPERATURE GAUGE INSPECTION

- (1) Remove the IG terminal screw from area A.
- (2) Measure resistance between terminals with circuit tester.


## Caution

For inspection, use a circuit tester which uses a measurement current of 4mA or less.

**Standard value:**

- |       |                      |
|-------|----------------------|
| A - B | Approx. 51 $\Omega$  |
| A - C | Approx. 139 $\Omega$ |
| B - C | Approx. 190 $\Omega$ |

## DISASSEMBLY AND REASSEMBLY

**Disassembly steps**

1. Gauge bracket
2. Gauge glass
3. Window plate
4. Voltage gauge <Non-Turbo> or Pressure gauge <Turbo>
5. Oil pressure gauge
6. Engine coolant temperature gauge
7. Printed-circuit board
8. Gauge case

16F0213

# LIGHTING SYSTEM SPECIFICATIONS

## GENERAL SPECIFICATIONS

Items	Specifications
Exterior lights	
Headlight W	65155
Fog light W	35* <sup>1</sup> or 55* <sup>2</sup>
Front combination light	
Turn-signal light / side marker light CP	43/3 (3496)
Rear combination light	
Turn-signal light / side marker and tail light CP	32/2 (2057) <sup>(4)</sup>
Stop light / tail light CP	32/2 (2057)* <sup>1</sup>
Turn-signal and stop light / side marker and tail CP	3212 (2057)* <sup>2</sup>
Side marker and tail light CP	3 (168)* <sup>2</sup>
Back-up light CP	21
License plate light CP	3 (168)
High-mounted stop light CP	32 (1156) or LED* <sup>3</sup> : Light Emitting Diode
Engine compartment inspection light W	3.8 (194)
Interior lights	
Foot light W	3.4 (158)
Dome light W	8
Spot light W	8
Door light W	5
Glove compartment light W	3.4 (158)
Luggage compartment light W	5


## NOTE

- (1) \*<sup>1</sup>: Vehicles with small bumper  
 (2) \*<sup>2</sup>: Vehicles with large bumper  
 (3) \*<sup>3</sup>: Vehicles with rear spoiler  
 (4) The values in parentheses denote SAE trade number.

## SERVICE SPECIFICATIONS

Items	Specifications
Limit	
Headlight intensity	20,000 cd or more

## SPECIAL TOOL


Tool number and tool name	Replaced by Miller tool number	Application
 MB991 502 Scan Tool (MUT-II)	DRB-II Scan Tool	Checking the lighting system
 MB991 529 Diagnostic trouble code check harness	MB991 529	Checking the lighting system using a voltmeter

# TROUBLESHOOTING


## HEADLIGHT CIRCUIT (VEHICLES FOR U.S.)


<VEHICLES WITHOUT THEFT-ALARM SYSTEM>

CIRCUIT DIAGRAM



HEADLIGHT CIRCUIT (VEHICLES FOR U.S.) <VEHICLES WITHOUT THEFT-ALARM SYSTEM>  
(CONTINUED)











<VEHICLES WITH THEFT-ALARM SYSTEM> (CONTINUED)







(VEHICLES FOR CANADA)


<VEHICLES WITHOUT THEFT-ALARM SYSTEM>

CIRCUIT DIAGRAM







(VEHICLES FOR CANADA) <VEHICLES WITHOUT THEFT-ALARM SYSTEM> (CONTINUED)




<VEHICLES WITH THEFT-ALARM SYSTEM>  
CIRCUIT DIAGRAM



<VEHICLES WITH THEFT-ALARM SYSTEM> (CONTINUED)









COMPONENT LOCATION

Headlight relay/Tail light relay




Data link connector




Light automatic shut-off unit

<Vehicles with keyless entry system>




Light automatic shut-off unit


<Vehicles without keyless entry system>



ETACS unit



Daytime running light control unit/  
Upper beam relay



**OPERATION****<Headlights ON operation>**

- Turn the lighting switch to “HEAD”, and the contact point of the headlight relay will be closed to turn “ON” the headlight relay.
- When the dimmer switch is placed in the LO position, the headlight low-beams go on. When the switch is placed in the HI position, the headlight low-beams and high-beams go on.

**<High-beam indicator light>**

- When the high-beam is lit or when the passing switch is activated, the high-beam indicator light will be lit.

**<Light automatic shut-OFF system>**

- If the driver's door is opened after the ignition switch is turned to “OFF” or the ignition switch is turned to “OFF” after the driver's door is opened when the headlights are lit, the current which flows to the coil side of the headlight relay will be cut off by the light automatic shut-OFF unit opening the contact point, and the headlight relay will be turned “OFF” to automatically shut off the headlights.
- To turn the headlights on again after they are automatically shut off, turn the lighting switch to “OFF” once and then back to “HEAD”, or turn the ignition switch to “ACC” or “ON”, and the automatic shut-OFF will be cancelled and the current will flow from the light automatic shut-OFF unit to the coil side of the headlight relay again to close the contact point. Thus, the headlight relay will be turned “ON” to turn on the headlights.

**NOTE**

When the lighting switch is at “HEAD”, the light automatic shut-OFF system is valid for tail lights, parking and side marker lights, license plate light, illumination light, etc.


(Refer to P.8-315.)

## TROUBLESHOOTING HINTS


Phenomenon		Checking method
Headlights don't come on.	But the tail lights do illuminate.	<ul style="list-style-type: none"> <li>• Check the headlight relay. (Refer to P.8-338.)</li> <li>• Check the lighting switch. (Refer to P.8-344.)</li> <li>• Check the light automatic shut-OFF unit. (Refer to P.8-339.)</li> </ul>
	The tail lights also don't illuminate.	<ul style="list-style-type: none"> <li>• Check the fusible link ③.</li> </ul>
The low beam at both sides doesn't illuminate.		<ul style="list-style-type: none"> <li>• Check the "LO" contacts of the dimmer switch.</li> </ul>
The upper beam at both sides doesn't illuminate.	The passing signal functions OK.	<ul style="list-style-type: none"> <li>• Check the "HI" contacts of the dimmer switch.</li> </ul>
	The passing signal doesn't function.	<ul style="list-style-type: none"> <li>• Check the dimmer switch. (Refer to P.8-344.)</li> </ul>
One headlight doesn't illuminate.		<ul style="list-style-type: none"> <li>• Check the bulb.</li> </ul>
Can't switch from low to high beam or vice versa.		<ul style="list-style-type: none"> <li>• Check the dimmer switch. (Refer to P.8-344.)</li> </ul>
The high beam indicator light doesn't illuminate.	The high beam of the headlights is normal.	<ul style="list-style-type: none"> <li>• Check dedicated fuse No. ⑤.</li> <li>• Check the bulb.</li> </ul>
Headlights are not automatically shut off.	Tail lights are automatically shut off.	<ul style="list-style-type: none"> <li>• Check the light automatic shut-OFF unit. (Refer to P.8-339.)</li> </ul>
	Tail lights are not automatically shut off either.	<ul style="list-style-type: none"> <li>• Check the driver's side door switch. (Refer to GROUP 23A – Door Assembly).</li> <li>• Check the light automatic shut-OFF unit. (Refer to P.8-339.)</li> </ul>

## NOTE

For information concerning the theft-alarm system, refer to P.8-412.



20F0164



MB991529

20F0163

### Input Signal

Using the scan tool or voltmeter, check whether or not the input signals from each switch are being input to the ETACS unit.

### When using the scan tool

- (1) Connect the scan tool to the data link connector.

#### Caution


**Turn off the ignition switch beforehand whenever the scan tool is connected or disconnected.**

- (2) If the scan tool makes a peep sound when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.


### When using a voltmeter

- (1) Connect a voltmeter to the ETACS terminal and the ground terminal of the data link connector using the special tool.
- (2) If the voltmeter pointer deflects once when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.

FOG LIGHT CIRCUIT  
CIRCUIT DIAGRAM



FOG LIGHT CIRCUIT (CONTINUED)



**OPERATION**

- When the fog light switch is placed in the ON position with the lighting switch in the HEAD position and the dimmer switch in the LO position, current flows through the dedicated fuse ④ to the coil of the fog light relay, the fog light switch, the dimmer switch and ground, causing the contacts of the fog light relay to close.  
When the contacts of the fog light relay close, current flows through the dedicated fuse ④ to the contacts of the fog light relay, the fog lights and ground, causing the fog lights to come on.
- When the dimmer switch is placed in the HI position or the lighting switch is placed in the TAIL or OFF position while the fog lights are ON, current supply to the fog light relay or headlight relay is cut off. As a result, the contacts of the fog light relay open, and the fog lights go out.

**NOTE**

The fog lights are included in the light automatic shut-OFF system operation. (Refer to P.8-304.) The illumination lights are also included in the same system operation.

**Fog Lights Operation Conditions**

Fog light switch	Lighting switch	Dimmer switch	Fog lights
ON position	OFF position or TAIL position	LO position	OFF
		HI position	OFF
	HEAD position	LO position	ON
		HI position	OFF

**TROUBLESHOOTING HINTS**


1. The right or left fog lights only go on.
  - Check the bulb.
2. Fog lights do not go on when the fog light switch is set at ON.
  - Check the dedicated fuse ④.
  - Check the fog light relay. (Refer to P.8-338.)
  - Check the fog light switch.

**NOTE**


For the light automatic shut-OFF system troubleshooting hints, refer to P.8-305.

**COMPONENT LOCATION**


**Headlight relay/Foglight relay**



**Light automatic shut-off unit**




**Light automatic shut-off unit**




TAIL LIGHT, PARKING/SIDE MARKER LIGHT AND LICENSE PLATE LIGHT CIRCUIT

<VEHICLES WITH SMALL BUMPER>


CIRCUIT DIAGRAM




TAIL LIGHT, PARKING/SIDE MARKER LIGHT AND LICENSE PLATE LIGHT CIRCUIT  
 <VEHICLES WITH SMALL BUMPER> (CONTINUED)



<VEHICLES WITH LARGE BUMPER>  
CIRCUIT DIAGRAM



<VEHICLES WITH LARGE BUMPER> (CONTINUED)



**OPERATION**

- When the lighting switch is placed in the TAIL or HEAD position, current flows through the coil of the tail light relay to the lighting switch and ground, causing the contacts of the tail light relay to close. Then current flows through the contacts of the tail light relay to the dedicated fuse (2), the individual lights and ground, causing the tail lights, parking/side marker lights and license plate lights to go ON.

**<Light automatic shut-OFF system>**




- If the driver's door is opened after the ignition switch is turned to "OFF" or the ignition switch is turned to "OFF" after the driver's door is opened when the tail lights are lit, the current which flows to the coil side of the tail light relay will be cut off by the light automatic shut-OFF unit opening the contact point, and the tail light relay will be turned "OFF" to automatically shut off the tail lights, parking and front side marker lights and license plate light.
- To turn on the tail lights, parking and front side marker lights and license plate light again after they are automatically shut off, turn the lighting switch to "OFF" once and to "HEAD" again, or turn the ignition switch to "ACC" or "ON", and the automatic shut-off will be cancelled and the current will flow from the light automatic shut-OFF unit to the coil side of the tail light relay to close the contact point. Thus, the tail light relay will be turned "ON" to turn on the tail lights, parking and front marker lights and license plate light.

**NOTE**

When the lighting switch is at the "HEAD" position, the light automatic shut-OFF system will be also activated for the headlights. (Refer to P.8-304.) The same system will also be activated for the illumination lights, etc.

**TROUBLESHOOTING HINTS**

- All lights don't illuminate.
  - The headlights don't illuminate, either.
    - Check the fusible link (3).
  - The headlights illuminate.
    - Check the tail light relay. (Refer to P.8-338.)
    - Check the dedicated fuse (2).
    - Check the lighting switch. (Refer to P.8-344.)
    - Check the light automatic shut-OFF unit. (Refer to P.8-339.)
- Some light does not come on.
  - Check the bulb.
  - Check the grounding circuit.
- Some light is not automatically shut off.
  - Check the driver's side door switch. (Refer to GROUP 23A – Door Assembly.)
  - Check the automatic shut-OFF unit. (Refer to P.8-339.)

**COMPONENT LOCATION****Taillight relay****Light automatic shut-off unit****Light automatic shut-off unit**

**DOME LIGHT, FOOT LIGHT AND IGNITION KEY CYLINDER ILLUMINATION LIGHT CIRCUIT**

**OPERATION**

**<Dome light>**

- Battery voltage is always applied to the dome light. When the dome light switch is turned to “ON”, the dome light will remain lit. After either door is opened if the dome light switch is at “DOOR” position, the dome light will come on.
- With the dome light turned on (with the ignition switch in the OFF position and with the dome light switch in the DOOR position), close all doors, and the timer circuit in the ETACS unit will be activated to gradually vary the voltage for approx. 6 seconds owing to the duty control, and the voltage will be output to transistor Tr. Since the voltage applied to the dome light gradually decreases, the dome light will be dimmed.
- If the ignition switch is turned to “ON” while the dome light is lit (while the timer is activated), the timer circuit will be opened to turn “off” transistor Tr. This will immediately turn off the dome light without dimming.

**<Foot lights and ignition key illumination light>**


- Battery voltage is always applied to the foot lights and ignition key illumination light. With the ignition switch in the OFF position, open any door, and all lights will come on.
- With all lights turned on (with the ignition switch in the OFF position), close all doors, and the timer circuit inside the ETACS unit will operate in the same manner as the dome light to dim all lights. When the ignition switch is placed in the ON position with all lights turned on (with the timer in operation), the same operation as the dome light will take place.

**TROUBLESHOOTING HINTS**


Phenomenon		Checking method
Dome light does not come on when a door is opened with the dome light switch in the DOOR position.	The foot lights and ignition key cylinder illumination light don't illuminate, either.	<ul style="list-style-type: none"> <li>• Check the door switch input signal. (Refer to P.8-317.)</li> <li>• Check the door switch. (Refer to GROUP 23B – Door Assembly.)</li> </ul>
	The foot lights and ignition key cylinder illumination light illuminate.	<ul style="list-style-type: none"> <li>• Check the dome light switch.</li> <li>• Check the dome light bulb.</li> </ul>
Dome light, foot lights and ignition key illumination light go out at once when doors are closed.		<ul style="list-style-type: none"> <li>• Check the door switch input signal. (Refer to P.8-317.)</li> </ul>
Even if ignition switch is turned on while lights are being dimmed, lights do not go out at the same time.		<ul style="list-style-type: none"> <li>• Check the ignition switch input signal. (Refer to P.8-317.)</li> </ul>


**COMPONENT LOCATION**

**ETACS unit**




**Data link connector**





20F0164



MB991529

20F0163

### Input Signal

Using the scan tool or voltmeter, check whether or not the input signals from each switch are being input to the ETACS unit.

### When using the scan tool

- (1) Connect the scan tool to the data link connector.

#### Caution

**Turn off the ignition switch beforehand whenever the scan tool is connected or disconnected.**


- (2) If the scan tool makes a beep sound when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.

### When using a voltmeter

- (1) Connect a voltmeter to the ETACS terminal and the ground terminal of the data link connector using the special tool.
- (2) If the voltmeter pointer deflects once when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.





DOME LIGHT, FOOT LIGHT AND IGNITION KEY CYLINDER ILLUMINATION LIGHT CIRCUIT

CIRCUIT DIAGRAM




VEHICLES \*1  
WITHOUT  
THEFT-ALARM  
SYSTEM

VEHICLES \*2  
WITH  
THEFT-ALARM  
SYSTEM



DOOR LIGHT AND LUGGAGE COMPARTMENT LIGHT CIRCUIT  
CIRCUIT DIAGRAM




135-AC-R0817-N3C

OPERATION

- Battery voltage is always applied (via sub-fusible link No. ⑥ and multipurpose fuse No. ⑱) to the luggage compartment light and door light.
- When the door is opened, the door switch is switched ON and the door light illuminates.
- When the liftgate is opened, the luggage compartment light switch is switched ON and the luggage compartment light illuminates.

# GLOVE BOX LIGHT, VANITY MIRROR LIGHT AND INSPECTION LIGHT CIRCUIT CIRCUIT DIAGRAM



X35-AC-RO818-NC


## OPERATION

- When the lighting switch is placed in the TAIL or HEAD position, and the contacts of the tail light relay close, battery voltage is applied via the dedicated fuse ② to the glove box light, the vanity mirror light and the inspection light.
- When the glove box is opened, the glove box illumination light switch is switched ON and the glove box illumination light illuminates.
- When the vanity mirror lid is opened, the vanity mirror light switch is switched ON and the vanity mirror light illuminates.
- When the engine hood is opened, the inspection light switch is switched ON and the inspection light illuminates.


## NOTE

The light automatic shut-OFF system is valid for the glove box light, vanity mirror light and inspection light. (Refer to P.8-315.)

**BACK-UP LIGHT CIRCUIT  
CIRCUIT DIAGRAM**



**COMPONENT LOCATION**



X35-AC-R0914-R3C


**OPERATION**

- When, with the ignition switch at the "ON" position, the shift lever (or the selector lever) is moved to the "R" position, the backup light switch (M/T) is switched ON (or the park/neutral position switch (A/T) is switched to the "R" position), and the backup light illuminates.

TURN-SIGNAL LIGHT AND HAZARD LIGHT CIRCUIT

<VEHICLES WITH SMALL BUMPER – TYPE 1>

CIRCUIT DIAGRAM





**OPERATION**


1. When operation is normal
  - When the ignition switch is switched to the ON position, battery voltage is applied (via the multi-purpose fuse ⑪ and hazard switch) to the turn-signal and hazard flasher unit.
  - When the turn-signal switch is switched to the LH (or RH) position, Tr (within the flasher unit) is switched ON and OFF repeatedly. Then the contacts of the relay (also within the flasher unit) repeatedly switch from ON to OFF, causing the turn-signal lights and turn-signal indicator light LH (or RH) to flash.
2. If one of the bulbs is burned out
  - If either of the turn-signal light bulbs is burned-out, the resistance of the turn-signal circuit as a whole increases, resulting in shorter ON and OFF intervals of the Tr and a higher flashing rate of the lights.

**<Hazard-warning lights>**

- When the hazard-warning switch is switched to the “ON” position, the relay contact of the turn signal and hazard flasher unit is switched ON and OFF repeatedly, in the same manner as for the operation of the turn-signal lights, and the left and right turn-signal lights and turn-signal indicator lights simultaneously flash repeatedly.

**NOTE**

- (1) The number of flashes of the hazard-warning lights does not change if there is damaged or disconnected wiring of one light.
- (2) The light automatic shut-OFF system is valid for the illumination light of the hazard switch. (Refer to P.8-315.)

**COMPONENT LOCATION****Turn-signal and hazard flasher unit****TROUBLESHOOTING HINTS**


1. The turn-signal lights and hazard-warning lights do not operate at all.
  - Check the hazard switch contact (power supply side).
  - Check the turn-signal and hazard flasher unit.
2. All turn-signal lights at the left (or right) side do not function.
  - (1) The hazard-warning lights function normally.
    - Check the hazard switch contact (turn-signal side).
    - Check the turn-signal switch.
3. The number of flashes of the turn-signal lights is excessive.
  - Check the bulbs.
4. The hazard-warning lights do not function.
  - (1) The turn-signal lights function normally.
    - Check the hazard switch contact (hazard-warning light side).

**NOTE**

For the troubleshooting hints of the automatic light shut-OFF system, refer to P.8-315.



TURN SIGNAL  
AND HAZARD  
FLASHER UNIT



**OPERATION**

1. When operation is normal
  - When the ignition switch is switched to the ON position, battery voltage is applied (via the multi-purpose fuse ⑪) and hazard switch)
  - When the turn-signal switch is switched to the LH position, Tr1 (within the flasher unit) is switched ON and OFF repeatedly. Then the contacts of the relay 1 (also within the flasher unit) repeatedly switch from ON to OFF, causing the turn-signal lights and turn-signal indicator light LH to flash.
  - When the turn-signal switch is switched to the RH position, Tr2 (within the flasher unit) is switched ON and OFF repeatedly. Then the contacts of relay 2 (also within the flasher unit) repeatedly switch from ON to OFF, causing the turn-signal lights and turn-signal indicator light RH to flash.
2. If one of the bulbs is burned out
  - If the LH (or RH) turn-signal light bulb is burned-out, the resistance of the turn-signal circuit as a whole increases, resulting in shorter ON and OFF intervals of the LH Tr1 (or RH Tr2) and a higher flashing rate of the LH lights (or RH lights).

**<Hazard-warning lights>**

- When the hazard-warning switch is switched to the “ON” position, the relay contact of the turn signal and hazard flasher unit is switched ON and OFF repeatedly, in the same manner as for the operation of the turn-signal lights, and the left and right turn-signal lights and turn-signal indicator lights simultaneously flash repeatedly.

**NOTE**


- (1) The number of flashes of the hazard-warning lights does not change if there is damaged or disconnected wiring of one light.
- (2) The light automatic shut-OFF system is valid for the illumination light of the hazard switch. (Refer to P.8-315.)

**TROUBLESHOOTING HINTS**

1. The turn-signal lights and hazard-warning lights do not operate at all.
  - Check the hazard switch contact (power supply side).
  - Check the turn-signal and hazard flasher unit.
2. All turn-signal lights at the left (or right) side do not function.
  - (1) The hazard-warning lights function normally.
    - Check the hazard switch contact (turn-signal side).
    - Check the turn-signal switch.
3. The number of flashes of the turn-signal lights is excessive.
  - Check the bulbs.
4. The hazard-warning lights do not function.
  - (1) The turn-signal lights function normally.
    - Check the hazard switch contact (hazard-warning light side).

**NOTE**


For the troubleshooting hints of the automatic light shut-OFF system, refer to P.8-315.

**COMPONENT LOCATION****Turn-signal and hazard flasher unit**

TURN-SIGNAL LIGHT, HAZARD LIGHT AND STOP LIGHT CIRCUIT

<VEHICLES WITH LARGE BUMPER>


CIRCUIT DIAGRAM





**OPERATION**

1. When operation is normal
  - When the ignition switch is switched to the ON position, battery voltage is applied (via the multi-purpose fuse ⑪ and hazard switch) to the turn-signal and hazard flasher unit. Battery voltage is also always applied via the multi-purpose fuse ⑰ and the stop light switch to the turn-signal and hazard flasher unit.
  - When the turn-signal switch is placed in the LH (or RH) position, the LH Tr1 (or RH Tr2) repeatedly switches from ON to OFF. At the same time, the contacts of LH relay 1 (or the contacts of RH Tr2) repeatedly switch from ON to OFF, causing the turn-signal lights and turn-signal indicator light LH (or RH) to flash.
  - When the brake pedal is depressed while the turn-signal lights LH (or RH) are flashing, the stop light switch enters the ON state. Then the LH (or RH) rear combination lights that are indicating the turning direction continue to flash. In the other rear combination lights that are not indicating the turning direction, however, the stop light comes on.
2. If one of the bulbs is burned-out
  - If the LH (or RH) turn-signal light bulb is burned-out, the resistance of the turn-signal circuit as a whole increases, resulting in shorter ON and OFF intervals of the LH Tr1 (or RH Tr2) and a higher flashing rate of the LH lights (or RH lights).  
When the turn-signal switch is placed in the LH (or RH) position, if the contacts of the LH relay 3 (or the contacts of the RH relay 4) continue to be OFF, the front combination lights alone will flash at a higher rate just like when a turn-signal light bulb is burned-out, whereas the rear combination lights cease to flash.

**COMPONENT LOCATION****Turn-signal and hazard flasher unit****<Hazard-warning lights>**

- When the hazard-warning switch is switched to the "ON" position, the relay contact of the turn signal and hazard flasher unit is switched ON and OFF repeatedly, in the same manner as for the operation of the turn-signal lights, and the left and right turn-signal lights and turn-signal indicator lights simultaneously flash repeatedly.

**NOTE**

- (1) The number of flashes of the hazard-warning lights does not change if there is damaged or disconnected wiring of one light.
- (2) The light automatic shut-OFF system is valid for the illumination light of the hazard switch. (Refer to P.8-315.)

**TROUBLESHOOTING HINTS**

1. The turn-signal lights and hazard-warning lights do not operate at all.
  - Check the hazard switch contact (power supply side).
  - Check the turn-signal and hazard flasher unit.
2. All turn-signal lights at the left (or right) side do not function.
  - (1) The hazard-warning lights function normally.
    - Check the hazard switch contact (turn-signal side).
    - Check the turn-signal switch.
3. The number of flashes of the turn-signal lights is excessive.
  - Check the bulbs.
4. The turn-signal lights of the front combination lights flash at a higher rate.
  - (1) The turn-signal lights of the rear combination lights do not flash but the stop light illuminates.
    - Check the turn-signal and hazard flasher unit.
5. The hazard-warning lights do not function.
  - (1) The turn-signal lights function normally.
    - Check the hazard switch contact (hazard-warning light side).


**NOTE**

For the troubleshooting hints of the automatic light shut-OFF system, refer to P.8-315.

STOP LIGHT CIRCUIT

<VEHICLES WITH SMALL BUMPER>

CIRCUIT DIAGRAM




## SERVICE ADJUSTMENT PROCEDURES

### HEADLIGHT AIMING

#### PRE-AIMING INSTRUCTIONS

1. Inspect for badly rusted or faulty headlight assemblies. These conditions must be corrected before a satisfactory adjustment can be made.
2. Place vehicle on a level floor.
3. Bounce front suspension through three (3) oscillations by applying body weight to hood or bumper.
4. Inspect tire inflation.
5. Rock vehicle sideways to allow vehicle to assume its normal position.
6. If fuel tank is not full, place a weight in trunk of vehicle to simulate weight of a full tank [3 kg (6.5 lbs.) per gallon].
7. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 lbs.) placed in driver's position.
8. Thoroughly clean headlight lenses.





#### VERTICAL ADJUSTING

Adjust the vertical angle with the vertical adjusting gear so that the bubble of the vertical angle gauge is aligned with the "0" mark position.

#### NOTE

The beam angle will change about  $0^{\circ}12'$  with on mark.




#### HORIZONTAL ADJUSTING

Insert a screwdriver in the horizontal adjusting hole and turn until the "0" mark and the center line are in alignment.

#### NOTE

The beam angle will change about  $0^{\circ}23'$  with on mark.



## AIMING WITH SCREEN

### HEADLIGHT AIM PREPARATION

Place vehicle on a known level floor 7.6 m (25 feet) from aiming screen or light colored wall. Four lines of adhesive tape or like are required on screen or wall:



1. Position a vertical tape so that it is aligned with the vehicle center line.
2. Position a horizontal tape with reference to center line of headlight.
3. Position a vertical tape on the screen with reference to the center line of each of headlights.

### VISUAL HEADLIGHT ADJUSTMENT

1. A properly aimed lower beam will appear on the aiming screen 7.6 m (25 feet) in front of the vehicle. The shaded area as shown in the illustration indicates high intensity zone.
2. Adjust low beam of headlights to match the low beam pattern of the right and left headlights.

### NOTE

If the visual headlight adjustment at low beam is made, the adjustment at high beam is not necessary.



3. Check to see that the bubble in the headlight vertical angle gauge is in the illustrated position.
4. If the bubble is out of position, adjust by turning the adjusting screw.
5. Confirm that the "0" mark on the headlight horizontal angle adjusting gear (B) is in alignment with the center line.
6. If not, perform the adjustment as follows.

- (1) Pull up the stopper.
- (2) Push the gear (B) in the arrow direction to disengage it from the gear (A).
- (3) Align the "0" mark on the gear (B) with the center line.
- (4) Push down the stopper to engage the gear (B) with the gear (A).


## LUMINOUS INTENSITY MEASUREMENT

Measure the luminous intensity of headlights with a photometer in accordance with the instruction manual prepared by the manufacturer of the photometer and make sure that the luminous intensity is within the following limit.

**Limit: 20,000 cd or more**


### NOTE

- (1) When measuring the luminous intensity of headlight, keep the engine at 2,000 rpm and have the battery charged.
- (2) If there are specific regulations for luminous intensity of headlights in the region where the vehicle is operated, make sure that the intensity conforms to the requirements of such regulations.



**FOG LIGHT AIMING**

1. Place vehicle on a known level floor 7.6 m (25 feet) from aiming screen or light colored wall.
2. Adjust the adjusting screw so that the top end of high intensity area may come to the same level as the fog light center height.



**BULB REPLACEMENT**

1. Disconnect the connector.
2. Turn the bulb socket counterclockwise to pull it out.

**Caution**


**Do not touch the surface of the headlight bulb with hands or dirty gloves. If the surface does become dirty, clean it with alcohol or thinner, and let it dry thoroughly before installing.**

# HEADLIGHT

## REMOVAL AND INSTALLATION

### Removal steps

1. Front combination light
2. Headlight




16F0480

# FOG LIGHT

## REMOVAL AND INSTALLATION

### <Vehicles with small bumper>




16F0487

### <Vehicles with small bumper>

#### Removal steps

1. Front air side spoiler
2. Fog light assembly
- + 5. Bulb

### <Vehicles with large bumper>



16F0488


### <Vehicles with large bumper>

#### Fog light removal steps

1. Front air side spoiler
2. Fog light assembly

#### Bulb replacement removal steps

3. Lens
4. Projector unit
- 4 5. Bulb
6. Bracket



## SERVICE POINT OF REMOVAL

### 5. REMOVAL OF BULB

- (1) Remove the socket cover (vehicles with small bumper fog light) or projector unit (vehicles with larger bumper fog light).
- (2) Remove the bulb mounting spring and remove the bulb.


#### Caution

Do not touch the surface of the headlight bulb with bare hands or dirty gloves.

If there are deposits on the surface, loosen and remove the deposits with a cloth dipped in alcohol or thinner, and let the surface dry before mounting the bulb.

## FRONT COMBINATION LIGHT

### REMOVAL AND INSTALLATION



16F0477


# REAR COMBINATION LIGHT - BACK-UP LIGHT AND LICENSE PLATE LIGHT

## REMOVAL AND INSTALLATION

<Vehicles with small bumper>


### Removal steps

1. Rear combination light unit
2. Bulb
3. Rear side trim (Refer to GROUP 23A – Trims.)
3. Socket assembly



16F0208

<Vehicles with large bumper>



### Removal steps

1. Rear combination light unit
2. Bulb
3. Rear side trim (Refer to GROUP 23A – Trims.)
3. Socket assembly

16F0209

# HIGH MOUNTED STOP LIGHT

N08IKAL

## REMOVAL AND INSTALLATION

### <Vehicles with rear spoiler>


#### Removal steps

1. Liftgate lower trim  
(Refer to GROUP 23A – Trims.)
2. Air spoiler  
(Refer to GROUP 23A – Aero Parts.)
- ↔ 3. High mounted stop light


### <Vehicles without rear spoiler>

#### Removal steps

1. Liftgate lower trim  
(Refer to GROUP 23A – Trims.)
2. High mounted stop light cover
3. High mounted stop light lens and bracket
4. Gasket



16F0230




16F0231

### SERVICE POINT OF REMOVAL

#### 3. REMOVAL OF HIGH-MOUNTED STOP LIGHT (Vehicles with rear spoiler)

Remove the air spoiler center stay mounting screws before removing the high-mounted stop light.




16F0197

### RELAY

#### INSPECTION

#### HEADLIGHT RELAY / TAILLIGHT RELAY / FOG LIGHT RELAY


Connect battery to terminal 1 and check continuity between terminals with terminal 3 grounded.



16F0122

18F0061


Power is supplied	4 – 5 terminals	Continuity
Power is not supplied	4 – 5 terminals	No continuity
	1 – 3 terminals	Continuity



**UPPER BEAM RELAY  
(VEHICLES FOR CANADA)**

Connect battery to terminal 1 and check continuity between terminals with terminal 2 grounded.

Power is supplied	3 – 4 terminals	Continuity
Power is not supplied	3 – 4 terminals	No continuity
	1 – 2 terminals	Continuity




**LIGHT AUTOMATIC SHUT-OFF UNIT**

- (1) Remove the quarter trim. (Refer to GROUP 23A – Trim.)
- (2) Keeping the connector connected to the light automatic shut-OFF unit, connect the test light (12V – 3.4W) from the harness side to terminal No. 6. (for tail lights) or No. 7 (for headlights). Under the following conditions, check the operation of the test light.

	Conditions	Test light
(1)	Ignition switch and lighting switch are at "OFF" position.	Illuminated
(2)	Lighting switch is at "TAIL" or "HEAD" with ignition switch at "ACC" or "ON" position.	Illuminated
(3)	Driver's door is opened after ignition switch is turned from state (2) to "OFF" position. (Reverse procedure is also allowable.)	Illuminated
(4)	Ignition switch is once turned from state (3) "OFF", then turned to "TAIL" or "HEAD".	Extinguished
(5)	Ignition switch is turned from state (3) to "ACC" or "ON" position.	Illuminated

# FOG LIGHT SWITCH


## REMOVAL AND INSTALLATION




### Removal steps

1. Knee protector  
(Refer to GROUP 23A – Instrument Panel.)
- ↔
2. Column cover lower
- ↔
3. Column cover upper
4. Meter bezel
5. Fog light switch
6. Rear window defogger switch


Front of vehicle



16F0122



16F0140



16A0358

### SERVICE POINTS OF REMOVAL

#### 2. REMOVAL OF COLUMN COVER LOWER / 3. COLUMN COVER UPPER

After the screws have been removed, remove the covers, while making sure not to break the grippers.


### INSPECTION

Operate the switch to check for continuity between terminals.

Terminal	1	5	3	4
Switch position				
ON	○	○		Illumination light
OFF				

### NOTE


- (1) ○—○ indicates that there is continuity between the terminals.
- (2) Refer to P.8-410. Check the rear window defogger switch.



## RHEOSTAT


### INSPECTION

(1) Remove the instrument panel switch from the knee protector.



(2) Connect the battery and a test bulb (40W) as shown in the figure.


(3) The function of the rheostat is normal if the intensity of illumination changes smoothly, without flashing or flickering, when the rheostat is operated.



## HAZARD SWITCH

### INSPECTION

(1) Remove the center air outlet assembly from instrument panel. [Refer to GROUP 24 – VENTILATORS (Instrument Panel).]



(2) Operate the switch to check for continuity between terminals.

Terminal	1	5	6	7	8	9	10	2	3
Switch position									
ON			○	○	○	○	○		○
OFF		○			○				○

Illumination light

**NOTE**

○—○ indicates that there is continuity between the terminals.

# COLUMN SWITCH

## SPECIFICATIONS


### GENERAL SPECIFICATIONS

Items	Specifications
Column switch	
Lighting switch	
Rated load A	$0.22 \pm 0.05$
Voltage drop V	0.2 or less
Turn-signal switch	
Rated load A	$6.6 \pm 0.5$
Voltage drop V	0.2 or less
Dimmer/passing switch	
Rated load A	
High beam	$10.7 \pm 0.8$
Low beam	$9.8 \pm 0.7$
Passing	$20.5 \pm 1.5$
Voltage drop V	0.2 or less

**NOTE**

For the wiper and washer switch, refer to P.8-355.


## SPECIAL TOOL

Tool number and tool name	Replaced by Miller tool number	Application
 <p>M 8990803 Steering wheel puller</p>	General service tool	Removal of steering wheel

# COLUMN SWITCH

## REMOVAL AND INSTALLATION

**CAUTION: SRS**  
 Before removal of air bag module, refer to GROUP 23B – SRS Service Precautions and Air Bag Module and Clock Spring.



- 1. Air bag module (Refer to GROUP 23B – Air Bag Module and Clock Spring.)
- 2. Steering wheel
- 3. Knee protector (Refer to GROUP 23A – Instrument Panel.)
- 4. Column cover lower
- 5. Column cover upper
- 6. Lap cooler duct and foot shower duct
- 7. Column switch left (For lighting switch, dimmer/passing switch and turn signal switch)
- 8. Column switch right (For wiper and washer switch)

16F0506


### SERVICE POINTS OF REMOVAL

#### 2. REMOVAL OF STEERING WHEEL

Remove the steering wheel by using the special tool.

**Caution**


Do not hammer on the steering wheel. Doing so may damage the collapsible column mechanism.




13R0655

#### 4. REMOVAL OF COLUMN COVER LOWER / 5. COLUMN COVER UPPER

Front of vehicles



19F0123



**INSPECTION**

- (1) Remove the knee protector and the column cover. (Refer to GROUP 23A – Instrument Panel.)
- (2) Disconnect the column switch left connector (16 terminals) and check the continuity between the terminals for each switch.

**LIGHTING SWITCH**

Operate the switch and check the continuity between the terminals.

Terminal	3	5	6	7	10	14
Switch position						
OFF						
☞☛						
☸☹	○	○	○	○	○	○

**NOTE**

○—○ indicates that there is continuity between the terminals.

**TURN SIGNAL SWITCH**

Operate the switch and check the continuity between the terminals.

Terminal	1	12	13
Switch position			
Left	○	○	○
Neutral			
Right	○	○	

**NOTE**

○—○ indicates that there is continuity between the terminals.

**DIMMER/PASSING SWITCH**

Operate the switch and check the continuity, between the terminals.


Terminal	2	8	9	16
Switch position				
Dimmer switch	LOW		○	○
	HIGH		○	○
Passing switch	○	○	○	

**NOTE**

○—○ indicates that there is continuity between the terminals.

**WIPER AND WASHER SWITCH**

Refer to P.8-355.



## SERVICE POINTS OF INSTALLATION

### 2. INSTALLATION OF STEERING WHEEL

To center the clock spring, line up the "NEUTRAL" mark of the clock spring with the mating mark.

#### Caution

If the clock spring's mating mark is not properly aligned, the steering wheel may not be completely rotational during a turn, or the flat cable within the clock spring may be severed, obstructing normal operation of the SRS and possibly leading to serious injury to the vehicle's driver.

# WIPER AND WASHER SYSTEM

## SPECIFICATIONS

### GENERAL SPECIFICATIONS



t e r n s	Specifications
Windshield wiper motor Type Speed control system Braking system rpm at load of 1 Nm (0.72 ft.lbs.) Low speed High speed Nominal torque   Nm (ft.lbs.)	Ferrite-magnet type Third brush system Dynamic brake system  48 ± 4 70 ± 7 24 (17)
Rear wiper motor Motor type Braking system rpm at load of 0.6 Nm (0.43 ft.lbs.)	Ferrite-magnet type Dynamic braking system  38 ± 5
Windshield wiper blade Wiping angle Driver's side Passenger's side Wiper blade length   mm (in.) Driver's side Passenger's side	89" 91"  525 (20.7) 500 (19.7)
Rear wiper blade Wiping angle Wiper blade length   m m ( i n . )	87" ± 1.5" 550 (21.7)
Window washer motor and pump Motor type Pump type Power consumption A Time of continuous use   sec. With washer fluid Empty operation Nozzle jet pressure   kPa (psi) Tank capacity   lit. (qts.)	Direct current ferrite magnet type Centrifugal type 3.8 or less  Max. 60 Max. 20 120 (17) or more 2.0 (2.1) or more
Rear window washer motor and pump Motor type Pump type Power consumption A Time of continuous use   sec. With washer fluid Empty operation Nozzle jet pressure   kPa (psi) Tank capacity   lit. (qts.)	Direct current ferrite magnet type Centrifugal type 3.8 or less  Max. 60 Max. 20 120 (17) or more 1.2 (1.3) or more

Items	Specifications
Wiper and washer switch Rated load A Wiper switch LO, HI INT Washer switch Voltage drop (at 12V and the rated load) V Wiper switch Washer switch	4 0.22 ± 0.05 Max. 4 0.2 or less 0.5 or less
Rear wiper and washer switch Rated load A Wiper switch Washer switch Voltage drop V	5 5 0.1 or less
Intermittent wiper relay <Front (incorporated in column switch)> Intermittent interval (min.-max.) sec. Variable-interval intermittent wiper Delay time in washer moving sec. <Rear> Intermittent interval sec.	Approx. 3 – 12 0.6 8 ± 2

**SERVICE SPECIFICATIONS**

Items	Specifications
Standard value Front wiper blade park position (A) mm (in.)	15 <sup>+5</sup> <sub>-0</sub> (.6 <sup>+2</sup> <sub>-0</sub> )


**SPECIAL TOOL**


Tool number and tool name	Replaced by Miller tool number	Application
 MB990449 Window moulding remover	M B990449	Removal of liftgate moulding, upper
 MB991502 Scan Tool (MUT-II)	DRB-II Scan Tool	Checking the wiper and washer system
 MB991529 Diagnostic trouble code check harness	MB991529	Checking the wiper and washer system using a voltmeter

# TROUBLESHOOTING



## WINDSHIELD WIPER AND WASHER CIRCUIT

### CIRCUIT DIAGRAM






**COMPONENT LOCATION**  
Wiper relay




\*1: VEHICLES WITHOUT THEFT-ALARM SYSTEM  
\*2: VEHICLES WITH THEFT-ALARM SYSTEM

**Data link connector**



**ETACS unit**



**OPERATION****<Low-speed (and high-speed) wiper>**

- When the wiper switch is placed in the LO position with the ignition switch in the ACC or ON position, wipers operate continuously at low speed.
- Placing the wiper switch in the HI position causes the wipers to operate at high speed.

**<Intermittent wiper>**

- If the wiper switch is turned to the INT position when the ignition switch is in the ON or ACC position, the voltage value from the intermittent variable volume switch is input to the intermittent time detection circuit.
- The intermittent time detection circuit outputs an H signal at the intermittent time according to the set value of the intermittent variable volume switch and, via OR, turns the Tr on and off to operate the wiper.

**<Auto wiper stop>**

- When the wiper switch is placed in the OFF position, the cam contacts of wiper motor causes current to flow through the auto wiper stop circuit, allowing the wiper blades to cycle before they reach to the stop positions.

**<Mist wiper>**


- If the washer switch is on for 0.6 second or less when the ignition switch is at ON or ACC with the wiper switch turned off, the washer liquid will not be poured but the transistor will be turned on to operate the wipers one time.

**<Wiper linked with washer>**


- If the washer switch is on for 0.6 second or more when the ignition switch is at ON or ACC with the wiper switch turned off, the washer liquid will be poured and the transistor will be turned on 0.6 second later to operate the wipers two or three times.

**TROUBLESHOOTING HINTS**

Phenomenon		Inspection method
Wipers do not operate continuously	Washer does not operate.	<ul style="list-style-type: none"> <li>• Check the multi-purpose fuse No. ⑨.</li> </ul>
	Washer operates.	<ul style="list-style-type: none"> <li>• Check the wiper motor. (Refer to P.8-355.)</li> <li>• Check the column switch. (Refer to P.8-355.)</li> </ul>
Low-speed (or high-speed) wiper operation only is inoperative.		<ul style="list-style-type: none"> <li>• Check the column switch. (Refer to P.8-355.)</li> </ul>
Wipers do not operate intermittently. (They operate continuously.)		<ul style="list-style-type: none"> <li>• Check the wiper switch "INT" input signal. (Refer to P.8-351.)</li> <li>• Check the column switch. (Refer to P.8-355.)</li> </ul>
Wipers do not stop.		<ul style="list-style-type: none"> <li>• Check the wiper switch "INT" input signal. (Refer to P.8-351.)</li> <li>• Check the column switch; (Refer to P.8-355.)</li> <li>• Check the wiper motor. (Refer to P.8-355.)</li> </ul>
The intermittent time will not vary even if the variable intermittent wiper control switch is operated.		<ul style="list-style-type: none"> <li>• Check the variable intermittent wiper control switch input signal. (Refer to P.8-351.)</li> <li>• Check the column switch. (Refer to P.8-355.)</li> </ul>
Even if the washer switch is on for 0.6 second or more, the washer will not operate.	The wipers linked with the washer operate.	<ul style="list-style-type: none"> <li>• Check the washer motor. (Refer to P.8-355.)</li> <li>• Check the washer nozzle and washer tube.</li> </ul>
	The wipers linked with the washer do not operate.	<ul style="list-style-type: none"> <li>• Check the washer switch input signal. (Refer to P.8-351.)</li> <li>• Check the washer switch. (Refer to P.8-355.)</li> </ul>



20F0164



MB991529

20F0163

**INPUT SIGNAL**

Using the scan tool or voltmeter, check whether or not the input signals from each switch are being input to the ETACS unit.

**When using the scan tool**

- (1) Connect the scan tool to the data link connector.

**Caution**

**Turn off the ignition switch beforehand whenever the scan tool is connected or disconnected.**

- (2) If the scan tool makes a peep sound when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.

**When using a voltmeter**

- (1) Connect a voltmeter to the ETACS terminal and the ground terminal of the data link connector using the special tool.
- (2) If the voltmeter pointer deflects once when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.

## REAR WIPER AND WASHER CIRCUIT

### OPERATION

#### <Low-speed wiper>

- When the rear wiper switch is placed in the ON position with the ignition switch in the ACC or ON position, wipers operate continuously at low speed.

#### <Auto wiper stop>

- When the rear wiper switch is placed in the OFF position, the cam contacts of wiper motor cause current to flow through the auto wiper stop circuit, allowing the wiper blades to cycle before they reach to the stop positions.

#### <Intermittent wiper>

- When the rear wiper switch is placed in the INT position with the ignition switch in ACC or ON position, the rear intermittent wiper relay is energized causing the rear intermittent wiper relay contacts to close and open repeatedly.
- When the contacts are closed, the wiper motor is energized.
- When the rear wiper motor is energized, the rear intermittent wiper relay contacts open; however, the cam contacts keep the rear wiper motor energized until the wiper blades return to their stop position.

### TROUBLESHOOTING HINTS



- Wipers do not operate.
  - Washer is not operative, either.
    - Check multi-purpose fuse No. ⑨.
    - Check ground.
- Low-speed wiper operation only is inoperative.
  - Check wiper switch.
- Wipers do not stop.
  - Check wiper motor.
  - Check rear intermittent wiper relay.
  - Check rear wiper switch.
- Intermittent wiper operation is inoperative.
  - Check terminal voltage of the rear intermittent wiper relay energized.  
(Refer to P.8-359 for information concerning the installation position of the intermittent wiper relay.)

Terminal No.	Voltage	C h e c k
2	0v	Rear intermittent wiper relay or rear wiper switch
	12v	Rear intermittent wiper relay
	0 ↔ 12v (alternating)	– (Normal)

- Washer is inoperative.
  - Check washer motor.
  - Check washer switch.


### COMPONENT LOCATION

#### Rear intermittent wiper relay






# WINDSHIELD WIPER AND WASHER REMOVAL AND INSTALLATION



16F0103



16F0188

### Removal steps of linkage

- 1. Wiper blade
- \* 2. Wiper arm
- 3. Front deck garnish
- 4. Air inlet garnish (RH)
- 5. Hole cover
- ◄► 6. Wiper motor
- 7. Linkage

### Removal steps of wiper motor

- 1. Wiper blade
- ◄► 2. Wiper arm
- 5. Hole cover
- ◄► 6. Wiper motor

### Removal of column switch (wiper washer switch)


- 15. Column switch (Refer to P.8-343.)

### Removal steps of washer tank

- 8. Battery
- 9. Battery tray
- 10. Washer tank
- 11. Washer motor
- 12. Washer fluid level sensor

### Removal steps of washer tube

- 8. Battery
- 9. Battery tray
- 13. Washer nozzle
- 14. Washer tube




**SERVICE POINTS OF REMOVAL**

**6. REMOVAL OF WIPER MOTOR**


- (1) Remove the wiper motor mounting bolts.
- (2) Using a plain screwdriver, detach the crank arm of the wiper motor from the linkage to remove the wiper motor.

**Caution**


Do not remove the crank arm from the wiper motor except when necessary, as the auto stop angle has been preset. When the crank arm is to be removed, make a mark on both of them before removal.



Inspection of Operation



Inspection of Stop Position



**INSPECTION**

**INSPECTION OF WIPER MOTOR**

Inspect the wiper motor mounted on the vehicle with its connector disconnected.

**Inspection of Wiper Motor Operation at LOW and HIGH Speeds**

Connect the battery to the wiper motor as shown, and check its operation at LOW and HIGH speeds.

**Inspection of Wiper Motor STOP Position**


- (1) Operate the wiper motor at LOW speed and intermediately disconnect the battery to let the wiper motor stop.
- (2) Connect the terminals as well as the battery, as shown, and check that the wiper motor stops at the automatically-stopped position following LOW-speed operation.

**INSPECTION OF COLUMN SWITCH**

- (1) Remove the knee protector.  
(Refer to GROUP 23A – Instrument Panel.)
- (2) Remove the column cover.
- (3) Remove the column switch right coupling connector (11 terminals).

**Inspection of Wiper and Washer Switch**

Operate the switch to check for continuity between the terminals.




16F0200

Switch position		Terminal No.								
		3	4	5	6	7	8	9	10	
Wiper switch	OFF				○					○
	INT	○			○				○	○
	LO			○	○					
	HI			○		○				
Variable intermittent wiper control switch			○						○	
Washer switch				○				○		

**NOTE**

○—○ denotes that there is continuity between the terminals.




### Inspection of Wiper Relay (Built-in Column Switch)

- (1) Check to ensure that there is continuity between terminals ⑤ and ⑩ and between the terminals ⑥ and ⑪, and that there is no continuity between terminals ⑥ and ⑪.
- (2) Connect the positive terminal of the battery to terminal ⑤ and the negative terminal to terminal ⑪ to check that the battery voltage is available at terminal ⑥.


### INSPECTION OF WASHER MOTOR

- (1) When the washer motor is inspected, make sure that it is mounted on the washer tank and that the washer tank is filled with water.
- (2) Connect the battery as shown to check whether water is pumped out.



### INSPECTION OF WASHER FLUID LEVEL SENSOR

- (1) Connect a circuit tester to the connector of the level sensor as shown.
- (2) Check that when the float is moved down, the circuit is closed and that when the float is moved up, the circuit is opened.




## SERVICE POINTS OF INSTALLATION


### 2. INSTALLATION OF WIPER ARM

- (1) The wiper arms, right and left, are different in shape. Check the identification symbol.
- (2) After the wiper blades have been set, install them in such a way that the ends of the wiper blades will stop at the specified positions (standard values).

Standard value: (A)  $15 \begin{smallmatrix} +5 \\ -0 \end{smallmatrix}$  ( $.6 \begin{smallmatrix} +.2 \\ -0 \end{smallmatrix}$  in.)



# REAR WIPER AND WASHER REMOVAL AND INSTALLATION



16F0104

### Removal steps of wiper motor



- Rear spoiler (Refer to GROUP 23A – Aero Parts.)
- + 1. Wiper blade
- 2. Wiper arm
- 3. Spacer
- 4. Wiper motor
- 5. Cap
- 6. Washer tank
- 7. Washer motor

### Removal steps of washer tube

- 8. Liftgate moulding, upper
  - 9. Washer nozzle
  - 10. Tube and grommet assembly
  - 11. Washertube
- Front pillar trim (RH)  
 Quarter trim (RH)  
 Quarter upper trim (RH) } (Refer to GROUP 23A – Trim.)  
 Rear roof rail trim  
 Rear side trim (RH)

### Removal steps of washer tank




- Rear end trim (Refer to GROUP 23A – Trim.)
- 5. Cap
- 6. Washer tank
- 7. Washer motor



Inspection of operation



Inspection of stop position



**SERVICE POINT OF REMOVAL**

**8. REMOVAL OF LIFTGATE MOULDING, UPPER**

Using a special tool, pry the clip portion to remove the upper liftgate moulding.

**INSPECTION**

**WIPER MOTOR**

Check the wiper motor with it mounted on the vehicle and with its harness connector disconnected.

**Operation of Wiper Motor**

Connect a battery to the wiper motor, as shown, to check the operation of the wiper motor.

**Wiper Motor Stop Position**

- (1) Operate the wiper motor by the procedure described above and intermediately disconnect the battery to let the wiper motor stop.
- (2) Reconnect the battery as shown and check that the wiper motor stops at the automatically-stopped position after operation.


**WIPER WASHER SWITCH**

- (1) Remove switch garnish B from the knee protector.
- (2) Operate the switch to check for continuity between the terminals.

Switch position		Terminal							
		2	4	5	6	7	8	1	3
Wiper switch	OFF		O-O						
	INT		O-O			O-O			
	ON			O-O					
Washer switch	OFF								
	ON	O-O			O-O				

ILL


NOTE  
O-O denotes that there is continuity between the terminals



**INTERMITTENT WIPER RELAY**


- (1) Remove the quarter trim. (Refer to Group 23A – Trim.)
- (2) With the intermittent wiper relay connected to the wiring harness connector, let the wiper operate intermittently and check the voltage at terminal ②.

Condition	Standard
When wiper is stationary	0v
When wiper is in operation	Battery voltage



**WASHER MOTOR**

- (1) When the washer motor is inspected, make sure that it is mounted on the washer tank and that the washer tank is filled with water.
- (2) Connect the battery as shown to check whether water is pumped out.



**SERVICE POINT OF INSTALLATION**

**2. INSTALLATION OF WIPER ARM**

After assembling the wiper blade to the wiper arm, install the wiper arm with its tip positioned along the ceramic part.

# HORN

## SPECIFICATIONS

### GENERAL SPECIFICATIONS


Items	Specifications	
Type	Flat type	Flat type*
Effective sounding voltage V	11.5-15	11 – 14.5"
Power consumption A	3.0	Max. 3.5"
Sound level dB		
"low" sound	100-112	—
"high" sound	100-112	105 – 120*
Fundamental frequency Hz		
"low" sound	350 – 390	—
"high" sound	395 – 435	405 – 435"

NOTE: The \* symbol is applicable to vehicles equipped with the theft-alarm horn.

## TROUBLESHOOTING


<VEHICLES WITHOUT THEFT-ALARM SYSTEM>

### CIRCUIT DIAGRAM




### COMPONENT LOCATION

Horn relay




<VEHICLES WITH THEFT-ALARM SYSTEM>  
CIRCUIT DIAGRAM




## COMPONENT LOCATION

## Theft-alarm horn relay



## Horn relay



## OPERATION

- The horn switch always receives battery voltage via the dedicated fuse ⑥ and the coil of the horn relay.
- When the horn switch is set to ON, the contacts of the horn relay close. Then current flows through the dedicated fuse ⑥ to the contacts of the horn relay, the horn and ground, causing the horn to sound.

## TROUBLESHOOTING HINTS

- One of the horn does not sound.
- Check the horn.
2. Horns do not sound.
- Check the horn switch.
  - Check the dedicated fuse ⑥.

## NOTE

- (1) For vehicles equipped with the theft-alarm system, refer to P.8-412.
- (2) For information concerning the horn relay and theft-alarm horn relay, refer to P.8-363.


## HORN SWITCH

## REMOVAL AND INSTALLATION

**CAUTION: SRS**  
Before removal of air bag module, refer to GROUP 23B – SRS Service Precautions and Air Bag Module and Clock Spring.

## Removal steps

1. Air bag module (Refer to GROUP 23B – Air Bag Module and Clock Spring.)
2. Horn switch (Steering wheel assembly)




# RELAY

## INSPECTION

### HORN RELAY


Connect battery to terminal 1 and check continuity between terminals with terminal 3 grounded.



Power is supplied	4 – 5 terminals	Continuity
Power is not supplied	4 – 5 terminals	No continuity
	1 – 3 terminals	Continuity

### THEFT-ALARM HORN RELAY

Connect battery to terminal 2 and check continuity between terminals with terminal 4 grounded.



Power is supplied	1 – 3 terminals	Continuity
Power is not supplied	1 – 3 terminals	No continuity
	2 – 4 terminals	Continuity

# CIGARETTE LIGHTER


## SPECIFICATIONS


### GENERAL SPECIFICATIONS

Items	Specifications
Max. input W	120
Reset time second	Within 18
Thermal fuse fusion temperature °C(°F)	180–250 (356 – 482)

## TROUBLESHOOTING

### CIRCUIT DIAGRAM



**CIGARETTE LIGHTER****REMOVAL AND INSTALLATION**

16F0274

**INSPECTION**

- Take out the plug, and check for a worn edge on the element spot connection, and for shreds of tobacco or other material on the element.
- Using an ohmmeter, check the continuity of the element.

**CAUTIONS FOR USE OF THE CIGARETTE LIGHTER SOCKET AS AUXILIARY POWER SOURCE**

1. When using a "plug-in" type of accessory, do not use anything with a load of more than 120W.
2. It is recommended that only the lighter be inserted in the receptacle.  
Use of "plug-in" type accessories may damage the receptacle and result in poor retention of the lighter.


**NOTE**


The specified load should be strictly observed, because overloaded cord burns the ignition switch and harness.

# RADIO AND TAPE PLAYER


## TROUBLESHOOTING

<RADIO AND TAPE PLAYER (WITH AMPLIFIER)>  
CIRCUIT DIAGRAM






<RADIO AND TAPE PLAYER (WITH AMPLIFIER)> (CONTINUED)




<RADIO AND TAPE PLAYER (WITHOUT AMPLIFIER)>


CIRCUIT DIAGRAM




RADIO AND TAPE PLAYER




<RADIO AND TAPE PLAYER (WITHOUT AMPLIFIER)> (CONTINUED)






<VEHICLES HARNESS WITHOUT RADIO AND TAPE PLAYER>


CIRCUIT DIAGRAM





**COMPONENT LOCATION**

**Motor antenna control unit**




## TROUBLESHOOTING CHART

Item	Problem symptom	Relevant chart
Noise	Noise appears at certain places when traveling (AM).	A-1
	Noise appears at certain places when traveling (FM).	A-2
	Mixed with noise, only at night (AM).	A-3
	Broadcasts can be heard but both AM and FM have a lot of noise.	A-4
	There is more noise either on AM or on FM.	A-5
	There is noise when starting the engine.	A-6
	Some noise appears when there is vibration or shocks during traveling.	A-7
	Noise sometimes appears on FM during traveling.	A-8
	Ever-present noise.	A-9
Radio	When switch is set to ON, no power is available.	B-1
	No sound from one speaker.	B-2
	There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.	B-3
	Insufficient sensitivity.	B-4
	Distortion on AM or on both AM and FM.	B-5
	Distortion on FM only.	B-6
	Too few automatic select stations.	B-7
	Insufficient memory (preset stations are erased).	B-8
Cassette player	Cassette tape will not insert.	C-1
	No sound.	C-2
	No sound from one speaker.	C-3
	Sound quality is poor, or sound is weak.	C-4
	Cassette tape will not eject.	C-5
	Uneven revolution. Tape speed is fast or slow.	C-6
	Automatic search does not work	C-7
	Faulty auto reverse.	C-8
	Tape gets caught in mechanism.	c-9
CD player	CD will not be accepted.	D-1
	No sound.	D-2
	CD sound skips.	D-3
	Sound quality is poor.	D-4
	CD will not be ejected.	D-5
	No sound from one speaker.	D-6
Motor antenna	Motor antenna won't extend or retract.	E-1
	Motor antenna extends and retracts but does not receive.	E-2


CHART

A. NOISE

A-1 Noise appears at certain places when traveling (AM).



**A-Z | Noise appears at certain places when traveling (FM).**



No

↓  
If there is more noise than other radios, find out the noise conditions and the name and frequency of the receiving stations from the user, and consult with the service center.

**NOTE**

About FM waves:


FM waves have the same properties as light, and can be deflected and blocked. Wave reception is not possible in the shadow of obstructions such as buildings or mountains.

1. The signal becomes weak as the distance from the station's transmission antenna increases. Although this may vary according to the signal strength of the transmitting station and intervening geographical formations or buildings, the area of good reception is approx. 20 – 25 km (12 – 16 miles) for stereo reception, and 30 – 40 km (19 – 25 miles) for monaural reception.
2. The signal becomes weak when an area of shadow from the transmitting antenna (places where there are obstructions such as mountains or buildings between the antenna and the car),


and noise will appear. <This is called first fading, and gives a steady buzzing noise.>

3. If a direct signal hits the antenna at the same time as a signal reflected by obstructions such as mountains or buildings, interference of the two signals will generate noise. During traveling, noise will appear each time the vehicle's antenna passes through this kind of obstructed area. The strength and interval of the noise -varies according to the signal strength and the conditions of deflection. <This is called multipath noise, and is a repetitious buzzing.>
4. Since FM stereo transmission and reception has a weaker field than monaural, it is often accompanied by a hissing noise.

**FM Broadcast Good Reception Areas**



**FM Signal Characteristics and Signal Interference**



**A-3 | Mixed with noise, only at night (AM).**


The following factors can be considered as possible causes of noise appearing at night.

1. Factors due to signal conditions: Due to the fact that long-distance signals are more easily received at night, even stations that are received without problem during the day may experience interference in a general worsening of reception conditions. The weaker a station is the more susceptible it is to interference, and a change to a different station or the appearance of a beating


sound\* may occur.

Beat sound\*: Two signals close in frequency interfere with each other, creating a repetitious high-pitched sound. This sound is generated not only by sound signals but by electrical waves as well.

2. Factors due to vehicle noise: Generator noise may be a cause.



**A-4 Broadcasts can be heard but both AM and FM have a lot of noise.**



**NOTE**


About noise encountered during FM reception only. Due to differences in FM and AM systems, FM is not as susceptible as AM to interference from engines, power lines, lightning, etc. On the other hand, there are cases due to the characteristics of FM waves of noise or distortion generated by typical

noise interference (first fading and multipath). (Refer to A-2.)

<Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>

**A-5 | There is more noise either on AM or on FM.**

1. There is much noise only on AM  
 Due to differences in AM and FM systems, AM is more susceptible to noise interference.



2. There is much noise only on FM  
 Due to differences in FM and AM systems, FM is not as susceptible as AM to interference from engines, power lines, lightning, etc. On the other hand, there are cases due to the characteristics of FM waves of noise or distortion

generated by typical noise interference (first fading and multipath). (Refer to A-2) <Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>

**A-6 There is noise when starting the engine.**

Noise type Sounds are in parentheses ( ).	Conditions	Cause	Inspection or replacement	
			Noise-preventive part	Mounting place (next page)
AM, FM: Ignition noise (Popping, Snapping, Cracking, Buzzing)	<ul style="list-style-type: none"> <li>Increasing the engine speed causing the popping sound to speed up, and volume decreases.</li> <li>Disappears when the ignition switch is turned to ACC.</li> </ul>	<ul style="list-style-type: none"> <li>Mainly due to the spark plugs.</li> <li>Due to the engine noise.</li> </ul>	<ul style="list-style-type: none"> <li>Noise filter</li> <li>Ground cable</li> <li>Noise condenser</li> </ul>	<p>2 2, 3, 4 1, 2</p>
Other electrical components		Noise may appear as electrical components become older.	Repair or replace electrical components.	
Static electricity (Cracking, Crinkling)	<ul style="list-style-type: none"> <li>Disappears when the vehicle is completely stopped.</li> <li>Severe when the clutch is engaged.</li> </ul>	Occurs when parts or wiring move for some reason and contact metal parts of the body.	Return parts or wiring to their proper position.	
	<ul style="list-style-type: none"> <li>Various noises are produced depending on the body part of the vehicle.</li> </ul>	Due to detachment from the body of the front hood, bumpers, exhaust pipe and muffler, suspension, etc.	Ground parts by bonding. Cases where the problem is not eliminated by a single response to one area are common, due to several body parts being imperfectly grounded.	

**Caution**

1. **Connecting a high tension cable to the noise filter may destroy the noise filter and should never be done.**
2. **Check that there is no external noise. Since failure to do this may result in misdiagnosis due to inability to identify the noise source, this operation must be performed.**
3. **Noise prevention should be performed by suppressing strong sources of noise step by step.**






**NOTE**

1. Condenser  
The condenser does not pass D.C. current, but as the number of waves increases when it passes A.C. current, impedance (resistance


against A.C.) decreases, and current flow is facilitated. A noise suppressing condenser which takes advantage of this property is inserted between the power line for the noise source and the ground. This suppresses noise by grounding the noise component (A.C. or pulse signal) to the body of the vehicle.

2. Coil  
The coil passes D.C. current, but impedance rises as the number of waves increases relative to the A.C. current. A noise suppressing coil which takes advantage of this property is inserted into the power line for the noise source, and works by preventing the noise component from flowing or radiating out of the line.


NOISE SUPPRESSION PARTS MOUNTING POSITIONS



**A-7** Some noise appears when there is vibration or shocks during traveling.



## A-8 | Noise sometimes appears on FM during traveling.



\* About multipath noise and fading noise  
Because the frequency of FM waves is extremely high, it is highly susceptible to effects from geological formations and buildings. These effects disrupt the broadcast signal and obstruct reception in several ways.

- Multipath noise  
This describes the echo that occurs when the broadcast signal is reflected by a large obstruc-

tion and enters the receiver with a slight time delay relative to the direct signal (repetitious buzzing).

- Fading noise  
This is a buzzing noise that occurs when the broadcast beam is disrupted by obstructing objects and the signal strength fluctuates intricately within a narrow range.

**A-9 Ever-present noise.**


Noise is often created by the following factors, and often the radio is OK when it is checked individually.

- Traveling conditions of the vehicle
- Terrain of area traveled through
- Surrounding buildings
- Signal conditions
- Time period


For this reason, if there are still problems with noise even after the measures described in steps A-1 to A-8 have been taken, get information on the factors listed above as well as determining whether the problem occurs with AM or FM, the station names, frequencies, etc., and contact a service center.

**B. RADIO**


**B-1 No power is supplied when the switch is set to ON.**




**B-2 No sound from one speaker.**



**B-3** There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.




**B-4 | Insufficient sensitivity.**




\* For multipath noise and fading noise problems, refer to P.8-384.


**B-5 | Distortion on AM or on both AM and FM.**




**B-6 | Distortion on FM only**



**B-7 Too few automatic select stations.**




**B-8 Insufficient memory (preset stations are erased).**




C. CASSETTE PLAYER


**C-1** **Cassette tape will not be inserted.**




**C-2** **No sound (even after a #ape has been inserted).**




C-3 | No sound from one speaker.




**C-4 | Sound quality is poor, or sound is weak.**

**C-5 | Cassette tape will not eject.**


The problems covered here are all the result of the use of a bad tape (deformed or not properly tightened) or of a malfunction of the cassette player itself. Malfunctions involving the tape becoming caught in the mechanism and ruining the case are also possible, and attempting to force the tape out of the player can cause damage to the mechanism. The player should be taken to a service dealer for repair.

**C-6 Uneven revolution. Tape speed is fast or slow.**




**C-7 Automatic search does not work.**



**C-9 Faulty auto reverse.****C-9 Tape gets caught in mechanism\*1.**


\*1

When the tape is caught in the mechanism, the case may not eject. When this occurs, do not try to force the tape out as this may damage the tape player mechanism. Take the cassette to a service dealer for repair.




D. CD PLAYER

**D-I CD will not be accepted.**




- \*1 If the CD is already loaded, doesn't the shutter open to allow insertion when another CD is inserted?
- \*2 If the key switch is not at ACC or ON, the CD stops at depth of 15 mm below the panel surface even when it is inserted, and it will be rejected when pushed farther?
- \*3 Even though the CD is loaded, E (error) is sometimes displayed with the CD rejected because of vibration/shock or dew on the CD face or optical lens.

**D-2 No sound.**




**D-3 CD sound skips.**


1. Sound sometimes skips during parking.




2. Sound sometimes skips during driving.  
 (Stop vehicle, and check it.)  
 (Check it by using a proper CD which is free of scratch, dirt or other abnormality.)




**D-4 Sound quality is poor.**



**D-5 CD will not be ejected.**




**D-6 No sound from one speaker.**





E. MOTOR ANTENNA

**E-1 | Motor antenna won't extend or retract.**

Clean and polish the surface of the antenna rod.



**E-2 Motor antenna extends and retracts but does not receive.**




Checking the antenna\*


Ohmmeter measurement locations	Result
Circuits from F to A, B, C, D and E	Continuity
Circuit between G and H	Continuity
Circuits from H to A, B, C, D and E	No continuity

**RADIO REMOTE-CONTROL****REMOVAL AND INSTALLATION****CAUTION: SRS**

When removing and installing the radio remote control switch, don't allow any impact or shock to the air bag module.



16F0491


**RADIO AND TAPE PLAYER****REMOVAL AND INSTALLATION****Removal steps**

1. Radio panel
2. Radio and tape player
3. CD player
4. Radio bracket
5. Front console assembly (Refer to GROUP 23A – Console Box.)

16F0096

**SPEAKER**  
**<DOOR SPEAKER>**

**REMOVAL AND INSTALLATION**




**Removal steps**

1. Door trim (Refer to GROUP 23A – Door Trim and Waterproof Film.)
2. Speaker garnish
3. Speaker
4. Speaker cover

16F0279

**<REAR SPEAKER>**


**REMOVAL AND INSTALLATION**



**Removal steps**

1. Quarter trim (Refer to GROUP 23A – Trim.)
2. Speaker garnish
3. Speaker
4. Speaker box

16F0097

**MOTOR ANTENNA · ANTENNA FEEDER CABLE · AMPLIFIER****REMOVAL AND INSTALLATION**

16F0497

**Removal steps of motor antenna**

- Rear side trim (LH)  
(Refer to GROUP 23A – Trim.)
1. Ring nut
  2. Base
  3. Antenna pole
  4. Antenna feeder cable and motor antenna connection
  5. Motor antenna

**Removal steps of antenna feeder cable**


- Rear side trim (LH) } (Refer to GROUP 23A  
Quarter trim (LH) } –Trim.)
- Rear console assembly  
(Refer to GROUP 23A–Console Box.)  
Radio and tape player  
(Refer to P.8-400)
4. Antenna feeder cable and motor antenna connection
  6. Rear seat cushion
  7. Rear seatback
  8. Inner seat belt
  9. Console side cover (LH)
  10. Antenna feeder cable
  11. Sub antenna feeder cable

**Amplifier removal**

12. Amplifier (under passenger's seat)

**WHIP ANTENNA · ANTENNA FEEDER CABLE · AMPLIFIER**

**REMOVAL AND INSTALLATION**



16F0492

**Removal steps of whip antenna**


- Rear side trim (LH)  
(Refer to GROUP 23A – Trim.)
- 1. Mast antenna
- 2. Mounting nut
- 3. Mounting insulator and packing
- 4. Antenna base and antenna feeder connection
- 5. Antenna base

**Removal steps of antenna feeder**

- Rear side trim (LH) } (Refer to GROUP 23A
- Quarter trim (LH) } –Trim.)
- Rear console assembly  
(Refer to GROUP 23A – Console Box.)
- Radio and tape player  
(Refer to P.8-400)
- 4. Antenna feeder cable and antenna base connection
- ◆ ● + 6. Rear seat cushion
- 7. Rear seatback
- 8. Inner seat belt
- 9. Console side cover (LH)
- 10. Antenna feeder cable
- 11. Sub antenna feeder cable

**Amplifier removal**

- 12. Amplifier (under passenger's seat)




19F0063

**SERVICE POINT OF REMOVAL**

**6. REMOVAL OF REAR SEAT CUSHION**

Raise and remove the seat cushion with the lever pulled.




16F0186

16F0199

**INSPECTION**

**INSPECTION OF ANTENNA MOTOR <VEHICLE WITH MOTOR ANTENNA>**


Disconnect the motor antenna control unit connector, connect the positive terminal of the power supply to terminal ① and connect the negative terminal to terminal ④ to check that the antenna goes up, and that when the connections are reversed, the antenna goes down.



**INSPECTION OF MOTOR ANTENNA CONTROL UNIT <VEHICLE WITH MOTOR ANTENNA>**

- (1) Connect the harness connector to the motor antenna.  
(Body harness)
- (2) Disconnect the antenna motor connector.
- (3) With the ignition switch in the ACC or ON position, operate the radio switch and check the voltage between the terminals during the period when the antenna is going up or going down.


Antenna operating direction	Terminals to check	Voltage (V)
Down	1 - 3	10 - 13
Up	3 - 4	10 - 13



**SERVICE POINT OF INSTALLATION**


**6. INSTALLATION OF REAR SEAT CUSHION**

- (1) Securely fit the attachment wire of the seat cushion under the seatback.
- (2) Pass the inner seat belt buckles through the cushion.
- (3) Securely fit the lock plates of the seat cushion into the holes in the floor.




**REPLACEMENT OF ANTENNA POLE <VEHICLE WITH MOTOR ANTENNA>**

- (1) Remove the ring nut.





- (2) Set the radio switch to ON. After the antenna pole has extended, remove the antenna pole and rack cable as an assembly.



- (3) Extend the antenna pole up to its farthest point.  
NOTE  
If the motor end of the rack cable is bent, straighten it.
- (4) Force the rack cable into the motor assembly with the tooth side of the rack cable toward the luggage compartment.
  
- (5) Turn the tooth side of the rack cable toward the rear of the vehicle (90° clockwise) to bring the rack cable into mesh with the motor gear.
- (6) Lightly pull the rack cable. If it comes out without resistance, it means that the rack cable is not in mesh with the motor gear. Recheck that the rack cable end is not bent before repeating the above-mentioned steps (2) and (3).
- (7) With the antenna pole upright and the radio switch at OFF, take up the rack cable. As the rack cable is taken up, insert the antenna pole toward the motor antenna.
- (8) After the ring nut has been tightened, set the radio switch to ON and OFF to check the operation of the antenna pole.

## CD AUTO CHANGER

### REMOVAL AND INSTALLATION




16F0495

#### Removal steps

1. CD changer cover  
Luggage compartment floor carpet, high floor center board.
2. CD auto changer
3. CD changer bracket (front)
4. CD changer bracket (rear)


# REAR WINDOW DEFOGGER

## SPECIAL TOOL

Tool number and tool name	Replaced by Miller tool number	Application
 <p>MB991 502 Scan Tool (MUT-II)</p> <p>16X0606</p>	DRB-II Scan Tool	Checking the rear window defogger system
 <p>MB991 529 Diagnostic trouble code check harness</p>	M B991529	Checking the rear window defogger system using a voltmeter

**TROUBLESHOOTING**

**CIRCUIT DIAGRAM**



## OPERATION

- If the defogger switch is turned to “ON” when the generator is generating electricity (L terminal exceeds 1 OV.) with the ignition switch at the “ON” position, the timer circuit in the ETACS unit will be operated to keep the transistor “on” for 11 minutes to close the contact point of the defogger relay. When the defogger relay is “on”, the defogger and mirror heater will be activated. Moreover, the indicator light of the defogger switch is lit to inform that the defogger and mirror heater are activated.
- When 11 minutes have passed, the defogger and mirror heater will stop activating even if the defogger switch is at “ON”. When the defogger and mirror heater are activated (the timer is activated), they will also stop activating even if the defogger switch is set at “ON” again or if the generator stops generating electricity (the terminal is 3.5V or less.)

## NOTE

The light automatic shut-off system is valid for the illumination light of the defogger switch. (Refer to P.8-304.)

## TROUBLESHOOTING HINTS


Phenomenon	Checking method
Mirror heater operates but defogger does not operate.	<ul style="list-style-type: none"> <li>• Check the defogger (Refer to P.8-410.)</li> </ul>
Defogger operates but mirror heater does not operate.	<ul style="list-style-type: none"> <li>• Check the dedicated fuse No. ⑩.</li> <li>• Check the mirror heater. (Refer to GROUP 23A – Door Mirror.)</li> </ul>
Neither defogger nor mirror heater operates.	<ul style="list-style-type: none"> <li>• Check the multi-purpose fuse No. ③.</li> <li>• Check the defogger relay. (Refer to P.8-411.)</li> <li>• Check the defogger switch. (Refer to P.8-410.)</li> <li>• Check the defogger switch input signal. (Refer to P.8-409.)</li> <li>• Check the ignition switch input signal. (Refer to P.8-409.)</li> <li>• Check the generator. (Refer to P.8-233.)</li> </ul>
Illumination light of defogger switch does not come on or is dim.	<ul style="list-style-type: none"> <li>• Check the illumination light bulb.</li> <li>• Check the rheostat. (Refer to P.8-341.)</li> </ul>

## NOTE


For the troubleshooting hints of the automatic light shut-OFF system, refer to P.8-315

## COMPONENT LOCATION


Data link connector




ETACS unit



Defogger relay





### Input Signal

Using the scan tool or voltmeter, check whether or not the input signals from each switch are being input to the ETACS unit.


### When using the scan tool

- (1) Connect the scan tool to the data link connector.

#### Caution

**Turn off the ignition switch beforehand whenever the scan tool is connected or disconnected.**

- (2) If the scan tool makes a peep sound when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.



### When using a voltmeter

- (1) Connect a voltmeter to the ETACS terminal and the ground terminal of the data link connector using the special tool.
- (2) If the voltmeter pointer deflects once when each switch is operated (turned ON/OFF), the input signal to ECU is normally sent from the switch circuit system.

## SERVICE ADJUSTMENT PROCEDURES

### THE PRINTED-HEATER LINES CHECK

- (1) Run engine at 2,000 rpm. Check heater element with battery at full.
  - (2) Turn ON rear window defogger switch. Measure heater element voltage with circuit tester at rear window glass center A.
- Condition good if indicating about 6 V.
- (3) If 12 V is indicated at A, there is a break in the negative terminals from A.  
Move test bar slowly to negative terminal to detect where voltage changes suddenly (0 V).
  - (4) If 0 V is indicated at A, there is a break in the positive terminals from A. Detect where the voltage changes suddenly (12 V) with the same method described.

### THE PRINTED-HEATER LINES REPAIR

#### REQUIRED MATERIALS

- Thinner
- Tape
- Conductive paint
- Lead-free gasoline
- Fine brush

- (1) Clean disconnected area with lead-free gasoline. Tape along both sides of heater element.
- (2) Mix conductive paint thoroughly. Thin the required amount of paint in a separate container with a small amount of thinner and paint break three times at 15 minute intervals.
- (3) Remove tape and leave for a while before use (circuit complete).
- (4) When completely dry (after 24 hours) finish exterior with a knife.

#### Caution

**Clean glass with a soft cloth (dry or damp) along defogger heater element.**





## REAR WINDOW DEFOGGER SWITCH


- (1) Remove rear window defogger switch from the meter bezel. (Refer to P.8-340.)
- (2) Operate the switch and check the continuity between the terminals.

Switch position \ Terminal	1	2	3	4	5	6
OFF				○		
ON	0	○	○	○		
	0	IND		ILL		0

#### NOTE

○—○ indicates that there is continuity between the terminals.





## DEFOGGER RELAY

### INSPECTION

Connect battery power source to terminal 1. Check circuit between terminals with terminal 3 grounded.

Power is supplied	4 – 5 terminals	Continuity
Power is not supplied	4 – 5 terminals	No continuity
	1 – 3 terminals	Continuity


## THEFT-ALARM SYSTEM

### SPECIAL TOOL

Tool number and tool name	Replaced by Miller tool number	Application
<p>MB991 502 Scan Tool (MUT-II)</p> <p>16X0606</p>	DRB-II Scan Tool	Checking the theft-alarm system
<p>MB991 529 Diagnostic trouble code check harness</p>	MB991529	Checking the theft-alarm system using a voltmeter


# TROUBLESHOOTING


## CIRCUIT DIAGRAM






CIRCUIT DIAGRAM (CONTINUED)






COMPONENT LOCATION


Name	Symbol	Name	Symbol
Data link connector	F	Light automatic shut-off unit	G
Diode	D	Starter relay	A
ETACS unit	C	Theft-alarm horn relay	B
Headlight relay	A	Theft-alarm starter relay	E
Horn relay	A	–	–




16F0502




19F0134




16F0503




16F0189




16F0354






36F0021





16F0282



16F0498





**TROUBLESHOOTING GUIDE**

**CHECKING THE INPUT**

**When using the scan tool**

1. Connect the scan tool to the data link connector.

**Caution**

Turn off the ignition switch beforehand whenever the scan tool is connected or disconnected.

**When using a voltmeter**

1. Connect a voltmeter to the ETACS terminal and the ground terminal of the data link connector using the special tool.
2. Make sure that when the following switches are turned on, the output shown in the illustration is delivered. (Only those switches which are related to the theft-alarm system are listed here.)
  - Driver and front passenger door switches
  - Headlight switch
  - Driver and front passenger door lock switches
  - Passing light switch
  - Hood switch
  - Liftgate switch
  - Door key cylinder switch
  - Liftgate switch

Tester	output
Voltmeter	Rectangular wave  is output
Scan tool	Buzzer sound

If there is no output of a voltage pattern at all, check for a malfunction of that switch or for damaged or disconnected wiring.

**TROUBLESHOOTING QUICK-REFERENCE TABLE**

For information concerning the locations of electrical components, refer to P.8-416.

**1I. ARMING / DISARMING RELATIONSHIP**

Trouble symptom	Cause	Check method	Remedy
The system is not armed (The SECURITY light doesn't illuminate, and the alarm doesn't function.) (The central door locking system functions normally. If the central locking system does not function normally, refer to P.8-423.)	Damaged or disconnected wiring of ECU power supply circuit	Check by using check chart P.8-421.	Replace the fusible link No. ⑥ or the fuse No. ⑱. Repair the harness.
	Damaged or disconnected wiring of door switch input circuit	Check by using check chart P.8-422.	Repair the harness or replace the door switch.
The arming procedures are followed, but the SECURITY light does not illuminate. (There is an alarm, however, when an alarm test is conducted after about 20 seconds have passed.)	Damaged or disconnected wiring of SECURITY light activation circuit	Check by using check chart P.8-426.	Replace the fusible link No. ⑥ or the fuse No. ⑱. Repair the harness.
	Blown SECURITY light bulb		Replace the bulb.
	Malfunction of the ECU.		Replace the ECU.
The alarm sounds in error when, while the system is armed, a door or the liftgate is unlocked by using the key.	Damaged or disconnected wiring of a door key cylinder and the liftgate unlock switch input circuit.	If input checks P.8-418 indicate a malfunction, check by using check chart P.8-423.	Repair the harness or replace a door key cylinder and the liftgate unlock switch.
	Malfunction of a door key cylinder and the liftgate unlock switch.		
	Malfunction of the ECU.		Replace the ECU.

**2. ACTIVATION / DEACTIVATION RELATIONSHIP**

Trouble symptom	Cause	Check method	Remedy
There is no alarm when, as an alarm test, a door is opened without using the key. (The arming and disarming are normal, and the alarm is activated when the liftgate or hood is opened.)	Damaged or disconnected wiring of door switch (all doors) input circuit	If input checks P.8-418 indicate a malfunction, check by using check chart P.8-422.	Repair the harness or replace the door switch.
	Malfunction of the door switch		
	Malfunction of the ECU	—	Replace the ECU.
There is no alarm when, as an alarm test, the liftgate is opened without using the key. (The alarm is activated, however, by opening a door or the hood.)	Damaged or disconnected wiring of liftgate switch input circuit	If input checks P.8-418 indicate a malfunction, check by using check chart P.8-425.	Repair the harness or replace the liftgate switch.
	Malfunction of the liftgate switch.		
	Malfunction of the ECU.		Replace the ECU.
There is no alarm when, as an alarm test, the hood is opened from within the vehicle. (The alarm is activated, however, by opening a door or the liftgate.)	Damaged or disconnected wiring of hood switch input circuit.	If input checks P.8-418 indicate a malfunction, check by using check chart P.8-422.	Repair the harness or replace the hood switch.
	Malfunction of the hood switch.		
	Malfunction of the ECU.	—	Replace the ECU.

Trouble symptom	Cause	Check method	Remedy
Engine would not start [Engine starting is possible when the starter relay is in the switched-off (normally closed) condition, with the clutch switch in the switch-off and the ECU harness connector disconnected.]	There is a short-circuit of the starter relay activation circuit	Check by using check chart P.8-429.	Repair the harness.
When, as a test of the alarm, a door or the liftgate is opened without using the key, or the hood is opened from within the vehicle, the horn and the theft-alarm horn sound but the headlights don't flash. (The headlights can, however, be switched ON by using the passing switch.)	Damaged or disconnected wiring of headlight power supply circuit or headlight activation circuit	Check by using check chart P.8-428, 429.	Repair the harness or replace the diode D <sub>2</sub> . Replace the headlight relay or the headlight,
	Malfunction of the ECU.		Replace the ECU.
The headlights flash during an alarm test but the horn or the theft alarm horn does not sound.	Damaged or disconnected wiring of horn relay power supply circuit or horn activation circuit Damaged or disconnected wiring of the theft-alarm horn relay power supply circuit or the theft-alarm horn activation circuit.	Check by using check chart P.8-426, 427, 428.	Repair the harness. Replace the horn. Replace dedicated fuse No. ⑥ or the fusible link No. ⑥.
	Malfunction of the ECU.		Replace the ECU.
The system is not deactivated when, during an alarm test in which the alarm is intentionally activated, the door or liftgate is unlocked by using the key. (The system also cannot be disarmed.)	Damaged or disconnected wiring of door key cylinder and liftgate unlock switch input circuit	If input checks (P.8-418) indicate a malfunction, check by using check chart P.8-424, 425.	Repair the harness. Replace the key cylinder switch or the liftgate switch.
	Malfunction of door key cylinder and liftgate unlock switch.		
	Malfunction of the ECU		Replace the ECU.


ECU: Electronic Control Unit

NOTE

- (1) If the liftgate unlock switch or door key cylinder unlock switch is operated roughly, or if these switches have been installed incorrectly or switches themselves are defective the ECU may not accept the warning or alarm cancelling signal. In such case, the alarm operation will take place when the door is opened using a key.  
[When the door key cylinder switch has been shorted, however, if the ignition switch is turned ON, the ECU judges the detection switch as faulty and thereafter, it will prevent setting of (warning) alarm until the shorting is corrected.]
- (2) If the liftgate is opened using a key and is left opened when the door key cylinder switch system has a trouble (wiring harness damage, open circuit, etc.), the ECU judges it as the liftgate holding mode and does not produce alarm even when the door is opened.

CHECKING THE CIRCUIT AND INDIVIDUAL PART

1. ETACS POWER-SUPPLY AND GROUND CIRCUITS



KX35-AK-R5401-N4


Description of operation

The battery supplies a stabilized 5V power supply to the ECU, via the constant-voltage circuit and terminal 51 (which is directly connected to the battery).

ECU terminal voltage (Connection condition of the ECU connector).

ECU terminal No.	Signal	Condition	Terminal voltage
51	ECU power supply	At all times	12V

2. KEY-REMINDER SWITCH INPUT CIRCUIT



KX35-AK-R5402-N4


Description of operation

The key-reminder switch is switched OFF and HIGH-level signals are sent to the ECU when the key is inserted into the ignition key cylinder: when the key is removed, the key-reminder switch is switched ON and LOW-level signals are sent to the ECU.

ECU terminal voltage (Connection condition of the ECU connector).

ECU terminal No.	Signal	Condition	Terminal voltage
64	Key-reminder switch	Key removed	12V
		Key inserted	0V

3. HOOD SWITCH INPUT CIRCUIT



KX35-AK-R5403-N4

Description of operation


When the hood is closed (the hood switch is switched OFF), HIGH-level signals are sent to the ECU:  
 When the hood is opened (the hood switch is switched ON), LOW-level signals are sent to the ECU.

ECU terminal voltage (Connection condition of the ECU connector).

ECU terminal No.	Signal	Condition		Terminal voltage
18	Hood switch	Hood	Open	0V
			Closed	5V*

\* Measurement is not possible by using a voltmeter, but is possible by using an oscilloscope.

4. DOOR SWITCH INPUT CIRCUIT



KX35-AK-R5404-N4

Description of operation


When the door is closed (the door switch is switched OFF), HIGH-level signals are sent to the ECU:  
 When the door is opened (the door switch is switched ON), LOW-level signals are sent to the ECU.

ECU terminal voltage (Connection condition of the ECU)

ECU terminal No.	Signal	Condition		Terminal voltage
10	Driver door switch	Driver door	Open	0V
			Closed	5V*
	Passenger door switch	Passenger door	Open	0V
			Closed	5V*

\* Measurement is not possible by using a voltmeter, but is possible by using an oscilloscope.

5. DOOR LOCK ACTUATOR SWITCH INPUT CIRCUIT



Description of operation

When a door is locked by the lock knob or the key, the door lock actuator switch is switched OFF, and HIGH-level signals are sent to the ECU. These signals activate the timer circuit of the ECU, thereby causing the activation circuit to function, thus activating the door lock actuator of all doors.

ECU terminal voltage (Connection condition of the ECU connector).

ECU terminal No.	Signal	Condition	Terminal voltage
13	Door lock actuator switch (driver door)	Door lock actuator switch	Lock: OFF 5V*
		Unlock: ON	0V
14	Door lock actuator switch (passenger door)	Door lock actuator switch	Lock: OFF 5V*
		Unlock: ON	0V


\* Measurement is not possible by using a voltmeter, but is possible by using an oscilloscope.

6. DOOR KEY CYLINDER UNLOCK AND LIFTGATE CYLINDER LOCK SWITCH INPUT CIRCUIT

Description of operation


When the door key is rotated or the liftgate key is unlocked, LOW-level signals are sent to the ECU.

ECU terminal voltage (Connection condition of the ECU connector).



ECU terminal No.	Signal	Condition		Terminal voltage
		Door key cylinder (LH)	Door key cylinder (RH)	
19	Door key cylinder unlock switch	Not rotate	Not rotate	5V
		Rotate	Rotate	0V
		Not rotate	Rotate	5V
		Rotate	Rotate	0V
20	Liftgate unlock switch	Lock	Lock	5V
		Unlock	Unlock	0V

7. LIFTGATE SWITCH INPUT CIRCUIT



KX35-AK-R5407-N4

Description of operation


When the liftgate is closed (the liftgate switch is switched OFF), HIGH-level signals are sent to the ECU. When the liftgate is opened (the liftgate switch is switched ON), LOW-level signals are sent to the ECU.

ECU terminal voltage (Connection condition of the ECU connector).

ECU terminal No.	Signal	Condition	Terminal voltage
17	Liftgate switch	Liftgate Open	0V
		Liftgate Closed	5V*

\* Measurement is not possible by using a voltmeter, but is possible by using an oscilloscope.

8. SECURITY LIGHT ACTIVATION CIRCUIT




Description of operation

If all doors are in locked state after key-less locking, the ECU transistor is turned ON and the security light comes on.

Checking the security light activation circuit (Disconnect the connector of the ECU and check at the wiring harness side.)

Step	Check object	Judgement		Cause	Remedy
		Normal	Mal-function		
1	D-04 connector terminal voltage 51	12V	0V	Fuse (19) damaged or disconnected	Replace the fuse
				Harness damaged or disconnected, or short-circuit	Repair the harness
2	D-04 connector terminal voltage 52	12V	0V	Damaged or disconnected wiring of SECURITY light bulb	Replace the bulb
				Harness damaged or disconnected	Repair the harness
3	ECU terminal voltage 57	12V	0V	Harness damaged or disconnected, or short-circuit	Repair the harness

9. HORN RELAY POWER-SUPPLY CIRCUIT




Description of operation

Power voltage is always supplied to the horn relay.

Checking the horn relay power-supply circuit (Disconnect the horn relay)

Check object	Judgement		Cause	Remedy
	Normal	Mal-function		
HORN RELAY connector terminal voltage 5	12V	0V	Dedicated fuse (3) damaged or disconnected	Replace the fuse
			Damaged or disconnected harness	Repair the harness

10. HORN ACTIVATION CIRCUIT



Description of operation


The ECU transistor is turned 'ON if the vehicle door, etc. are opened without use of the key.

This energizes the horn relay to activate the horn.

Checking the horn activation circuit (Disconnect the connector of the ECU, then short-circuit terminal connector No. 58, and activate the horn relay.)

Step	Check object	Judgement		Cause	Remedy
		Normal	Mal-function		
1	Horn relay terminal voltage (4-Ground)	12V	0V	Malfunction of the horn relay	Check the horn relay (Refer to P.8-363.)
2	Horn terminal voltage (LH & RH) (1-Ground)	12V	0V	Harness damaged or disconnected	Repair the harness
3	Horn terminal voltage (LH & RH) (1'-Ground)	Horn sounds (0V)	Horn doesn't sound (0V)	Malfunction of the horn	Replace the horn
			Battery voltage	Damaged or disconnected wiring of ground circuit	Repair the harness

11. THEFT ALARM HORN RELAY POWER-SUPPLY CIRCUIT




Description of operation

Power voltage is always supplied to the theft alarm horn relay.

Checking the horn relay power-supply circuit (Disconnect the theft alarm horn relay)

Check object	Judgement		Cause	Remedy
	Normal	Mal-function		
THEFT ALARM HORN RELAY connector terminal voltage 1	12v	ov	Fuse (14) damaged or disconnected	Replace the fuse
			Damaged or disconnected harness	Repair the harness

12. THEFT ALARM HORN ACTIVATION CIRCUIT




Description of operation

The ECU transistor is turned ON if the vehicle door, etc. are opened without use of the key. This energizes the theft alarm horn relay to activate the horn. Checking the horn activation circuit (Disconnect the connector of the ECU, then short-circuit terminal connector No. 58, and activate the theft alarm horn relay.)

Step	Check object	Judgement		Cause	Remedy
		Normal	Mal-function		
1	Horn relay terminal voltage (1-Ground)	12V	0V	Malfunction of the horn relay	Check the horn relay (Refer to P.8-363.)
2	Horn terminal voltage (1-Ground)	12V	0V	Harness damaged or disconnected	Repair the harness
3	Horn terminal voltage (1-Ground)	Horn sounds (0V)	Horn doesn't sound (0V)	Malfunction of the horn	Replace the horn
			Battery voltage	Damaged or disconnected wiring of ground circuit	Repair the harness

13. HEADLIGHT POWER-SUPPLY CIRCUIT




Description of operation

Power voltage is always supplied to the headlight relay. Checking the headlight power-supply circuit (Disconnect the headlight relay)

Check object	Judgement		Cause	Remedy
	Normal	Mal-function		
(Wiring harness side) terminal voltage (5-Ground)	12V	0V	Fusible link (3) blown	Replace the fusible link
			Damaged or disconnected harness	Repair the harness

14. HEADLIGHT ACTIVATION CIRCUIT




Description of operation

The ECU transistor is turned ON if the vehicle door, etc. are opened without use of the key. This energizes the headlight relay to activate the headlight.

Checking the headlight activation circuit (Disconnect the connector of the ECU, then short-circuit terminal connector No. 2, and activate the headlight relay.)

Step	Check object	Judgement		Cause	Remedy	
		Normal	Mal-function			
1	Headlight relay terminal voltage (4-Ground)	12V	0V	Malfunction of the headlight relay	Check the headlight relay (Refer to P.8-338.)	
2	Headlight terminal voltage (2-Ground)	12V	0V	Harness damaged or disconnected	Repair the harness	
3	Headlight terminal voltage	Column switch		Malfunction of the headlight. Harness damaged or disconnected. Malfunction of column switch	Replace the headlight or column switch. Repair the harness.	
		<HI> (1-Ground)	12V			0V
		<LO> (1-Ground)	0V			0V

15. STARTER RELAY ACTIVATION CIRCUIT



Description of operation

The ECU transistor is turned ON if the vehicle door etc. are opened without use of the key. This turns OFF the starter relay and power ceases to be supplied to the starter magnet switch.

Checking the starter relay activation circuit (Disconnect the connector of the ECU, depress fully the clutch pedal and activate the starter relay)

Step	Check object	Judgement		Cause	Remedy
		Normal	Mal-function		
1	Starter relay terminal voltage (2-Ground)	12V	0V	Malfunction of the starter relay	Check the starter relay
2	Starter motor terminal (1-Ground)	12V	0V	Harness damaged or disconnected	Repair the harness
(Starter motor connector B-24: Separation)					
3	Continuity between "B-24" connector and ground	0 Ω	∞ Ω	Damaged magnet switch	Replace magnet switch

C

C

C

UNITED STATES



The special service tools referred to herein are required for certain service operations. These special service tools or their equivalent, if not obtainable through a local source are available through the following outlet.

12842 Farmington Road, Livonia, Michigan 48150, U.S.A.

**MILLER SPECIAL TOOLS**  
**SPX Corporation**

Telephone (313) 522-6717

FAX (313) 522-6505

CANADA



The special service tools referred to herein are required for certain service operations. These special service tools or their equivalent, if not obtainable through a local source are available through the following outlet.

C & D Riley Enterprises Ltd., P.O. Box 243, Amherstburg, Ontario N9V 2Z4

Telephone (519) 736-4600

FAX (5 19) 736-8433

INTERNATIONAL



The special service tools referred to herein are required for certain service operations. These special service tools or their equivalent, if not obtainable through a local source are available through the following outlet.

12842 Farmington Road, Livonia, Michigan 48150, U.S.A.

**MILLER SPECIAL TOOLS**  
**SPX Corporation**

Telephone (313) 522-6717

FAX (313) 522-6505



WE ENCOURAGE  
PROFESSIONALISM



THROUGH TECHNICIAN  
CERTIFICATION

**CustomerOne** ™